

A INTRODUCTION

This manual consists of the following 11 sections:

No.	Section	Description
A	INDEX	Index of the contents of this manual.
	INTRODUCTION	Brief explanation of each section.
B	HOW TO USE THIS MANUAL	Instructions on how to use this manual.
C	TROUBLE-SHOOTING	Describes the basic inspection procedures for electrical circuits.
D	ABBREVIATIONS	Defines the abbreviations used in this manual.
E	GLOSSARY OF TERMS AND SYMBOLS	Defines the symbols and functions of major parts.
F	RELAY LOCATIONS	Shows position of the Electronic Control Unit, Relays, Relay Block, etc. This section is closely related to the system circuit.
G	ELECTRICAL WIRING ROUTING	Describes position of Parts Connectors, Splice points, Ground points, etc. This section is closely related to the system circuit.
H	POWER SOURCE (Current Flow Chart)	Describes power distribution from the power supply to various electrical loads.
I	INDEX	Index of the system circuits.
	SYSTEM CIRCUITS	Electrical circuits of each system are shown from the power supply through ground points. Wiring connections and their positions are shown and classified by code according to the connection method. (Refer to the section, "How to use this manual"). The "System Outline" and "Service Hints" useful for troubleshooting are also contained in this section.
J	GROUND POINTS	Shows ground positions of all the parts described in this manual.
K	OVERALL ELECTRICAL WIRING DIAGRAM	Provides circuit diagrams showing the circuit connections.

This manual provides information on the electrical circuits installed on vehicles by dividing them into a circuit for each system.

The actual wiring of each system circuit is shown from the point where the power source is received from the battery as far as each ground point. (All circuit diagrams are shown with the switches in the OFF position.)

When troubleshooting any problem, first understand the operation of the circuit where the problem was detected (see System Circuit section), the power source supplying power to that circuit (see Power Source section), and the ground points (see Ground Points section). See the System Outline to understand the circuit operation.

When the circuit operation is understood, begin troubleshooting of the problem circuit to isolate the cause. Use Relay Location and Electrical Wiring Routing sections to find each part, junction block and wiring harness connectors, wiring harness and wiring harness connectors, splice points, and ground points of each system circuit. Internal wiring for each junction block is also provided for better understanding of connection within a junction block.


Wiring related to each system is indicated in each system circuit by arrows (from __, to __). When overall connections are required, see the Overall Electrical Wiring Diagram at the end of this manual.

B HOW TO USE THIS MANUAL

* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the SYSTEM CIRCUITS SECTION.



POWER WINDOW




- (A) : System Title
- (B) : Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B.

Example:  Indicates Relay Block No. 1.

- (C) : Indicates the connector to be connected to a part (the numeral indicates the pin No.)

Explanation of pin use.




The pins shown are only for the highest grade, or only include those in the specification.

- (D) : Connector Color
Connectors not indicated are milky white in color.
- (E) : () is used to indicate different wiring and connector, etc. when the vehicle model, engine type, or specification is different.

- (F) : Indicates related system.

- (G) : Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows (↗).

Outside numerals are pin numbers.




The first letter of the code for each wiring harness and wiring harness connector(s) indicates the component's location, e.g., "E" for the Engine Compartment, "I" for the Instrument Panel and Surrounding area, and "B" for the Body and Surrounding area.

When more than one code has the first and second letters in common, followed by numbers (e.g., IH1, IH2), this indicates the same type of wiring harness and wiring harness connector.

- (H) : Represents a part (all parts are shown in sky blue). The code is the same as the code used in parts position.

- (I) : Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it). Junction Blocks are shaded to clearly separate them from other parts (different junction blocks are shaded differently for further clarification).

Example:




- (J) : Indicates the wiring color.

Wire colors are indicated by an alphabetical code.

- B = Black L = Blue R = Red
- BR = Brown LG = Light Green V = Violet
- G = Green O = Orange W = White
- GR = Gray P = Pink Y = Yellow


The first letter indicates the basic wire color and the second letter indicates the color of the stripe.

Example: L - Y



- (K) : Indicates a wiring Splice Point (Codes are "E" for the Engine Room, "I" for the Instrument Panel, and "B" for the Body).


Example:



The Location of Splice Point I 5 is indicated by the shaded section.

- (L) : Page No.

- (M) : Indicates a shielded cable.




- (N) : Indicates a ground point.

The first letter of the code for each ground point(s) indicates the component's location, e.g., "E" for the Engine Compartment, "I" for the Instrument Panel and Surrounding area, and "B" for the Body and Surrounding area.

- (O) : Indicates the pin number of the connector.

The numbering system is different for female and male connectors.

Example: Numbered in order from upper left to lower right Numbered in order from upper right to lower left



- (P) : When 2 parts both use one connector in common, the parts connector name used in the wire routing section is shown in square brackets [].

B HOW TO USE THIS MANUAL



SYSTEM OUTLINE

WITH THE IGNITION SW TURNED ON, THE CURRENT FLOWS TO **TERMINAL 3** OF THE POWER WINDOW MASTER SW, **TERMINAL 2** OF THE POWER WINDOW CONTROL RELAY AND **TERMINAL 8** OF THE POWER WINDOW SW THROUGH THE DOOR FUSE.

1. DRIVER'S WINDOW "MANUAL UP" OPERATION BY MASTER SW

HOLDING MANUAL SW (DRIVER'S) ON "UP" POSITION LOCATED IN POWER WINDOW MASTER SW, THE CURRENT FLOWS TO **TERMINAL 5** OF THE POWER WINDOW CONTROL RELAY THROUGH **TERMINAL 3** OF THE MASTER SW → **TERMINAL 2** TO OPERATE A POWER WINDOW CONTROL RELAY. THUS THE CURRENT INSIDE THE RELAY FLOWS FROM **TERMINAL 2** OF THE RELAY → **TERMINAL 1** → **TERMINAL 2** OF THE POWER WINDOW MOTOR → **TERMINAL 1** → **TERMINAL 4** OF THE RELAY → **TERMINAL 3** → TO GROUND. THE MOTOR TURNS TO ASCENT THE WINDOW. RELEASING THIS SW, THE ROTATION OF MOTOR IS STOPPED AND THE WINDOWS CAN STOP AT WILL POINT.

(FOR THE "MANUAL DOWN" OPERATION, CURRENT FLOWS IN THE REVERSE DIRECTION BECAUSE THE TERMINALS WHERE IT FLOW ARE CHANGED).

2. DRIVER'S WINDOW "AUTO DOWN" OPERATION BY MASTER SW

ONCE THE "AUTO DOWN" BUTTON OF THE MASTER SW IS PUSHED, THE CURRENT FLOW **TERMINAL 9** OF THE POWER WINDOW CONTROL RELAY THROUGH **TERMINAL 3** OF THE MASTER SW → **TERMINALS 8 AND 9** TO OPERATE THE RELAY. THUS THE CURRENT INSIDE THE POWER WINDOW CONTROL RELAY FLOWS FROM **TERMINAL 2** OF THE RELAY → **TERMINAL 4** → **TERMINAL 1** OF THE POWER WINDOW MOTOR → **TERMINAL 2** → **TERMINAL 1** OF THE RELAY → **TERMINAL 3** → TO GROUND. THE MOTOR CONTINUES THE ROTATION ENABLING TO DESCENT THE WINDOW.

THE WINDOW DESCENDS TO THE END POSITION. THE CURRENT WILL BE CUT OFF TO RELEASE THE AUTO DOWN FUNCTION BASED ON THE INCREASING CURRENT BETWEEN **TERMINAL 2** OF THE RELAY AND **TERMINAL 1** IN RELAY.

3. DRIVER'S WINDOW AUTO DOWN RELEASE OPERATION BY MASTER SW

HOLDING THE MANUAL SW (DRIVER'S) ON "UP" POSITION IN OPERATING AUTO DOWN. THE CURRENT FROM **TERMINAL 3** OF THE MASTER SW PASSING **TERMINAL 2** FLOWS **TERMINAL 5** OF THE RELAY AND RELEASES THE AUTO DOWN FUNCTION IN THE POWER WINDOW CONTROL RELAY. RELEASING THE HAND FROM SW, WINDOW STOPS AND CONTINUING ON TOUCHING SW, THE FUNCTION SWITCHES TO MANUAL UP OPERATION.

4. PASSENGER'S WINDOW UP OPERATION (MASTER SW) AND WINDOW LOCK SW OPERATION

HOLDING PASSENGER'S WINDOW SW (MASTER SW) ON "UP", THE CURRENT FLOWS FROM **TERMINAL 3** OF THE MASTER SW PASSING **TERMINAL 6** TO **TERMINAL 3** OF THE POWER WINDOW SW (PASSENGER'S) → **TERMINAL 4** → **TERMINAL 2** OF THE MOTOR → **TERMINAL 1** → **TERMINAL 9** OF THE POWER WINDOW SW → **TERMINAL 7** → **TERMINAL 1** OF THE MASTER SW → **TERMINAL 4** TO GROUND. THE MOTOR RUNS TO ASCENT THE WINDOW. RELEASING THIS SW, THE ROTATION OF MOTOR IS STOPPED AND WINDOW CAN STOP AT WILL PLACE.

SWITCHING THE WINDOW LOCK SW IN "LOCK" POSITION, THE CIRCUIT IS OPENED AND STOPPED THE MOTOR ROTATION.

(FOR THE DOWN OPERATION, CURRENT FLOWS IN THE REVERSE DIRECTION BECAUSE THE TERMINALS WHERE IT FLOWS ARE CHANGED).



SERVICE HINTS

P 2 POWER WINDOW CONTROL RELAY

3-GROUND: ALWAYS CONTINUITY

2-GROUND: APPROX. 12 VOLTS WITH THE IGNITION SW AT ON POSITION

5-GROUND: APPROX. 12 VOLTS WITH THE IGNITION SW AT ON POSITION AND THE MASTER SW AT UP POSITION

8-GROUND: APPROX. 12 VOLTS WITH THE IGNITION SW AT ON POSITION AND THE MASTER SW AT AUTO DOWN POSITION

9-GROUND: APPROX. 12 VOLTS WITH THE IGNITION SW AT ON POSITION AND THE MASTER SW AT DOWN OR AUTO DOWN POSITION

P 4 POWER WINDOW MASTER SW

4-GROUND: ALWAYS CONTINUITY

3-GROUND: APPROX. 12 VOLTS WITH THE IGNITION SW AT ON POSITION

WINDOW LOCK SW

OPEN WITH THE WINDOW LOCK SW AT LOCK POSITION



○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
P 2	21	P 4	21	P 6	21
P 3	21	P 5	21		



○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCK (RELAY BLOCK LOCATION)
1	16	R/B NO. 1 (INSTRUMENT PANEL LEFT)



○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
3B	14	J/B NO. 3 AND COWL WIRE (INSTRUMENT PANEL LEFT SIDE)



□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
ID1	26	FRONT DOOR RH WIRE AND COWL WIRE (RIGHT KICK PANEL)
IH1	26	FRONT DOOR LH WIRE AND COWL WIRE (LEFT KICK PANEL)




▽ : GROUND POINTS


CODE	SEE PAGE	GROUND POINT LOCATION
IC	24	COWL LEFT



○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I 5	24	COWL WIRE			

- Ⓚ : Explains the system outline.
- Ⓡ : Indicates values or explains the function for reference during troubleshooting.
- Ⓢ : Indicates the reference page showing the position on the vehicle of the parts in the system circuit.
 Example: Part “P 4” (Power Window Master SW) is on page 21 of the manual.
 * The letter in the code is from the first letter of the part, and the number indicates its order in parts starting with the letter.
 Example: P 4

- Ⓣ : Indicates the reference page showing the position on the vehicle of Relay Block Connectors in the system circuit.
 Example: Connector “1” is described on page 16 of this manual and is installed on the left side of the instrument panel.
- Ⓤ : Indicates the reference page showing the position on the vehicle of J/B and Wire Harness in the system circuit.
 Example: Connector “3B” connects the Cowl Wire and J/B No. 3. It is described on page 14 of this manual, and is installed on the instrument panel left side.
- Ⓥ : Indicates the reference page describing the wiring harness and wiring harness connector (the female wiring harness is shown first, followed by the male wiring harness).
 Example: Connector “ID1” connects the front door RH wire (female) and cowl wire (male). It is described on page 26 of this manual, and is installed on the right side kick panel.
- Ⓦ : Indicates the reference page showing the position of the ground points on the vehicle.
 Example: Ground point “IC” is described on page 24 of this manual and is installed on the cowl left side.
- Ⓧ : Indicates the reference page showing the position of the splice points on the vehicle.
 Example: Splice point “I 5” is on the Cowl Wire Harness and is described on page 24 of this manual.

HINT:

Junction connector (code: J1, J2, J3, J4, J5, J6, J7, J8, J9) in this manual include a short terminal which is connected to a number of wire harnesses. Always perform inspection with the short terminal installed. (When installing the wire harnesses, the harnesses can be connected to any position within the short terminal grouping. Accordingly, in other vehicles, the same position in the short terminal may be connected to a wire harness from a different part.)

Wire harness sharing the same short terminal grouping have the same color.


B HOW TO USE THIS MANUAL

The "Current Flow Chart" section, describes which parts each power source (fuses, fusible links, and circuit breakers) transmits current to. In the Power Source circuit diagram, the conditions when battery power is supplied to each system are explained. Since all System Circuit diagrams start from the power source, the power source system must be fully understood.

H POWER SOURCE (Current Flow Chart)

The chart below shows the route by which current flows from the battery to each electrical source (Fusible Link, Circuit Breaker, Fuse, etc.) and other parts.


The next page and following pages show the parts to which each electrical source outputs current.



Location	Page Nos. of Related Systems	Parts	Code or Location	CB or Fuse																					
				A 2	A 3	A 4	A 6	A 8	A 9	A 10	A 11	A 12	A 13	A 14	A 16	A 17	A 19	A 20	B 1	B 2	B 3	C 4	C 5	C 6	C 7
15A	ECU-B																								
10A	GAUGE																								
10A	TURN																								
15A	ECU-IG																								




POWER SOURCE



* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the SYSTEM CIRCUITS SECTION.


The ground points circuit diagram shows the connections from all major parts to the respective ground points. When troubleshooting a faulty ground point, checking the system circuits which use a common ground may help you identify the problem ground quickly. The relationship between ground points (EA, IB, and IC shown below) can also be checked this way.

J GROUND POINT



* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the SYSTEM CIRCUITS SECTION.

C TROUBLESHOOTING




VOLTAGE CHECK

- (a) Establish conditions in which voltage is present at the check point.


Example:

- Ⓐ - Ignition SW on
 - Ⓑ - Ignition SW and SW 1 on
 - Ⓒ - Ignition SW, SW 1 and Relay on (SW2 off)
- (b) Using a voltmeter, connect the negative lead to a good ground point or negative battery terminal, and the positive lead to the connector or component terminal. This check can be done with a test light instead of a voltmeter.



CONTINUITY AND RESISTANCE CHECK


- (a) Disconnect the battery terminal or wire so there is no voltage between the check points.
- (b) Contact the two leads of an ohmmeter to each of the check points.




If the circuit has diodes, reverse the two leads and check again.

When contacting the negative lead to the diode positive side and the positive lead to the negative side, there should be continuity.

When contacting the two leads in reverse, there should be no continuity.



- (c) Use the volt/ohmmeter with high impedance (10 kΩ/V minimum) for troubleshooting of the electrical circuit.



FINDING A SHORT CIRCUIT

- Remove the blown fuse and disconnect all loads of the fuse.
- Connect a test light in place of the fuse.
- Establish conditions in which the test light comes on.

Example:

- Ⓐ - Ignition SW on
 - Ⓑ - Ignition SW and SW 1 on
 - Ⓒ - Ignition SW, SW 1 and Relay on (Connect the Relay) and SW 2 off (or Disconnect SW 2)
- Disconnect and reconnect the connectors while watching the test light. The short lies between the connector where the test light stays lit and the connector where the light goes out.
 - Find the exact location of the short by lightly shaking the problem wire along the body.


CAUTION:

- Do not open the cover or the case of the ECU unless absolutely necessary. (If the IC terminals are touched, the IC may be destroyed by static electricity.)**
- When replacing the internal mechanism (ECU part) of the digital meter, be careful that no part of your body or clothing comes in contact with the terminals of leads from the IC, etc. of the replacement part (spare part).**


DISCONNECTION OF MALE AND FEMALE CONNECTORS

To pull apart the connectors, pull on the connector itself, not the wire harness.

HINT: Check to see what kind of connector you are disconnecting before pulling apart.



C TROUBLESHOOTING





HOW TO REPLACE TERMINAL (with terminal retainer or secondary locking device)


1. PREPARE THE SPECIAL TOOL
HINT: To remove the terminal from the connector, please construct and use the special tool or like object shown on the left.
2. DISCONNECT CONNECTOR
3. DISENGAGE THE SECONDARY LOCKING DEVICE OR TERMINAL RETAINER
 - (a) Locking device must be disengaged before the terminal locking clip can be released and the terminal removed from the connector.
 - (b) Use a special tool or the terminal pick to unlock the secondary locking device or terminal retainer.

NOTICE:





Do not remove the terminal retainer from connector body.



- Ⓐ For Non-Waterproof Type Connector
HINT: The needle insertion position varies according to the connector's shape (number of terminals etc.), so check the position before inserting it.
- "Case 1"
Raise the terminal retainer up to the temporary lock position.



- "Case 2"
Open the secondary locking device.



- ② For Waterproof Type Connector
- HINT: Terminal retainer color is different according to connector body.
- Example:
- | | |
|--------------------|----------------|
| Terminal Retainer: | Connector Body |
| Black or White | : Gray |
| Black or White | : Dark Gray |
| Gray or White | : Black |

“Case 1”


Type where terminal retainer is pulled up to the temporary lock position (Pull Type). Insert the special tool into the terminal retainer access hole (▲ Mark) and pull the terminal retainer up to the temporary lock position.

HINT: The needle insertion position varies according to the connector's shape (number of terminals, etc.), so check the position before inserting it.


“Case 2”

Type which cannot be pulled as far as Power Lock insert the tool straight into the access hole of terminal retainer as shown.


C TROUBLESHOOTING



Push the terminal retainer down to the temporary lock position.



(c) Release the locking lug from terminal and pull the terminal out from rear.




4. INSTALL TERMINAL TO CONNECTOR

(a) Insert the terminal.

HINT:

1. Make sure the terminal is positioned correctly.
2. Insert the terminal until the locking lug locks firmly.
3. Insert the terminal with terminal retainer in the temporary lock position.



(b) Push the secondary locking device or terminal retainer into the full lock position.

5. CONNECT CONNECTOR






















ABBREVIATIONS


















The following abbreviations are used in this manual.

ABS	= Anti-Lock Brake System
A/C	= Air Conditioning
A/T	= Automatic Transaxle
COMB.	= Combination
C/P	= Coupe Type
ECU	= Electronic Control Unit
EGR	= Exhaust Gas Recirculation
ESA	= Electronic Spark Advance
FL	= Fusible Link
IC	= Integrated Circuit
J/B	= Junction Block
L/B	= Liftback Type
LH	= Left-Hand
M/T	= Manual Transaxle
O/D	= Overdrive
R/B	= Relay Block
RH	= Right-Hand
SFI	= Sequential Multiport Fuel Injection
SRS	= Supplemental Restraint System
SW	= Switch
TEMP.	= Temperature
VSV	= Vacuum Switching Valve
W/	= With
W/O	= Without

* The titles given inside the components are the names of the terminals (terminal codes) and are not treated as being abbreviations.


E GLOSSARY OF TERMS AND SYMBOLS

 <p>BATTERY Stores chemical energy and converts it into electrical energy. Provides DC current for the auto's various electrical circuits.</p>	<p>GROUND The point at which wiring attaches to the Body, thereby providing a return path for an electrical circuit; without a ground, current cannot flow.</p> 
 <p>CAPACITOR (Condenser) A small holding unit for temporary storage of electrical voltage.</p>	<p>HEADLIGHTS Current flow causes a headlight filament to heat up and emit light. A headlight may have either a single (1) filament or a double (2) filament.</p> <p>1. SINGLE FILAMENT</p>  <p>2. DOUBLE FILAMENT</p> 
 <p>CIGARETTE LIGHTER An electric resistance heating element.</p>	
 <p>CIRCUIT BREAKER Basically a reusable fuse, a circuit breaker will heat and open if too much current flows through it. Some units automatically reset when cool, others must be manually reset.</p>	<p>HORN An electric device which sounds a loud audible signal.</p> 
 <p>DIODE A semiconductor which allows current flow in only one direction.</p>	<p>IGNITION COIL Convert low-voltage DC current into high-voltage ignition current for firing the spark plugs.</p> 
 <p>DIODE, ZENER A diode which allows current flow in one direction but blocks reverse flow only up to a specific voltage. Above that potential, it passes the excess voltage. This acts as a simple voltage regulator.</p>	<p>LIGHT Current flow through a filament causes the filament to heat up and emit light.</p> 
 <p>PHOTODIODE The photodiode is a semiconductor which controls the current flow according to the amount of light.</p>	<p>LED (LIGHT EMITTING DIODE) Upon current flow, these diodes emit light without producing the heat of a comparable light.</p> 
 <p>DISTRIBUTOR, IIA Channels high-voltage current from the ignition coil to the individual spark plugs.</p>	<p>METER, ANALOG Current flow activates a magnetic coil which causes a needle to move, thereby providing a relative display against a background calibration.</p> 
 <p>FUSE A thin metal strip which burns through when too much current flows through it, thereby stopping current flow and protecting a circuit from damage.</p>  <p>FUSIBLE LINK A heavy-gauge wire placed in high amperage circuits which burns through on overloads, thereby protecting the circuit. The numbers indicate the cross-section surface area of the wires.</p> <p>(for Medium Current Fuse)</p>  <p>(for High Current Fuse or Fusible Link.)</p>	<p>METER, DIGITAL Current flow activates one or many LED's, LCD's, or fluorescent displays, which provide a relative or digital display.</p> 
	<p>MOTOR A power unit which converts electrical energy into mechanical energy, especially rotary motion.</p> 


 <p>RELAY 1. NORMALLY CLOSED 2. NORMALLY OPEN</p>	 <p>SPEAKER An electromechanical device which creates sound waves from current flow.</p>
 <p>RELAY, DOUBLE THROW A relay which passes current through one set of contacts or the other.</p>	<p>SWITCH, MANUAL</p>  <p>1. NORMALLY OPEN 2. NORMALLY CLOSED</p> <p>Opens and closes circuits, thereby stopping (1) or allowing (2) current flow.</p>
 <p>RESISTOR An electrical component with a fixed resistance, placed in a circuit to reduce voltage to a specific value.</p>	<p>SWITCH, DOUBLE THROW A switch which continuously passes current through one set of contacts or the other.</p> 
 <p>RESISTOR, TAPPED A resistor which supplies two or more different non adjustable resistance values.</p>	<p>SWITCH, IGNITION A key operated switch with several positions which allows various circuits, particularly the primary ignition circuit, to become operational.</p> 
 <p>RESISTOR, VARIABLE OR RHEOSTAT A controllable resistor with a variable rate of resistance. Also called a potentiometer or rheostat.</p>	<p>SWITCH, WIPER PARK Automatically returns wipers to the stop position when the wiper switch is turned off.</p> 
 <p>SENSOR (Thermistor) A resistor which varies its resistance with temperature.</p>	<p>TRANSISTOR A solid state device typically used as an electronic relay; stops or passes current depending on the voltage applied at "base."</p> 
 <p>SENSOR, SPEED Uses magnetic impulses to open and close a switch to create a signal for activation of other components. <small>(Reed Switch Type)</small></p>	<p>WIRES</p> <p>(1) NOT CONNECTED Wires are always drawn as straight lines on wiring diagrams. Crossed wires (1) without a black dot at the junction are not joined; crossed wires (2) with a black dot or octagonal (O) mark at the junction as spliced (joined) connections.</p> 
 <p>SHORT PIN Used to provide an unbroken connection within a junction block.</p>	<p>(2) SPLICED</p> 
 <p>SOLENOID An electromagnetic coil which forms a magnetic field when current flows, to move a plunger, etc.</p>	

F RELAY LOCATIONS


[Engine Compartment]




[Instrument Panel]




[Body]
[L/B]



[Body]
[C/P]





[Body]
[Convertible]




F RELAY LOCATIONS

○ : Inpane J/B Left Kick Panel (See Page 18)





[Inpane J/B Inner Circuit]




F RELAY LOCATIONS

○ : J/B No. 1 Left Kick Panel (See Page 18)




[J/B No. 1 Inner Circuit]




F RELAY LOCATIONS


○ : J/B No. 3 Behind the Instrument Panel Center (See Page 18)




[J/B No. 3 Inner Circuit]



① : R/B No. 1 | Left Kick Panel (See Page 18)




④ : R/B No. 1 | Right Kick Panel (See Page 18)




F RELAY LOCATIONS

② : R/B No. 2	Engine Compartment Left (See Page 18)
○ : J/B No. 2	


- *1: 100A ALT Fuse (for High Current)
- *2: 60A MAIN Fuse (for High Current)
- *3: 50A ABS Fuse (for High Current)
- *4: 15A HEAD (LH) (USA)
15A HEAD LO (LH) (Canada)
- *5: 15A HEAD (RH) (USA)
15A HEAD LO (RH) (Canada)



⑤ : R/B No. 5 Engine Compartment Front Right (See Page 18)




⑥ : R/B No. 6 Engine Compartment Front Left (See Page 18)



G ELECTRICAL WIRING ROUTING

Position of Parts in Engine Compartment

[5S-FE]



- A 1 A/C Condenser Fan Motor
- A 2 A/C Magnetic Clutch and Lock Sensor
- A 3 A/C Triple Pressure SW (A/C Dual and Single Pressure SW)
- A 4 ABS Actuator
- A 5 ABS Actuator
- A 6 ABS Speed Sensor Front LH
- A 7 ABS Speed Sensor Front RH

- B 1 Back-Up Light SW
- B 2 Brake Fluid Level Warning SW

- C 1 Cruise Control Actuator
- C 16 Crankshaft Position Sensor

- D 1 Data Link Connector 1
- D 2 Distributor

- E 2 Electronically Controlled Transmission Solenoid
- E 3 Electronically Controlled Transmission Solenoid
- E 4 Engine Coolant Temp. Sensor


- F 1 Front Airbag Sensor LH
- F 2 Front Airbag Sensor RH
- F 3 Front Side Marker Light LH
- F 4 Front Side Marker Light RH
- F 5 Front Turn Signal Light and Parking Light LH
- F 6 Front Turn Signal Light and Parking Light RH
- F 7 Front Wiper Motor
- F 11 Front Fog Light LH
- F 12 Front Fog Light RH

- G 1 Generator
- G 2 Generator

- H 1 Headlight Hi LH
- H 2 Headlight Hi RH
- H 3 Headlight Lo LH
- H 4 Headlight Lo RH
- H 5 Horn LH
- H 6 Horn RH

Position of Parts in Engine Compartment

[5S-FE]




- | | | | |
|------|-----------------------------------|-----|--|
| I 1 | Idle Air Control Valve | P 1 | Park/Neutral Position SW |
| I 2 | Igniter | R 1 | Radiator Fan Motor |
| I 3 | Ignition Coil | S 1 | Starter |
| I 6 | Injector No. 1 | S 2 | Starter |
| I 7 | Injector No. 2 | T 1 | Throttle Position Sensor |
| I 8 | Injector No. 3 | V 1 | Vehicle Speed Sensor (Combination Meter) |
| I 9 | Injector No. 4 | V 3 | VSV (EGR) |
| I 10 | Intake Air Temp. Sensor | W 1 | Washer Motor |
| K 1 | Knock Sensor | W 2 | Water Temp. Sender |
| M 1 | Manifold Absolute Pressure Sensor | W 3 | Water Temp. SW (Radiator Fan) |
| N 1 | Noise Filter (Ignition System) | | |
| O 1 | Oil Pressure SW | | |
| O 2 | Oxygen Sensor (Bank 1 Sensor 1) | | |
| O 3 | Oxygen Sensor (Bank 1 Sensor 2) | | |

G ELECTRICAL WIRING ROUTING

Position of Parts in Engine Compartment

[7A-FE]



- A 1 A/C Condenser Fan Motor
- A 2 A/C Magnetic Clutch
- A 3 A/C Triple Pressure SW (A/C Dual and Single Pressure SW)
- A 4 ABS Actuator
- A 5 ABS Actuator
- A 6 ABS Speed Sensor Front LH
- A 7 ABS Speed Sensor Front RH

- B 1 Back-Up Light SW
- B 2 Brake Fluid Level Warning SW

- C 1 Cruise Control Actuator
- C 16 Crankshaft Position Sensor

- D 1 Data Link Connector 1
- D 2 Distributor

- E 2 Electronically Controlled Transmission Solenoid
- E 4 Engine Coolant Temp. Sensor


- F 1 Front Airbag Sensor LH
- F 2 Front Airbag Sensor RH
- F 3 Front Side Marker Light LH
- F 4 Front Side Marker Light RH
- F 5 Front Turn Signal Light and Parking Light LH
- F 6 Front Turn Signal Light and Parking Light RH
- F 7 Front Wiper Motor
- F 11 Front Fog Light LH
- F 12 Front Fog Light RH

- G 1 Generator
- G 2 Generator

- H 1 Headlight Hi LH
- H 2 Headlight Hi RH
- H 3 Headlight Lo LH
- H 4 Headlight Lo RH
- H 5 Horn LH
- H 6 Horn RH
- H 10 Oxygen Sensor (Bank 1 Sensor 1)

Position of Parts in Engine Compartment


[7A-FE]



I 1	Idle Air Control Valve	R 1	Radiator Fan Motor
I 2	Igniter	S 1	Starter
I 6	Injector No. 1	S 2	Starter
I 7	Injector No. 2	T 1	Throttle Position Sensor
I 8	Injector No. 3	V 1	Vehicle Speed Sensor (Combination Meter)
I 9	Injector No. 4	V 3	VSV (EGR)
I 10	Intake Air Temp. Sensor	W 1	Washer Motor
K 1	Knock Sensor	W 2	Water Temp. Sender
M 1	Manifold Absolute Pressure Sensor	W 3	Water Temp. SW (Radiator Fan)
O 1	Oil Pressure SW		
P 1	Park/Neutral Position SW		

G ELECTRICAL WIRING ROUTING

Position of Parts in Instrument Panel



- A 8 A/C Amplifier
- A 9 A/C Thermistor
- A 10 ABS ECU
- A 11 ABS ECU
- A 12 Air Inlet Control Servo Motor
- A 13 Air Vent Mode Control Servo Motor
- A 14 Airbag Squib (Steering Wheel Pad)
- A 15 Airbag Squib (Front Passenger Airbag Assembly)
- A 16 Ashtray Illumination

- B 3 Blower Motor
- B 4 Blower Resistor
- B 5 Blower SW

- C 2 Center Airbag Sensor Assembly
- C 3 Cigarette Lighter
- C 4 Cigarette Lighter Illumination
- C 5 Circuit Opening Relay
- C 6 Clock
- C 7 Clutch Start SW
- C 8 Combination Meter

- C 9 Combination Meter
- C 10 Combination Meter
- C 11 Combination SW
- C 12 Combination SW
- C 13 Combination SW
- C 14 Cruise Control Clutch SW
- C 15 Cruise Control ECU

- D 3 Daytime Running Light Relay (Main)
- D 4 Diode (Door Courtesy Light)
- D 5 Diode (Key Off Operation)
- D 6 Diode (Luggage Compartment Light)
- D 7 Door Lock Control Relay
- D 15 Data Link Connector 3

- E 5 Engine Control Module
- E 6 Engine Control Module
- E 7 Engine Control Module


- G 3 Glove Box Light
- G 4 Glove Box Light SW

Position of Parts in Instrument Panel

*1: Separate Type Amplifier

*2: Built-in Type Amplifier

*3: 7A-FE



H 7 Hazard SW
 H 8 Heater Control SW
 H 11 Heated Oxygen Sensor (Bank 1 Sensor 2)

I 11 Ignition Key Cylinder Light
 I 12 Ignition SW
 I 13 Integration Relay

J 1 Junction Connector (Earth)
 J 2 Junction Connector
 J 3 Junction Connector
 J 4 Junction Connector
 J 5 Junction Connector
 J 6 Junction Connector
 J 7 Junction Connector
 J 8 Junction Connector
 J 9 Junction Connector (Earth)

K 2 Key Interlock Solenoid

O 6 O/D Main SW

P 2 Parking Brake SW

Q 1 Quarter Power Window SW LH (Convertible)
 Q 2 Quarter Power Window SW RH (Convertible)

R 2 Radio and Player
 R 3 Radio and Player
 R 4 Rear Window Defogger SW
 R 5 Remote Control Mirror SW (w/o Power Window)
 R 6 Rheostat

S 3 Shift Lock ECU
 S 4 Stereo Component Amplifier
 S 5 Stereo Component Amplifier
 S 6 Stereo Component Amplifier
 S 7 Stop Light SW

T 2 Top Stack Control SW (Convertible)
 T 3 Top Stack Main Relay (Convertible)


U 1 Unlock Warning SW

W 4 Woofer Speaker Amplifier
 W 5 Woofer Speaker Amplifier

G ELECTRICAL WIRING ROUTING

Position of Parts in Body


[L/B]



- | | | | |
|------|--|------|--|
| A 17 | ABS Speed Sensor Rear LH | M 4 | Moon Roof Limit SW |
| A 18 | ABS Speed Sensor Rear RH | M 5 | Moon Roof Motor |
| A 19 | Auto Antenna Motor and Relay | P 3 | Personal Light (w/o Moon Roof) |
| B 6 | Buckle SW LH | P 6 | Power Window Control SW (Passenger's Side) |
| B 7 | Buckle SW RH | P 7 | Power Window Master SW |
| D 8 | Door Courtesy Light LH | P 8 | Power Window Motor LH |
| D 9 | Door Courtesy Light RH | P 9 | Power Window Motor RH |
| D 10 | Door Courtesy SW LH | R 7 | Rear Combination Light LH |
| D 11 | Door Courtesy SW RH | R 8 | Rear Combination Light RH |
| D 12 | Door Lock Control SW (Passenger's Side) | R 9 | Rear Speaker LH |
| D 13 | Door Lock Motor, Door Unlock Detection SW and Door Key Lock and Unlock SW LH | R 10 | Rear Speaker RH |
| D 14 | Door Lock Motor, Door Unlock Detection SW and Door Key Lock and Unlock SW RH | R 11 | Rear Window Defogger (+) |
| F 8 | Front Door Speaker LH | R 12 | Rear Window Defogger (-) |
| F 9 | Front Door Speaker RH | R 13 | Rear Wiper Motor and Relay |
| F 10 | Fuel Sender and Pump | R 14 | Remote Control Mirror LH |
| H 9 | High Mounted Stop Light | R 15 | Remote Control Mirror RH |
| L 1 | License Plate Light | R 16 | Remote Control Mirror SW (w/ Power Window) |
| L 2 | Luggage Compartment Light | T 4 | Tension Reducer Solenoid LH |
| L 3 | Luggage Compartment Light SW | T 5 | Tension Reducer Solenoid RH |
| M 2 | Moon Roof Control Relay | T 10 | Tweeter Speaker LH |
| M 3 | Moon Roof Control SW and Personal Light (w/ Moon Roof) | T 11 | Tweeter Speaker RH |
| | | W 6 | Woofer Speaker LH |
| | | W 7 | Woofer Speaker RH |

Position of Parts in Body

[C/P]




- | | | | |
|------|--|------|--|
| A 17 | ABS Speed Sensor Rear LH | M 4 | Moon Roof Limit SW |
| A 18 | ABS Speed Sensor Rear RH | M 5 | Moon Roof Motor |
| A 19 | Auto Antenna Motor and Relay | P 3 | Personal Light (w/o Moon Roof) |
| B 6 | Buckle SW LH | P 6 | Power Window Control SW (Passenger's Side) |
| B 7 | Buckle SW RH | P 7 | Power Window Master SW |
| D 8 | Door Courtesy Light LH | P 8 | Power Window Motor LH |
| D 9 | Door Courtesy Light RH | P 9 | Power Window Motor RH |
| D 10 | Door Courtesy SW LH | R 7 | Rear Combination Light LH |
| D 11 | Door Courtesy SW RH | R 8 | Rear Combination Light RH |
| D 12 | Door Lock Control SW (Passenger's Side) | R 9 | Rear Speaker LH |
| D 13 | Door Lock Motor, Door Unlock Detection SW and Door Key Lock and Unlock SW LH | R 10 | Rear Speaker RH |
| D 14 | Door Lock Motor, Door Unlock Detection SW and Door Key Lock and Unlock SW RH | R 11 | Rear Window Defogger (+) |
| F 8 | Front Door Speaker LH | R 12 | Rear Window Defogger (-) |
| F 9 | Front Door Speaker RH | R 14 | Remote Control Mirror LH |
| F 10 | Fuel Sender and Pump | R 15 | Remote Control Mirror RH |
| H 9 | High Mounted Stop Light | R 16 | Remote Control Mirror SW (w/ Power Window) |
| L 1 | License Plate Light | T 4 | Tension Reducer Solenoid LH |
| L 2 | Luggage Compartment Light | T 5 | Tension Reducer Solenoid RH |
| L 3 | Luggage Compartment Light SW | T 10 | Tweeter Speaker LH |
| M 2 | Moon Roof Control Relay | T 11 | Tweeter Speaker RH |
| M 3 | Moon Roof Control SW and Personal Light (w/ Moon Roof) | W 6 | Woofer Speaker LH |
| | | W 7 | Woofer Speaker RH |

G ELECTRICAL WIRING ROUTING

Position of Parts in Body

[Convertible]



A 17 ABS Speed Sensor Rear LH
 A 18 ABS Speed Sensor Rear RH
 A 19 Auto Antenna Motor and Relay

B 6 Buckle SW LH
 B 7 Buckle SW RH

D 8 Door Courtesy Light LH
 D 9 Door Courtesy Light RH
 D 10 Door Courtesy SW LH
 D 11 Door Courtesy SW RH
 D 12 Door Lock Control SW (Passenger's Side)
 D 13 Door Lock Motor, Door Unlock Detection SW
 and Door Key Lock and Unlock SW LH
 D 14 Door Lock Motor, Door Unlock Detection SW
 and Door Key Lock and Unlock SW RH

F 8 Front Door Speaker LH
 F 9 Front Door Speaker RH

F 10 Fuel Sender and Pump


H 9 High Mounted Stop Light

L 1 License Plate Light
 L 2 Luggage Compartment Light
 L 3 Luggage Compartment Light SW

P 4 Personal Light LH
 P 5 Personal Light RH
 P 6 Power Window Control SW (Passenger's Side)
 P 7 Power Window Master SW
 P 8 Power Window Motor LH
 P 9 Power Window Motor RH
 P 10 Personal Light LH
 P 11 Personal Light RH

Position of Parts in Body

[Convertible]




- | | |
|------|--|
| Q 3 | Quarter Power Window Motor LH |
| Q 4 | Quarter Power Window Motor RH |
| | |
| R 7 | Rear Combination Light LH |
| R 8 | Rear Combination Light RH |
| R 9 | Rear Speaker LH |
| R 10 | Rear Speaker RH |
| R 11 | Rear Window Defogger (+) |
| R 12 | Rear Window Defogger (-) |
| R 14 | Remote Control Mirror LH |
| R 15 | Remote Control Mirror RH |
| R 16 | Remote Control Mirror SW (w/ Power Window) |

- | | |
|------|-----------------------------|
| T 4 | Tension Reducer Solenoid LH |
| T 5 | Tension Reducer Solenoid RH |
| T 6 | Top Stack Bypass SW |
| T 7 | Top Stack Motor LH |
| T 8 | Top Stack Motor RH |
| T 9 | Top Stack Relay |
| T 10 | Tweeter Speaker LH |
| T 11 | Tweeter Speaker RH |
| | |
| W 6 | Woofer Speaker LH |
| W 7 | Woofer Speaker RH |


G ELECTRICAL WIRING ROUTING

- : Location of Connector Joining Wire Harness and Wire Harness
- ▽ : Location of Ground Points


[5S-FE]



- : Location of Splice Points



Connector Joining Wire Harness and Wire Harness




CODE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (INSIDE OF R/B NO.2)

G ELECTRICAL WIRING ROUTING


□ : Location of Connector Joining Wire Harness and Wire Harness

▽ : Location of Ground Points


[7A-FE]



○ : Location of Splice Points




Connector Joining Wire Harness and Wire Harness




CODE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (INSIDE OF R/B NO.2)
EB1	ENGINE ROOM NO.2 WIRE AND ENGINE WIRE (NEAR THE STARTER)

G ELECTRICAL WIRING ROUTING


□ : Location of Connector Joining Wire Harness and Wire Harness



▽ : Location of Ground Points




Connector Joining Wire Harness and Wire Harness




CODE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IC1	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IC2	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IC3	ENGINE ROOM MAIN WIRE AND COWL WIRE (INSIDE OF R/B NO.4)
IC4	ENGINE ROOM MAIN WIRE AND COWL WIRE (INSIDE OF R/B NO.4)
ID1	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)
ID2	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)
IE1	FRONT DOOR LH WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IE2	FRONT DOOR LH WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IF1	COWL WIRE AND FLOOR WIRE (LEFT KICK PANEL)
IG1	INSTRUMENT PANEL WIRE AND FLOOR WIRE (LEFT KICK PANEL)
IH1	FLOOR WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)

G ELECTRICAL WIRING ROUTING


□ : Location of Connector Joining Wire Harness and Wire Harness



○ : Location of Splice Points



Connector Joining Wire Harness and Wire Harness




CODE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
II1	ENGINE WIRE AND INSTRUMENT PANEL WIRE (NEAR THE ENGINE CONTROL MODULE)
II2	ENGINE WIRE AND INSTRUMENT PANEL WIRE (NEAR THE ENGINE CONTROL MODULE)
IJ1	ENGINE WIRE AND COWL WIRE (INSTRUMENT PANEL CENTER)
IK1	INSTRUMENT PANEL WIRE AND FLOOR NO.3 WIRE (BEHIND THE RADIO AND PLAYER)
IK2	
IK3	
IL1	COWL WIRE AND A/C SUB WIRE (UPPER THE A/C UNIT)
IM1	ENGINE WIRE AND A/C SUB WIRE (NEAR THE BLOWER MOTOR)
IN1	FRONT DOOR RH WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)
IN2	


G ELECTRICAL WIRING ROUTING

- : Location of Connector Joining Wire Harness and Wire Harness
- ▽ : Location of Ground Points


[L/B]



- : Location of Splice Points



Connector Joining Wire Harness and Wire Harness




CODE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
BO1	BACK DOOR NO.1 WIRE AND FLOOR WIRE (BACK DOOR UPPER LEFT)
BP1	BACK DOOR NO.2 WIRE AND BACK DOOR NO.1 WIRE (BACK DOOR UPPER LEFT)
BQ1	FLOOR WIRE AND LUGGAGE ROOM WIRE (LUGGAGE ROOM LEFT)
BQ2	FLOOR WIRE AND LUGGAGE ROOM WIRE (LUGGAGE ROOM LEFT)

G ELECTRICAL WIRING ROUTING


□ : Location of Connector Joining Wire Harness and Wire Harness


▽ : Location of Ground Points

[C/P]



○ : Location of Splice Points






CODE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
BQ1	FLOOR WIRE AND LUGGAGE ROOM WIRE (LUGGAGE ROOM LEFT)


G ELECTRICAL WIRING ROUTING

- : Location of Connector Joining Wire Harness and Wire Harness
- ▽ : Location of Ground Points


[Convertible]



- : Location of Splice Points



Connector Joining Wire Harness and Wire Harness





CODE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
BQ1	FLOOR WIRE AND LUGGAGE ROOM WIRE (LUGGAGE ROOM LEFT)

H POWER SOURCE (Current Flow Chart)

The chart below shows the route by which current flows from the battery to each electrical source (Fusible Link, Circuit Breaker, Fuse, etc.) and other parts.

The next page and following pages show the parts to which each electrical source outputs current.




* These are the page numbers of the first page on which the related system is shown.

The part indicated is located somewhere in the system, not necessarily on the page indicated here.

[LOCATION] ① : Inpane J/B (See page 20)

② : R/B No. 2, J/B No. 2 (See page 26)



③ : R/B No. 4 (See page 25)

④ : R/B No. 6 (See page 27)

H POWER SOURCE (Current Flow Chart)

Location		* Page Nos. of Related Systems	204	208	208	204 208	162	208	102	208	208	108	186	122	208	182	182	167	154	108	76 86	154	66 70 76 86	74
		Parts	A/C Condenser Fan Motor	A/C Magnetic Clutch and Lock Sensor (5S-FE)	A/C Magnetic Clutch (7A-FE)	A/C Triple Pressure SW (A/C Dual and Single Pressure SW)	ABS Actuator	A/C Amplifier	ABS ECU	Air Inlet Control Servo Motor	Air Vent Mode Control Servo Motor	Ashtray Illumination	Auto Antenna Motor and Relay	Back-Up Light SW	Blower SW	Buckle SW LH	Buckle SW RH	Center Airbag Sensor Assembly	Cigarette Lighter	Cigarette Lighter Illumination	Circuit Opening Relay	Clock	Clutch Start SW	Charge Warning Light [Comb. Meter]
CB or Fuse		A 1	A 2	A 2	A 3	A 5	A 8	A 11	A 12	A 13	A 16	A 19	B 1	B 5	B 6	B 7	C 2	C 3	C 4	C 5	C 6	C 7	C 8	
①	30A DOOR																							
	30A POWER																							
	20A FOG																							
	20A WIPER																							
	15A CIG & RAD												●					●	●				●	
	15A ECU-IG				●				●															
	15A STOP								●															
	15A TAIL																							
	10A GAUGE									●				●			●	●						
	10A HTR		●	●				●			●					●								
	10A MIR-HTR																							
	10A TURN																							
	7.5A IGN																		●					●
	7.5A PANEL												●								●		●	
	7.5A ST																					●		●
③	50A ABS					●																		
	30A CDS	●																						
	30A RDI																							
	20A RADIO NO. 1																							
	15A ECU-B																							
	15A EFI																				●			
	15A HEAD (LH) (USA)																							
	15A HEAD (RH) (USA)																							
	15A HEAD LO (LH) (CANADA)																							
	15A HEAD LO (RH) (CANADA)																							
	10A DOME												●										●	
	10A HAZARD																							
	7.5A ALT-S																							
	7.5A HORN																							
	7.5A SRS WRN																		●					
④	10A A/C				●		●																	
	7.5A OBDII																							
⑥	15A HEAD HI (LH) (CANADA)																							
	15A HEAD HI (RH) (CANADA)																							
	7.5A DRL																							

* These are the page numbers of the first page on which the related system is shown.
The part indicated is located somewhere in the system, not necessarily on the page indicated here.

- [LOCATION] ① : Inpane J/B (See page 20) ② : R/B No. 1 (See page 25)
 ③ : R/B No. 2, J/B No. 2 (See page 26) ④ : R/B No. 4 (See page 25)
 ⑤ : R/B No. 5 (See page 27) ⑥ : R/B No. 6 (See page 27)

176 200	108	179	167	162	76, 86 156, 174 194, 196 200	96 98	112	103	96	103	173	142	145	173	156	156	76, 86 162, 167 174	98	112	128 134 150	112	128 134 150	112	112	112	76 86			
Combination Meter	Combination Meter Illumination [Comb. Meter]	Seat Belt Warning Light [Comb. Meter]	SRS Warning Light [Comb. Meter]	ABS Warning Light [Comb. Meter]	Combination Meter	High Beam Indicator Light [Comb. Meter]	Open Door Warning Light [Comb. Meter]	Turn Signal Indicator Light [Comb. Meter]	Dimmer SW [Comb. SW]	Turn Signal SW [Comb. SW]	Horn SW [Comb. SW]	Front Wiper and Washer SW [Comb. SW]	Rear Wiper and Washer SW [Comb. SW]	Horn SW [Comb. SW]	Cruise Control Clutch SW	Cruise Control ECU	Data Link Connector 1	Daytime Running Light Relay (Main)	Diode (Door Courtesy Light)	Diode (Key Off Operation)	Diode (Luggage Compartment Light)	Door Lock Control Relay	Door Courtesy Light LH	Door Courtesy Light RH	Door Courtesy SW RH	Data Link Connector 3			
C 8	C 9				C 11			C 12	C 13			C 14	C 15	D 1	D 3	D 4	D 5	D 6	D 7	D 8	D 9	D 11	D 15						

H POWER SOURCE (Current Flow Chart)

Location		* Page Nos. of Related Systems	86	66, 70 76, 86 174, 184 204	116	116	103 116	103 116	142	76 86	106	106	74	108	108	96 98	96 98	96 98	96 98	173	173	103 108	108 208
		Parts	Engine Control Module	Engine Control Module	Front Side Marker Light LH	Front Side Marker Light RH	Front Turn Signal Light and Parking Light LH	Front Turn Signal Light and Parking Light RH	Front Wiper Motor	Fuel Sender and Pump	Front Fog Light LH	Front Fog Light RH	Generator	Glove Box Light	Glove Box Light SW	Headlight Hi LH	Headlight Hi RH	Headlight Lo LH	Headlight Lo RH	Horn LH	Horn RH	Hazard SW	Heater Control SW
CB or Fuse		E 5	E 7	F 3	F 4	F 5	F 6	F 7	F 10	F 11	F 12	G 1	G 3	G 4	H 1	H 2	H 3	H 4	H 5	H 6	H 7	H 8	
①	30A DOOR																						
	30A POWER																						
	20A FOG									●	●												
	20A WIPER							●															
	15A CIG & RAD																						
	15A ECU-IG		●																				
	15A STOP		●																				
	15A TAIL		●	●	●	●	●																
	10A GAUGE	●	●										●										
	10A HTR																						●
	10A MIR-HTR		●																				
	10A TURN					●	●															●	
	7.5A IGN												●										
	7.5A PANEL													●	●							●	●
7.5A ST	●	●																					
③	50A ABS																						
	30A CDS																						
	30A RDI																						
	20A RADIO NO. 1																						
	15A ECU-B																						
	15A EFI		●							●													
	15A HEAD (LH) (USA)														●		●						
	15A HEAD (RH) (USA)															●		●					
	15A HEAD LO (LH) (CANADA)																●						
	15A HEAD LO (RH) (CANADA)																	●					
	10A DOME																						
	10A HAZARD					●	●															●	
	7.5A ALT-S												●										
7.5A HORN																			●	●			
7.5A SRS WRN																							
④	10A A/C																					●	
	7.5A OBDII																						
⑥	15A HEAD HI (LH) (CANADA)														●	●							
	15A HEAD HI (RH) (CANADA)																						
7.5A DRL																							

* These are the page numbers of the first page on which the related system is shown.
The part indicated is located somewhere in the system, not necessarily on the page indicated here.

- [LOCATION] ① : Inpane J/B (See page 20) ② : R/B No. 1 (See page 25)
 ③ : R/B No. 2, J/B No. 2 (See page 26) ④ : R/B No. 4 (See page 25)
 ⑤ : R/B No. 5 (See page 27) ⑥ : R/B No. 6 (See page 27)

	H 9	H10	H11	I 1	I11	I13	L 1	L 2	L 3	M 2	M 3	M 4	M 5	O 6	P 1	P 3	P 4	P 5	P 6	P 7	P 8	P 9	Q 1	Q 2	Q 3	Q 4	R 1	R 2	
120	High Mounted Stop Light																												
86	Oxygen Sensor (Bank 1 Sensor 1)	●																											
86	Heated Oxygen Sensor (Bank 1 Sensor 2)		●																										
76 86	Idle Air Control Valve			●																									
112	Ignition Key Cylinder Light				●																								
124	Integration Relay					●																							
116	License Plate Light						●																						
112	Luggage Compartment Light							●																					
112	Luggage Compartment Light SW																												
150	Moon Roof Control Relay									●																			
112 150	Moon Roof Control SW and Personal Light (w/ Moon Roof)									●																			
150	Moon Roof Limit SW									●																			
150	Moon Roof Motor									●																			
108 174	O/D Main SW													●															
66, 70, 76 86, 122 156, 174 196, 200	Park/Neutral Position SW													●															
112	Personal Light (w/o Moon Roof)																												
112	Personal Light LH																												
112	Personal Light RH																												
128	Power Window Control SW (Passenger's Side)																				●								
128	Power Window Master SW																				●								
128	Power Window Motor LH																				●								
128	Power Window Motor RH																				●								
128	Quarter Power Window SW LH																					●							
128	Quarter Power Window SW RH																					●							
128	Quarter Power Window Motor LH																					●							
128	Quarter Power Window Motor RH																					●							
204	Radiator Fan Motor																								●	●			
108	Radio and Player																										●		

H POWER SOURCE (Current Flow Chart)

Location		* Page Nos. of Related Systems																				
		Parts	Code or Location																			
		CB or Fuse																				
		108 186 192	108 184	140	108	122	103	120	116	122	103	120	116	145	138 140	138 140	138	138	108 186 188	108	76, 86 120, 148 156, 162 174	
		Radio and Player	Rear Window Defogger SW	Remote Control Mirror SW (w/o Power Window)	Rheostat	Back-Up Light LH [Rear Comb. Light LH]	Rear Turn Signal Light LH [Rear Comb. Light LH]	Stop Light LH [Rear Comb. Light LH]	Taillight and Rear Side Marker Light LH [Rear Comb. Light LH]	Back-Up Light RH [Rear Comb. Light RH]	Rear Turn Signal Light RH [Rear Comb. Light RH]	Stop Light RH [Rear Comb. Light RH]	Taillight and Rear Side Marker Light RH [Rear Comb. Light RH]	Rear Wiper Motor and Relay	Remote Control Mirror LH	Remote Control Mirror RH	Remote Control Mirror SW (w/ Power Window)	Shift Lock ECU	Stereo Component Amplifier	Stereo Component Amplifier	Stop Light SW	
		R 3	R 4	R 5	R 6	R 7		R 8			R 13	R 14	R 15	R 16	S 3	S 4	S 6	S 7				
①	30A	DOOR																				
	30A	POWER																				
	20A	FOG																				
	20A	WIPER												●								
	15A	CIG & RAD	●		●										●	●	●	●	●			
	15A	ECU-IG																●				
	15A	STOP						●				●						●			●	
	15A	TAIL							●					●								
	10A	GAUGE				●					●											
	10A	HTR		●																		
	10A	MIR-HTR																				
	10A	TURN						●				●										
	7.5A	IGN																	●		●	
7.5A	PANEL	●	●		●																	
7.5A	ST																					
③	50A	ABS																				
	30A	CDS																●				
	30A	RDI																				
	20A	RADIO NO. 1	●																		●	
	15A	ECU-B																				
	15A	EFI																				
	15A	HEAD (LH) (USA)																				
	15A	HEAD (RH) (USA)																				
	15A	HEAD LO (LH) (CANADA)																				
	15A	HEAD LO (RH) (CANADA)																				
	10A	DOME																				
	10A	HAZARD						●				●										
	7.5A	ALT-S																				
7.5A	HORN																					
7.5A	SRS WRN																					
④	10A	A/C																				
	7.5A	OBDII																				
⑥	15A	HEAD HI (LH) (CANADA)																				
	7.5A	DRL																				

* These are the page numbers of the first page on which the related system is shown.
The part indicated is located somewhere in the system, not necessarily on the page indicated here.

- [LOCATION] ① : Inpane J/B (See page 20) ② : R/B No. 1 (See page 25)
 ③ : R/B No. 2, J/B No. 2 (See page 26) ④ : R/B No. 4 (See page 25)
 ⑤ : R/B No. 5 (See page 27) ⑥ : R/B No. 6 (See page 27)

194	Top Stack Control SW	T 2																				76, 86 156, 174 194, 196 200	
194	Top Stack Main Relay	T 3																					76 86
182	Tension Reducer Solenoid LH	T 4																					142 145
182	Tension Reducer Solenoid RH	T 5																					204
194	Top Stack Bypass SW	T 6																					188
194	Top Stack Motor LH	T 7																					
194	Top Stack Motor RH	T 8																					
194	Top Stack Relay	T 9																					
	Vehicle Speed Sensor (Combination Meter)	V 1																					
	VSV (EGR)	V 3																					
	Washer Motor	W 1																					
	Water Temp. SW (Radiator Fan)	W 3																					
	Woofer Speaker Amplifier	W 4																					
	Diode (Idle-Up)																						76 86 182
	Integration Relay																						112 179
	Power Main Relay (Coil Side)	①																					128 134 150
	Power Main Relay (Point Side)																						128 134 150
	Defogger Relay (Coil Side)																						184
	Turn Signal Flasher																						103
	Fog Light Relay (Coil Side)	②																					106
	Fog Light Relay (Point Side)																						106
	EFI Relay (Coil Side)																						76 86 174
	EFI Relay (Point Side)																						76 86 174
	E/G MAIN Relay (Coil Side)																						204
	FAN NO. 1 Relay (Coil Side)	③																					204
	FAN NO. 1 Relay (Point Side)																						204
	HORN Relay																						173
	ST Relay (Coil Side)																						66 70 76 86

H POWER SOURCE (Current Flow Chart)

Location		* Page Nos. of Related Systems		208	208	162	162	204	204	204	98	98	98	98	
		Parts Code or Location		Heater Relay (Coil Side)	A/C COMP Relay	ABS MTR Relay (Point Side)	ABS SOL Relay (Point Side)	FAN NO. 2 Relay (Coil side)	FAN NO. 2 Relay (Point Side)	FAN NO. 3 Relay (Point Side)	DRL NO. 3 Relay (Coil Side)	DRL NO. 3 Relay (Point Side)	DRL NO. 4 Relay (Coil Side)	DRL NO. 4 Relay (Point Side)	
CB or Fuse		④	⑤						⑥						
①	30A DOOR														
	30A POWER														
	20A FOG														
	20A WIPER														
	15A CIG & RAD														
	15A ECU-IG							●							
	15A STOP														
	15A TAIL														
	10A GAUGE					●									
	10A HTR		●	●											
	10A MIR-HTR														
	10A TURN														
	7.5A IGN														
	7.5A PANEL														
	7.5A ST														
③	50A ABS				●	●									
	30A CDS							●	●						
	30A RDI														
	20A RADIO NO. 1														
	15A ECU-B														
	15A EFI														
	15A HEAD (LH) (USA)														
	15A HEAD (RH) (USA)														
	15A HEAD LO (LH) (CANADA)														
	15A HEAD LO (RH) (CANADA)														
	10A DOME														
	10A HAZARD														
	7.5A ALT-S														
	7.5A HORN														
7.5A SRS WRN															
④	10A A/C														
	7.5A OBDII														
⑥	15A HEAD HI (LH) (CANADA)													●	
	15A HEAD HI (RH) (CANADA)												●	●	
	7.5A DRL									●		●			

* These are the page numbers of the first page on which the related system is shown.

The part indicated is located somewhere in the system, not necessarily on the page indicated here.

[LOCATION] ① : Inpane J/B (See page 20)

② : R/B No. 1 (See page 25)

③ : R/B No. 2, J/B No. 2 (See page 26)


④ : R/B No. 4 (See page 25)


⑤ : R/B No. 5 (See page 27)

⑥ : R/B No. 6 (See page 27)



POWER SOURCE







POWER SOURCE

SERVICE HINTS

HEAD RELAY (USA)

2-1 : CLOSED WITH THE LIGHT CONTROL SW AT **HEAD** POSITION OR THE DIMMER SW AT **FLASH** POSITION

HEAD RELAY (CANADA)

2-1 : CLOSED WITH THE LIGHT CONTROL SW AT **HEAD** POSITION OR THE DIMMER SW AT **FLASH** POSITION
CLOSED WITH THE ENGINE RUNNING AND THE PARKING BRAKE LEVER RELEASED (PARKING BRAKE SW OFF)

TAILLIGHT RELAY

5-3 : CLOSED WITH THE LIGHT CONTROL SW AT **TAIL** OR **HEAD** POSITION

I12 IGNITION SW

7-5 : CLOSED WITH THE IGNITION KEY AT **ACC** OR **ON** POSITION

7-4 : CLOSED WITH THE IGNITION KEY AT **ON** OR **ST** POSITION

2-3 : CLOSED WITH THE IGNITION KEY AT **ON** OR **ST** POSITION

2-1 : CLOSED WITH THE IGNITION KEY AT **ST** POSITION

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
G 2	28 (5S-FE), 30 (7A-FE)	I12	33	J 5	33

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT
4	25	RIGHT KICK PANEL
6	27	ENGINE COMPARTMENT FRONT LEFT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IA	20	ENGINE ROOM MAIN WIRE AND INPANE J/B (LEFT KICK PANEL)
IB		
IC	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
2A	26	ENGINE ROOM MAIN WIRE AND J/B NO.2 (ENGINE COMPARTMENT LEFT)
2B		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	38 (5S-FE)	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (INSIDE OF R/B NO.2)
	40 (7A-FE)	
IC3	42	ENGINE ROOM MAIN WIRE AND COWL WIRE (INSIDE OF R/B NO.4)

▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EB	38 (5S-FE)	FRONT SIDE OF LEFT FENDER
	40 (7A-FE)	


○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E 3	38 (5S-FE)	ENGINE ROOM MAIN WIRE	E 5	38 (5S-FE)	ENGINE WIRE
	40 (7A-FE)		E 8	44 (7A-FE)	


G 2



I12




J 5




(HINT:SEE PAGE 7)



STARTING AND IGNITION (5S-FE)







STARTING AND IGNITION (5S-FE)

SERVICE HINTS

I 12 IGNITION SW

- 2-3 : CLOSED WITH THE IGNITION SW AT **ON** OR **ST** POSITION
- 2-1 : CLOSED WITH THE IGNITION SW AT **ST** POSITION

C 7 CLUTCH START SW (M/T)

- 1-2 : CLOSED WITH THE CLUTCH PEDAL FULLY DEPRESSED

ST RELAY

- (2) 3- (2) 5 : CLOSED WITH THE CLUTCH START SW ON (M/T), PARK/NEUTRAL POSITION SW ON (A/T) AND THE IGNITION SW AT **ST** POSITION

S 1 (A), S 2 (B) STARTER

- POINTS CLOSED WITH THE CLUTCH START SW ON AND THE IGNITION SW AT **ST** POSITION (M/T)
- POINTS CLOSED WITH PARK/NEUTRAL POSITION SW ON AND THE IGNITION SW AT **ST** POSITION (A/T)

P 1 PARK/NEUTRAL POSITION SW (A/T)

- 5-6 : CLOSED WITH THE A/T SHIFT LEVER AT **P** OR **N** POSITION

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C 7	32	E 7	B 32	N 1	29
C16	28	I 2	29	P 1	29
D 2	28	I 3	29	S 1	A 29
E 5	A 32	I12	33	S 2	B 29

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IB	20	ENGINE ROOM MAIN WIRE AND INPANE J/B (LEFT KICK PANEL)
IC	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
IF		
2A	26	ENGINE ROOM MAIN WIRE AND J/B NO.2 (ENGINE COMPARTMENT LEFT)
2B		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	38 (5S-FE)	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (INSIDE OF R/B NO.2)
ID1	42	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)
II1	44	ENGINE WIRE AND INSTRUMENT PANEL WIRE (NEAR THE ENGINE CONTROL MODULE)
II2		
IJ1	44	ENGINE WIRE AND COWL WIRE (INSTRUMENT PANEL CENTER)


▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EB	38 (5S-FE)	FRONT SIDE OF LEFT FENDER

○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I 8	44	ENGINE WIRE	I13	44	ENGINE WIRE


C 7




C16 DARK GRAY




D 2 BLACK




(A/T) E 5 (A) DARK GRAY




(M/T) E 5 (A) DARK GRAY




(A/T) E 7 (B) DARK GRAY




(M/T) E 7 (B) DARK GRAY




I 2 BLACK



I 3 BLACK




I12



N 1 GRAY



P 1 GRAY



8 1 (A)




8 2 (B) BLACK





CHARGING



SERVICE HINTS

G 1 (A) GENERATOR

- (A)** 3-GROUND : 13.9-15.1 VOLTS WITH THE ENGINE RUNNING AT 2000 RPM AND 25°C (77°F)
 13.5-14.3 VOLTS WITH THE ENGINE RUNNING AT 5000 RPM AND 115°C (239°F)
- (A)** 1-GROUND : 0-4 VOLTS WITH THE IGNITION SW AT ON POSITION AND THE ENGINE NOT RUNNING

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C 8	32	G 2	B	28 (5S-FE), 30 (7A-FE)	
G 1	A	I12		33	

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR





CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IA	20	ENGINE ROOM MAIN WIRE AND INPANE J/B (LEFT KICK PANEL)
IB		
IC		
ID	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
IE		
IC	22	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT KICK PANEL)
ID		
2A	26	ENGINE ROOM MAIN WIRE AND J/B NO.2 (ENGINE COMPARTMENT LEFT)
2B		
3C	24	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	38 (5S-FE)	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (INSIDE OF R/B NO.2)
	40 (7A-FE)	
II1	44	ENGINE WIRE AND INSTRUMENT PANEL WIRE (NEAR THE ENGINE CONTROL MODULE)

○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E 5	38 (5S-FE)	ENGINE WIRE	I 6	44	INSTRUMENT WIRE
E 8	40 (7A-FE)				





ENGINE CONTROL (5S-FE)

SYSTEM OUTLINE

THE ENGINE CONTROL SYSTEM UTILIZES A MICROCOMPUTER AND MAINTAINS OVERALL CONTROL OF THE ENGINE, TRANSMISSION, ETC. AN OUTLINE OF ENGINE CONTROL IS GIVEN HERE.

3. INPUT SIGNALS

(1) ENGINE COOLANT TEMP. SIGNAL SYSTEM

THE ENGINE COOLANT TEMP. SENSOR DETECTS THE ENGINE COOLANT TEMP. AND HAS A BUILT-IN THERMISTOR WITH A RESISTANCE WHICH VARIES ACCORDING TO THE ENGINE COOLANT TEMP. THUS THE ENGINE COOLANT TEMP. IS INPUT IN THE FORM OF A CONTROL SIGNAL TO **TERMINAL THW** OF THE ENGINE CONTROL MODULE.

(2) INTAKE AIR TEMP. SIGNAL SYSTEM

THE INTAKE AIR TEMP. SENSOR DETECTS THE INTAKE AIR TEMP., WHICH IS INPUT AS A CONTROL SIGNAL TO **TERMINAL THA** OF THE ENGINE CONTROL MODULE.

(3) OXYGEN SENSOR SIGNAL SYSTEM

THE OXYGEN DENSITY IN THE EXHAUST EMISSIONS IS DETECTED AND INPUT AS A CONTROL SIGNAL TO **TERMINALS OX1** AND **OX2** OF THE ENGINE CONTROL MODULE.

(4) RPM SIGNAL SYSTEM

CRANKSHAFT POSITION AND ENGINE RPM ARE DETECTED BY THE COIL INSTALLED INSIDE THE DISTRIBUTOR. CRANKSHAFT POSITION IS INPUT AS A CONTROL SIGNAL TO **TERMINAL NE+** OF THE ENGINE CONTROL MODULE, AND ENGINE RPM IS INPUT TO **TERMINAL G**.

(5) THROTTLE SIGNAL SYSTEM

THE THROTTLE POSITION SENSOR DETECTS THE THROTTLE VALVE OPENING ANGLE, WHICH IS INPUT AS A CONTROL SIGNAL TO **TERMINAL VTA** OF THE ENGINE CONTROL MODULE, OR WHEN THE VALVE IS FULLY CLOSED.

(6) VEHICLE SPEED SIGNAL SYSTEM

THE VEHICLE SPEED SENSOR DETECTS THE VEHICLE SPEED AND INPUTS A CONTROL SIGNAL TO **TERMINAL SPD** OF THE ENGINE CONTROL MODULE VIA THE COMBINATION METER.

(7) PARK/NEUTRAL POSITION SW SIGNAL SYSTEM

THE PARK/NEUTRAL POSITION SW DETECTS WHETHER THE SHIFT POSITION IS IN NEUTRAL OR NOT, AND INPUTS A CONTROL SIGNAL TO **TERMINAL NSW** OF THE ENGINE CONTROL MODULE.

(8) A/C SW SIGNAL SYSTEM

THE OPERATING VOLTAGE OF THE A/C MAGNETIC CLUTCH IS DETECTED AND IS INPUT IN THE FORM OF A CONTROL SIGNAL TO **TERMINAL ACT** OF THE ENGINE CONTROL MODULE, AND OPERATION A/C IDLE-UP VSV IS DETECTED AND IS INPUT IN THE FORM OF A CONTROL SIGNAL TO **TERMINAL AC1** OF THE ENGINE CONTROL MODULE.

(9) BATTERY SIGNAL SYSTEM

VOLTAGE IS CONSTANTLY APPLIED TO **TERMINAL BATT** OF THE ENGINE CONTROL MODULE. WHEN THE IGNITION SW IS TURNED TO ON, VOLTAGE FOR ENGINE CONTROL MODULE OPERATION IS APPLIED VIA THE EFI RELAY TO **TERMINAL +B** OF THE ENGINE CONTROL MODULE.

(10) INTAKE AIR VOLUME SIGNAL SYSTEM

INTAKE AIR VOLUME IS DETECTED BY THE MANIFOLD ABSOLUTE PRESSURE SENSOR AND IS INPUT AS A CONTROL SIGNAL TO **TERMINAL PIM** OF THE ENGINE CONTROL MODULE.

(11) STA SIGNAL SYSTEM

TO CONFIRM THAT THE ENGINE IS CRANKING, VOLTAGE APPLIED TO THE STARTER MOTOR DURING CRANKING IS DETECTED AND IS INPUT AS A CONTROL SIGNAL TO **TERMINAL STA** OF THE ENGINE CONTROL MODULE.

(12) ELECTRICAL LOAD SIGNAL SYSTEM

THE SIGNAL, WHEN SYSTEMS SUCH AS THE REAR WINDOW DEFOGGER, HEADLIGHT, ETC. WHICH CAUSE A HIGH ELECTRICAL BURDEN ARE ON, IS INPUT TO **TERMINAL ELS** AS A CONTROL SIGNAL.

4. CONTROL SYSTEM

* SFI SYSTEM

THE SFI SYSTEM MONITORS THE ENGINE CONDITION THROUGH THE SIGNALS, WHICH ARE INPUT FROM EACH SENSOR (INPUT SIGNALS FROM (1) TO (12) ETC.). THE BEST FUEL INJECTION VOLUME IS DECIDED BASED ON THIS DATA AND THE PROGRAM MEMORIZED BY THE ENGINE CONTROL MODULE, AND THE CONTROL SIGNAL IS OUTPUT TO **TERMINALS #10, #20, #30, AND #40** OF THE ENGINE CONTROL MODULE TO OPERATE THE INJECTOR (INJECT THE FUEL). THE SFI SYSTEM PRODUCES CONTROL OF FUEL INJECTION OPERATION BY THE ENGINE CONTROL MODULE IN RESPONSE TO THE DRIVING CONDITIONS.

DURING ENGINE CRANKING (SIGNAL INPUT TO **TERMINAL STA**) OR FOR APPROX. 2 SECONDS AFTER NE SIGNAL INPUT, ENGINE CONTROL MODULE OPERATION ENERGIZES (POINT CLOSED) THE FUEL PUMP CIRCUIT INSIDE THE CIRCUIT OPENING RELAY, CAUSING THE FUEL PUMP TO OPERATE.

* ESA SYSTEM

THE ESA SYSTEM MONITORS THE ENGINE CONDITIONS USING THE SIGNALS (INPUT SIGNALS (1 TO 5, 9, 10)) INPUT TO THE ENGINE CONTROL MODULE FROM EACH SENSOR. BASED ON THIS DATA AND THE PROGRAM MEMORIZED IN THE ENGINE CONTROL MODULE, THE MOST APPROPRIATE IGNITION TIMING IS DECIDED AND CURRENT IS OUTPUT TO **TERMINAL IGT** OF THE ENGINE CONTROL MODULE. THIS OUTPUT CONTROLS THE IGNITER TO PRODUCE THE MOST APPROPRIATE IGNITION TIMING FOR THE DRIVING CONDITIONS.

* IDLE AIR CONTROL SYSTEM

THE IDLE AIR CONTROL SYSTEM (ROTARY SOLENOID TYPE) INCREASES THE RPM AND PROVIDES IDLING STABILITY FOR FAST IDLE-UP WHEN THE ENGINE IS COLD AND WHEN THE IDLE SPEED HAS DROPPED DUE TO ELECTRICAL LOAD, ETC. THE ENGINE CONTROL MODULE EVALUATES THE SIGNALS FROM EACH SENSOR (INPUT SIGNALS (1 TO 3, 5, 8, 10, 12)), OUTPUTS CURRENT TO **TERMINALS ISCC** AND **ISCO**, AND CONTROLS THE IDLE AIR CONTROL VALVE.

* EGR CUT CONTROL SYSTEM

THE EGR CUT CONTROL SYSTEM CONTROLS THE VSV (EGR) BY EVALUATING THE SIGNALS FROM EACH SENSOR INPUT TO THE ENGINE CONTROL MODULE (INPUT SIGNALS (1 TO 6, 10)) AND BY SENDING OUTPUT TO **TERMINAL EGR** OF THE ENGINE CONTROL MODULE.

* A/C CUT CONTROL SYSTEM

WHEN THE VEHICLE SUDDENLY ACCELERATES FROM LOW ENGINE SPEED, THIS SYSTEM CUTS OFF AIR CONDITIONING OPERATION FOR A FIXED PERIOD OF TIME IN RESPONSE TO THE VEHICLE SPEED, THROTTLE VALVE OPENING ANGLE AND INTAKE MANIFOLD PRESSURE IN ORDER TO MAINTAIN ACCELERATION PERFORMANCE.

THE ENGINE CONTROL MODULE RECEIVES INPUT SIGNALS (4 TO 6, 8), AND OUTPUTS SIGNALS TO **TERMINAL ACT**.

5. DIAGNOSIS SYSTEM


WITH THE DIAGNOSIS SYSTEM, WHEN THERE IS A MALFUNCTIONING IN THE ENGINE CONTROL MODULE SIGNAL SYSTEM, THE MALFUNCTION SYSTEM IS RECORDED IN THE MEMORY. THE MALFUNCTIONING SYSTEM CAN THEN BE FOUND BY READING THE DISPLAY (CODE) OF THE MALFUNCTION INDICATOR LAMP.


6. FAIL-SAFE SYSTEM

WHEN A MALFUNCTION OCCURS IN ANY SYSTEM, IF THERE IS A POSSIBILITY OF ENGINE TROUBLE BEING CAUSED BY CONTINUED CONTROL BASED ON THE SIGNALS FROM THAT SYSTEM, THE FAIL-SAFE SYSTEM EITHER CONTROLS THE SYSTEM BY USING DATA (STANDARD VALUES) RECORDED IN THE ENGINE CONTROL MODULE MEMORY OR ELSE STOPS THE ENGINE.




ENGINE CONTROL (5S-FE)








ENGINE CONTROL (5S-FE)








ENGINE CONTROL (5S-FE)

FROM POWER SOURCE SYSTEM (SEE PAGE 62)



SERVICE HINTS

E 5 (A), E 6 (B), E 7 (C) ENGINE CONTROL MODULE

BATT	-E1	: ALWAYS 9.0-14.0 VOLTS
+B	-E1	: 9.0-14.0 VOLTS (IGNITION SW AT ON POSITION)
VC	-E2	: 4.5-5.5 VOLTS (IGNITION SW AT ON POSITION)
VTA	-E2	: 0.3-0.8 VOLTS (IGNITION SW ON AND THROTTLE VALVE FULLY CLOSED) 3.2-4.9 VOLTS (IGNITION SW ON AND THROTTLE VALVE OPEN)
PIM	-E2	: 3.3-3.9 VOLTS (IGNITION SW AT ON POSITION)
#10, #20, #30, #40-E01, E02		: 9.0-14.0 VOLTS (IGNITION SW AT ON POSITION)
THA	-E2	: 0.5-3.4 VOLTS (IGNITION SW ON AND INTAKE AIR TEMP. 20° C (68° F))
THW	-E2	: 0.2-1.0 VOLTS (IGNITION SW ON AND COOLANT TEMP. 80° C (176° F))
STA	-E1	: 6.0-14.0 VOLTS (ENGINE CRANKING)
IGT	-E1	: 0.8-1.2 VOLTS (ENGINE CRANKING OR IDLING)
W	-E1	: 9.0-14.0 VOLTS (NO TROUBLE AND ENGINE RUNNING)
ACT	-E1	: 4.5-5.5 VOLTS (IGNITION SW ON AND AIR CONDITIONING ON)
AC1	-E1	: 0-3.0 VOLTS (IGNITION SW ON AND AIR CONDITIONING ON)
ISCC, ISCO	-E1	: 9.0 -14.0 VOLTS (IGNITION SW AT ON POSITION)
TE1	-E1	: 9.0-14.0 VOLTS (IGNITION SW ON AND DATA LINK CONNECTOR 1 TE1-E1 NOT CONNECTED) 0-3.0 VOLTS (IGNITION SW ON AND DATA LINK CONNECTOR 1 TE1-E1 CONNECTED)
NSW	-E1	: 0-3.0 VOLTS (IGNITION SW ON AND PARK/NEUTRAL POSITION SW AT P OR N POSITION) 9.0-14.0 VOLTS (IGNITION SW ON AND PARK/NEUTRAL POSITION SW AT EXCEPT P AND N POSITION)
B/K	-E1	: 9.0-14.0 VOLTS (BRAKE PEDAL DEPRESSED)

RESISTANCE OF ECU WIRING CONNECTORS

(DISCONNECT WIRING CONNECTOR)

VTA	-E2	: 3.3- 10.0 KΩ (THROTTLE VALVE FULLY OPEN) 0.2- 0.8 KΩ (THROTTLE VALVE FULLY CLOSED)
VC	-E2	: 3.0- 7.0 KΩ
THA	-E2	: 2.0- 3.0 KΩ (INTAKE AIR TEMP. 20° C (68° F))
THW	-E2	: 0.2- 0.4 KΩ (COOLANT TEMP. 80° C (176° F))
ISCC, ISCO	-+B	: 19.3-22.3 Ω

C 5 CIRCUIT OPENING RELAY

1-2 : CLOSED WITH THE STARTER CRANKING AND ENGINE RUNNING

EFI RELAY

(2) 3- (2) 5 : CLOSED WITH THE IGNITION SW AT ON OR ST POSITION

E 4 ENGINE COOLANT TEMP. SENSOR

1-2	: 10.0- 20.0 KΩ (-20° C, -4° F) 4.0- 7.0 KΩ (0° C, 32° F) 2.0- 3.0 KΩ (20° C, 68° F) 0.9- 1.3 KΩ (40° C, 104° F) 0.4- 0.7 KΩ (60° C, 140° F) 0.2- 0.4 KΩ (80° C, 176° F)
-----	---

I 6, I 7, I 8, I 9 INJECTOR

1-2 : APPROX. 13.8 Ω

T 1 THROTTLE POSITION SENSOR

3-1	: 0.2- 5.7 KΩ WITH CLEARANCE BETWEEN THE LEVER AND THE STOP SCREW 0 MM (0 IN.)
2-1	: LESS THAN 2.3 KΩ WITH CLEARANCE BETWEEN THE LEVER AND THE STOP SCREW 0.5 MM (0.02 IN.) WITH CLEARANCE BETWEEN THE LEVER AND THE STOP SCREW 0.7 MM (0.028 IN.)
3-1	: 2.0- 10.2 KΩ WITH THE THROTTLE VALVE FULLY OPEN

○ : PARTS LOCATION

CODE		SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A 8		32	F10	34 (L/B), 35 (C/P)	J 7	33
C 5		32		36 (CONVERTIBLE)	J 9	33
C 7		32	I 1	29	K 1	29
C 9	B	32	I 2	29	M 1	29
C10	C	32	I 6	29	O 2	29
C16		28	I 7	29	O 3	29
D 1		28	I 8	29	P 1	29
D 2		28	I 9	29	S 7	33
D15		32	I10	29	T 1	29
E 4		28	I12	33	V 1	29
E 5	A	32	J 2	33	V 3	29
E 6	B	32	J 3	33		
E 7	C	32	J 4	33		



ENGINE CONTROL (5S-FE)

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT
4	25	RIGHT KICK PANEL

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IA	20	ENGINE ROOM MAIN WIRE AND INPANE J/B (LEFT KICK PANEL)
IB		
IC		
ID		
IE	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
IF		
IH		
I1A		
1A	22	ENGINE ROOM MAIN WIRE AND J/B NO.1 (LEFT KICK PANEL)
1C	22	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT KICK PANEL)
2A	26	ENGINE ROOM MAIN WIRE AND J/B NO.2 (ENGINE COMPARTMENT LEFT)
2B		
3B	24	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)
3C		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	38 (5S-FE)	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (INSIDE OF R/B NO.2)
ID1	42	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)
ID2		
IF1	42	COWL WIRE AND FLOOR WIRE (LEFT KICK PANEL)
II1	44	ENGINE WIRE AND INSTRUMENT PANEL WIRE (NEAR THE ENGINE CONTROL MODULE)
II2		
IJ1	44	ENGINE WIRE AND COWL WIRE (INSTRUMENT PANEL CENTER)
IM1	44	ENGINE WIRE AND A/C SUB WIRE (NEAR THE BLOWER MOTOR)


▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EB	38 (5S-FE)	FRONT SIDE OF LEFT FENDER
EC	38 (5S-FE)	INTAKE MANIFOLD
IE	42	INSTRUMENT PANEL BRACE LH
IF	42	R/B NO.4 SET BOLT
BH	46 (L/B)	UNDER THE LEFT CENTER PILLAR
	48 (C/P)	
	50 (CONVERTIBLE)	


○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E 6	38 (5S-FE)	ENGINE WIRE	I13	44	ENGINE WIRE
I 8	44				

A 8 BLACK




C 5 DARK GRAY




C 7



C 9 B




C10 C GRAY




C16 DARK GRAY




D 1 BLACK



D 2 BLACK




D15




E 4 DARK GRAY




(A/T) E 5 (A) DARK GRAY




(M/T) E 5 (A) DARK GRAY




E 6 (B) DARK GRAY



(A/T) E 7 (C) DARK GRAY




(M/T) E 7 (C) DARK GRAY



F10 DARK GRAY



I 1 GRAY



I 2 BLACK



I 6, I 8 BROWN




I 7, I 9 GRAY




I10 BLACK



I12



J 2



(HINT:SEE PAGE 7)

J 3




(HINT:SEE PAGE 7)

J 4



(HINT:SEE PAGE 7)

J 7



(HINT:SEE PAGE 7)

J 9



(HINT:SEE PAGE 7)

K 1 DARK GRAY



M 1 BLACK




O 2 DARK GRAY




O 3 DARK GRAY




P 1 GRAY



(W/ CRUISE S 7 CONTROL)



(W/O CRUISE S 7 CONTROL)




T 1 BLACK



V 1 BLACK




V 3 GRAY





HEADLIGHT (USA)



SERVICE HINTS

HEAD RELAY

(2) 2- (2) 1 : CLOSED WITH THE LIGHT CONTROL SW AT **HEAD** POSITION OR THE DIMMER SW AT **FLASH** POSITION

C11 LIGHT CONTROL SW [COMB. SW]

13-16 : CLOSED WITH THE LIGHT CONTROL SW AT **HEAD** POSITION

C11 DIMMER SW [COMB. SW]

8-16 : CLOSED WITH THE DIMMER SW AT **FLASH** POSITION

7-16 : CLOSED WITH THE DIMMER SW AT **HIGH** OR **FLASH** POSITION

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C 9	32	H 2	28 (5S-FE), 30 (7A-FE)	I13	33
C11	32	H 3	28 (5S-FE), 30 (7A-FE)	J 1	33
H 1	28 (5S-FE), 30 (7A-FE)	H 4	28 (5S-FE), 30 (7A-FE)		

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IA	20	ENGINE ROOM MAIN WIRE AND INPANE J/B (LEFT KICK PANEL)
IA	22	ENGINE ROOM MAIN WIRE AND J/B NO.1 (LEFT KICK PANEL)
1D	22	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT KICK PANEL)
1J	22	COWL WIRE AND J/B NO.1 (LEFT KICK PANEL)
2A	26	ENGINE ROOM MAIN WIRE AND J/B NO.2 (ENGINE COMPARTMENT LEFT)
2B		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS





CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IC2	42	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
ID1	42	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)

▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EB	38 (5S-FE)	FRONT SIDE OF LEFT FENDER
	40 (7A-FE)	
ID	42	LEFT KICK PANEL

○ : SPLICE POINTS


CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E3	38 (5S-FE)	ENGINE ROOM MAIN WIRE	E 4	40 (7A-FE)	ENGINE ROOM MAIN WIRE
	40 (7A-FE)		I 1	44	COWL WIRE
E4	38 (5S-FE)				




(HINT:SEE PAGE 7)



HEADLIGHT (CANADA)







HEADLIGHT (CANADA)

SYSTEM OUTLINE

VOLTAGE IS ALWAYS APPLIED FROM THE **MAIN** FUSE, THROUGH THE HEAD RELAY (COIL SIDE) TO **TERMINAL 5** OF THE DAYTIME RUNNING LIGHT RELAY (MAIN), **TERMINAL 3** OF LIGHT AUTO CUT RELAY (INTEGRATION RELAY), **TERMINAL 8** OF DIMMER SW, THROUGH DRL NO.2 RELAY (COIL SIDE), TO **TERMINAL 17** OF THE DAYTIME RUNNING LIGHT RELAY (MAIN). WHEN THE IGNITION SW IS TURNED ON, VOLTAGE FROM THE **GAUGE** FUSE IS APPLIED TO **TERMINAL 2** OF THE DAYTIME RUNNING LIGHT RELAY (MAIN).

1. DAYTIME RUNNING LIGHT OPERATION

WHEN THE ENGINE STARTS, VOLTAGE FROM **TERMINAL "L"** OF THE GENERATOR IS APPLIED TO **TERMINAL 11** OF THE DAYTIME RUNNING LIGHT RELAY (MAIN). IF THE PARKING BRAKE LEVER IS PULLED UP (PARKING BRAKE SW ON) AT THIS TIME, THE RELAY AND THE DAYTIME RUNNING LIGHTS DO NOT OPERATE.

WHEN THE PARKING BRAKE IS RELEASED (PARKING BRAKE SW OFF), A SIGNAL IS OUTPUT FROM **TERMINAL 1** OF THE PARKING BRAKE SW TO **TERMINAL 8** OF THE DAYTIME RUNNING LIGHT RELAY (MAIN). THIS ACTIVATES THE DAYTIME RUNNING LIGHT RELAY (MAIN), TURNING ON THE DRL NO.2 RELAY. CURRENT ALSO FLOWS FROM THE **MAIN** FUSE TO DRL NO.2 RELAY (POINT SIDE) → **HEAD HI (LH)** FUSE → HEADLIGHT HI LH → HEADLIGHT HI RH → **TERMINAL 1** OF DRL NO.3 RELAY → **TERMINAL 4** → **GROUND**, CAUSING THE HEADLIGHTS TO LIGHT UP AT HALF THEIR NORMAL BRIGHTNESS.

ONCE THE DAYTIME RUNNING LIGHT RELAY (MAIN) HAS BEEN ACTIVATED AND THE HEADLIGHTS LIGHT UP, THE HEADLIGHTS REMAIN ON EVEN IF THE PARKING BRAKE LEVER IS ENGAGED AGAIN (PARKING BRAKE SW ON).

2. HEADLIGHT OPERATION

WHEN THE LIGHT CONTROL SW IS AT **HEAD** POSITION AND THE DIMMER SW IS AT **LOW** POSITION, CURRENT FLOWS FROM THE HEAD RELAY (COIL SIDE) TO **TERMINAL 3** OF THE LIGHT AUTO CUT RELAY (INTEGRATION RELAY) → **TERMINAL 4** → **TERMINAL 14** OF LIGHT CONTROL SW → **TERMINAL 16** → **GROUND**, ACTIVATING THE HEAD RELAY.

THIS CAUSES CURRENT TO FLOW FROM THE HEAD RELAY (POINT SIDE) TO THE **HEAD LO** FUSE → HEADLIGHT LO → **GROUND**, CAUSING THE HEADLIGHT TO LIGHT UP AT NORMAL BRIGHTNESS. SIMULTANEOUSLY, CURRENT FLOWS FROM THE **DRL** FUSE TO DRL NO.3 RELAY (COIL SIDE) → **GROUND**, ACTIVATING RELAY NO.3.

WHEN THE DIMMER SW IS AT HIGH POSITION, **TERMINAL 7** OF THE DIMMER SW OUTPUTS A SIGNAL TO **TERMINAL 16** OF THE DAYTIME RUNNING LIGHT RELAY (MAIN) TO ACTIVATE IT. THIS TURNS ON DRL NO.2 RELAY, SO CURRENT FLOWS FROM DRL NO.2 RELAY (POINT SIDE) TO THE **HEAD HI (LH)** FUSE → HEADLIGHT HI LH → DRL NO.4 RELAY (POINT SIDE) → **GROUND**, AND FROM THE **HEAD HI (RH)** FUSE TO DRL NO.3 RELAY (POINT SIDE) → HEADLIGHT HI RH → DRL NO.4 RELAY (POINT SIDE) → **GROUND**, CAUSING THE HEADLIGHTS TO OPERATE AT HI.

WHEN THE DIMMER SW IS AT **FLASH** POSITION, CURRENT FROM THE HEAD RELAY (COIL SIDE) FLOWS TO **TERMINAL 8** OF THE DIMMER SW → **TERMINAL 16** → **GROUND**, ACTIVATING THE RELAY. SIMULTANEOUSLY, CURRENT FROM THE HEAD RELAY (POINT SIDE) FLOWS TO HEADLIGHT LO, LIGHTING UP HEADLIGHT LO AND ACTIVATING DRL NO.3 RELAY. THEN **TERMINAL 7** OF THE DIMMER SW OUTPUTS A SIGNAL TO **TERMINAL 16** OF THE DAYTIME RUNNING LIGHT RELAY (MAIN), ACTIVATING THE DAYTIME RUNNING LIGHT RELAY (MAIN) SO THAT CURRENT FLOWS TO HEADLIGHT HI LIKE IT DOES FOR **HIGH** POSITION. THIS CAUSES ALL HEADLIGHTS TO LIGHT UP.

SERVICE HINTS

D 3 DAYTIME RUNNING LIGHT RELAY (MAIN)

- 15-GROUND : ALWAYS APPROX. 12 VOLTS
- 2-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION
- 13-GROUND : ALWAYS CONTINUITY
- 5-GROUND : APPROX. 12 VOLTS WITH THE DAYTIME RUNNING LIGHT SYSTEM
DOES NOT OPERATE OR THE LIGHT CONTROL SW AT **OFF** OR **TAIL** POSITION
(WITH THE CONNECTOR DISCONNECTED, ALWAYS APPROX. 12 VOLTS)
- 8-GROUND : CONTINUITY WITH THE PARKING BRAKE LEVER PULLED

 : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
B 2	28 (5S-FE), 30 (7A-FE)	H 1	28 (5S-FE), 30 (7A-FE)	J 1	33
C 9	32	H 2	28 (5S-FE), 30 (7A-FE)	J 9	33
C11	32	H 3	28 (5S-FE), 30 (7A-FE)	P 2	33
D 3	32	H 4	28 (5S-FE), 30 (7A-FE)		
G 1	28 (5S-FE), 30 (7A-FE)	I13	33		

 : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT
6	27	ENGINE COMPARTMENT FRONT LEFT

 : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IA	20	ENGINE ROOM MAIN WIRE AND INPANE J/B (LEFT KICK PANEL)
ID	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
1A	22	ENGINE ROOM MAIN WIRE AND J/B NO.1 (LEFT KICK PANEL)
1C	22	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT KICK PANEL)
1D		
1J	22	COWL WIRE AND J/B NO.1 (LEFT KICK PANEL)
1K		
2A	26	ENGINE ROOM MAIN WIRE AND J/B NO.2 (ENGINE COMPARTMENT)
2B		

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IC2	42	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
ID1	42	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)
ID2		
I11	44	ENGINE WIRE AND INSTRUMENT PANEL WIRE (NEAR THE ENGINE CONTROL MODULE)

 : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EB	38 (5S-FE)	FRONT SIDE OF LEFT FENDER
	40 (7A-FE)	
ID	42	LEFT KICK PANEL
IE	42	INSTRUMENT PANEL BRACE LH
IF	42	R/B NO.4 SET BOLT

 : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E 1	38 (5S-FE)	ENGINE ROOM MAIN WIRE	E 4	40 (7A-FE)	ENGINE ROOM MAIN WIRE
	40 (7A-FE)		I 1	44	COWL WIRE
E 3	38 (5S-FE)		I 2		
	40 (7A-FE)		I15		
E 4	38 (5S-FE)				




HEADLIGHT (CANADA)


B 2 GRAY




C 9




C11



D 3 GRAY



G 1 BLACK



H 1 BLACK



H 2 BLACK




H 3 BROWN




H 4 BROWN



I13




J 1



(HINT:SEE PAGE 7)

J 9



(HINT:SEE PAGE 7)


P 2 BLACK




TURN SIGNAL AND HAZARD WARNING LIGHT




C 9



C11



F 5 GRAY




F 6 GRAY



H 7 BLACK




J 1




(HINT:SEE PAGE 7)

R 7




R 8





TURN SIGNAL AND HAZARD WARNING LIGHT



SERVICE HINTS

TURN SIGNAL FLASHER

- (1) 2-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW ON OR THE HAZARD SW ON
- (1) 1-GROUND : CHANGES FROM 12 TO 0 VOLTS WITH THE IGNITION SW ON AND THE TURN SIGNAL SW LEFT OR RIGHT, AND WITH THE HAZARD SW ON
- (1) 3-GROUND : ALWAYS CONTINUITY

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C 9	32	H 7	33	R 8	34 (L/B), 35 (C/P)
C11	32	J 1	33		37 (CONVERTIBLE)
F 5	28 (5S-FE), 30 (7A-FE)	R 7	34 (L/B), 35 (C/P)		
F 6	28 (5S-FE), 30 (7A-FE)		37 (CONVERTIBLE)		

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
1	25	LEFT KICK PANEL
2	26	ENGINE COMPARTMENT LEFT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IG	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
1A	22	ENGINE ROOM MAIN WIRE AND J/B NO.1 (LEFT KICK PANEL)
1D	22	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT KICK PANEL)
1F	22	FLOOR WIRE AND J/B NO.1 (LEFT KICK PANEL)
1J	22	COWL WIRE AND J/B NO.1 (LEFT KICK PANEL)
3B	24	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)
3C		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
ID1	42	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)
BQ1	46 (L/B)	FLOOR WIRE AND LUGGAGE ROOM WIRE (LUGGAGE ROOM LEFT)
	48 (C/P)	
	50 (CONVERTIBLE)	

▽ : GROUND POINTS


CODE	SEE PAGE	GROUND POINTS LOCATION
EA	38 (5S-FE)	FRONT SIDE OF RIGHT FENDER
	40 (7A-FE)	
EB	38 (5S-FE)	FRONT SIDE OF LEFT FENDER
	40 (7A-FE)	
ID	42	LEFT KICK PANEL
IE	42	INSTRUMENT PANEL BRACE LH
BK	46 (L/B)	BACK DOOR CENTER
	48 (C/P)	
	50 (CONVERTIBLE)	

○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E 1	38 (5S-FE)	ENGINE ROOM MAIN WIRE	I 1	44	COWL WIRE
	40 (7A-FE)				



FOG LIGHT



SERVICE HINTS

FOG LIGHT RELAY

(1) 3- **(1)** 5 : CLOSED WITH THE LIGHT CONTROL SW AT **HEAD** POSITION, DIMMER SW AT **LOW** POSITION AND THE FOG LIGHT SW AT **ON** POSITION

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C11	32	F12	28 (5S-FE), 30 (7A-FE)		
F11	28 (5S-FE), 30 (7A-FE)	J 1	33		

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
1	25	LEFT KICK PANEL
2	26	ENGINE COMPARTMENT LEFT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IA	20	ENGINE ROOM MAIN WIRE AND INPANE J/B (LEFT KICK PANEL)
IF	20	INSTRUMENT PANEL AND COWL WIRE (LEFT KICK PANEL)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS





CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IC2	42	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
ID1	42	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)

▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EB	38 (5S-FE)	FRONT SIDE OF LEFT FENDER
	40 (7A-FE)	
ID	42	LEFT KICK PANEL


○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E 1	38 (5S-FE)	ENGINE ROOM MAIN WIRE	E 4	38 (5S-FE)	ENGINE ROOM MAIN WIRE
	40 (7A-FE)			40 (7A-FE)	






ILLUMINATION



*1 : SEPARATE TYPE AMPLIFIER
 *2 : BUILT-IN TYPE AMPLIFIER





ILLUMINATION

SERVICE HINTS

TAILLIGHT RELAY

- 5-3 : CLOSED WITH THE LIGHT CONTROL SW AT **TAIL** OR **HEAD** POSITION
C11 LIGHT CONTROL SW [COMB. SW]
 14-16 : CLOSED WITH THE LIGHT CONTROL SW AT **TAIL** OR **HEAD** POSITION

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A16	32	H 8	33	R 3	C 33
C 4	32	I13	33	R 4	33
C 8	32	J 1	33	R 6	33
C11	32	J 2	33	S 4	A 33
G 3	32	O 6	33	S 6	B 33
G 4	32	R 2	A 33		
H 7	33		B 33		

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IA	20	ENGINE ROOM MAIN WIRE AND INPANE J/B (LEFT KICK PANEL)
IE	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
IF		
2A	26	ENGINE ROOM MAIN WIRE AND J/B NO.2 (ENGINE COMPARTMENT LEFT)
3A	24	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)
3B		
3C		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
ID1	42	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)
IK1	44	INSTRUMENT PANEL WIRE AND FLOOR NO.3 WIRE (BEHIND THE RADIO AND PLAYER)
IK2		

▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
ID	42	LEFT KICK PANEL
IE	42	INSTRUMENT PANEL BRACE LH

○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I12	44	COWL WIRE			

*1 : SEPARATE TYPE AMPLIFIER

*2 : BUILT-IN TYPE AMPLIFIER


A16




C 4



C 8 BLUE



C11



G 3




G 4 BLACK




H 7 BLACK




H 8 ORANGE



I13




J 1




(HINT:SEE PAGE 7)

J 2




(HINT:SEE PAGE 7)


O 6 BLUE




(*1) R 2 (A)



(*2) R 2 (B) BLUE



R 3 (C) BLUE




R 4




R 6 BLACK



S 4 (A)




S 6 (B) BLUE






INTERIOR LIGHT



- *1 : W/ MOON ROOF
- *2 : W/O MOON ROOF
- *3 : L/B
- *4 : C/P, CONVERTIBLE
- *5 : CONVERTIBLE
- *6 : L/B, C/P





INTERIOR LIGHT

SERVICE HINTS

INTEGRATION RELAY

- 1-GROUND : ALWAYS APPROX. 12 VOLTS
- 6-GROUND : CONTINUITY WITH THE LH DOOR OPEN
- 4-GROUND : CONTINUITY WITH THE RH DOOR OPEN

D10, D11 DOOR COURTESY SW LH, RH

- 1-GROUND : CLOSED WITH THE DOOR OPEN

L 3 LUGGAGE COMPARTMENT LIGHT SW

- 1-GROUND : CLOSED WITH THE LUGGAGE COMPARTMENT DOOR OPEN

: PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE	
C 9	32	D10	36 (CONVERTIBLE)	L 3	34 (L/B), 35 (C/P)	
D 4	32	D11	34 (L/B), 35 (C/P)		36 (CONVERTIBLE)	
D 6	32		I11	33	M 3	34 (L/B), 35 (C/P)
D 8	34 (L/B), 35 (C/P)	J 1	33	P 4	A	36 (CONVERTIBLE)
	36 (CONVERTIBLE)					
D 9	34 (L/B), 35 (C/P)	L 2	34 (L/B), 35 (C/P)	P10	B	36 (CONVERTIBLE)
	36 (CONVERTIBLE)					
D10	34 (L/B), 35 (C/P)					

: RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
ID	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
IE		
IF		
IH		
1A	22	ENGINE ROOM MAIN WIRE AND J/B NO.1 (LEFT KICK PANEL)
1C	22	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT KICK PANEL)
1D		
1E		
1F	22	FLOOR WIRE AND J/B NO.1 (LEFT KICK PANEL)
1H	22	ROOF WIRE AND J/B NO.1 (LEFT KICK PANEL)
1J	22	COWL WIRE AND J/B NO.1 (LEFT KICK PANEL)
2A	26	ENGINE ROOM MAIN WIRE AND J/B NO.2 (ENGINE COMPARTMENT LEFT)
2B		
3A	24	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)
3C		

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IE2	42	FRONT DOOR LH WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IG1	42	INSTRUMENT PANEL WIRE AND FLOOR WIRE (LEFT KICK PANEL)
IN2	44	FRONT DOOR RH WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)
BQ1	46 (L/B)	FLOOR WIRE AND LUGGAGE ROOM WIRE (LUGGAGE ROOM LEFT)
	48 (C/P)	
	50 (CONVERTIBLE)	
BQ2	46 (L/B)	

: GROUND POINTS


CODE	SEE PAGE	GROUND POINTS LOCATION
ID	42	LEFT KICK PANEL
IE	42	INSTRUMENT PANEL BRACE LH
IF	42	R/B NO.4 SET BOLT



: SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I 1	44	COWL WIRE	B 4	50 (CONVERTIBLE)	ROOF WIRE
I17	44	FLOOR WIRE	B 9	46 (L/B)	LUGGAGE ROOM WIRE

C 9



D 4



D 6



D 8 GRAY



D 9 GRAY




D10




D11



I11




J 1



(HINT:SEE PAGE 7)

J 9




(HINT:SEE PAGE 7)

(*3) L 2



(*5) L 2



(C/P) L 2




L 3 GRAY



(*1) M 3




(*2) P 3



P 4 (A)



P 5 (A)




P10 (B)




P11 (B)





*1 : W/ MOON ROOF *4 : C/P, CONVERTIBLE
 *2 : W/O MOON ROOF *5 : CONVERTIBLE
 *3 : L/B



TAILLIGHT







TAILLIGHT

SERVICE HINTS

TAILLIGHT RELAY

5-3 : CLOSED WITH THE LIGHT CONTROL SW AT TAIL OR HEAD POSITION

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C11	32	I13	33	R7	37 (CONVERTIBLE)
F3	28 (5S-FE), 30 (7A-FE)	J1	33	R8	34 (L/B), (35 (C/P)
F4	28 (5S-FE), 30 (7A-FE)	L1	34 (L/B), (35 (C/P)		37 (CONVERTIBLE)
F5	28 (5S-FE), 30 (7A-FE)		36 (CONVERTIBLE)		
F6	28 (5S-FE), 30 (7A-FE)	R7	34 (L/B), 35 (C/P)		

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IA	20	ENGINE ROOM MAIN WIRE AND INPANE J/B (LEFT KICK PANEL)
ID	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
IE		
IF		
1A	22	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1C	22	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1F	22	FLOOR WIRE AND J/B NO. 1 (LEFT KICK PANEL)
2A	26	ENGINE ROOM MAIN WIRE AND J/B NO.2 (ENGINE COMPARTMENT LEFT)
3C	24	INSTRUMENT PANEL WIRE AND J/B NO. 3 (BEHIND THE INSTRUMENT PANEL CENTER)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
ID1	42 (C/P)	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)
BQ1	46 (L/B)	FLOOR WIRE AND LUGGAGE ROOM WIRE (LUGGAGE ROOM LEFT)
	48 (C/P)	
	50 (CONVERTIBLE)	


▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EA	38 (5S-FE)	FRONT SIDE OF RIGHT FENDER
	40 (7A-FE)	
EB	38 (5S-FE)	FRONT SIDE OF LEFT FENDER
	40 (7A-FE)	
ID	42	LEFT KICK PANEL
IE	42	INSTRUMENT PANEL BRACE LH
BK	46 (L/B)	BACK DOOR CENTER
	48 (C/P)	
	50 (CONVERTIBLE)	

○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E1	38 (5S-FE)	ENGINE ROOM MAIN WIRE	B10	46 (L/B)	LUGGAGE ROOM WIRE
	40 (7A-FE)		B12	48 (C/P)	
E4	38 (5S-FE)			50 (CONVERTIBLE)	
	40 (7A-FE)				

C11




F 3 BROWN




F 4 BROWN




F 5 GRAY




F 6 GRAY



I13




J 1




(HINT:SEE PAGE 7)


L 1



R 7



R 8






STOP LIGHT

FROM POWER SOURCE SYSTEM (SEE PAGE 62)

*1 : L/B
*2 : C/P, CONVERTIBLE



SERVICE HINTS

S7 STOP LIGHT SW

2-1 : CLOSED WITH THE BRAKE PEDAL DEPRESSED

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
H 9	34 (L/B), 35 (C/P)	R 7	34 (L/B), 35 (C/P)	R 8	37 (CONVERTIBLE)
	36 (CONVERTIBLE)		37 (CONVERTIBLE)	S 7	33
J 2	33	R 8	34 (L/B), 35 (C/P)		

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IF	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
1E	22	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT KICK PANEL)
1F	22	FLOOR WIRE AND J/B NO.1 (LEFT KICK PANEL)
1J	22	COWL WIRE AND J/B NO.1 (LEFT KICK PANEL)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
ID1	42	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)
BO1	46 (L/B)	BACK DOOR NO.1 WIRE AND FLOOR WIRE (BACK DOOR UPPER LEFT)
BP1	46 (L/B)	BACK DOOR NO.2 WIRE AND BACK DOOR NO.1 WIRE (BACK DOOR UPPER LEFT)
BQ1	46 (L/B)	FLOOR WIRE AND LUGGAGE ROOM WIRE (LUGGAGE ROOM LEFT)
	48 (C/P)	
	50 (CONVERTIBLE)	


▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
BH	46 (L/B)	UNDER THE LEFT CENTER PILLAR
	48 (C/P)	
	50 (CONVERTIBLE)	
BK	46 (L/B)	BACK DOOR CENTER
	48 (C/P)	
	50 (CONVERTIBLE)	
BM	46 (L/B)	BACK DOOR RIGHT

○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
B 8	46 (L/B)	FLOOR WIRE	B12	48 (C/P)	LUGGAGE ROOM WIRE
	48 (C/P)			50 (CONVERTIBLE)	
B10	46 (L/B)	LUGGAGE ROOM WIRE	B16	46 (L/B)	BACK DOOR NO.2 WIRE
B11	50 (CONVERTIBLE)	FLOOR WIRE			

(L/B) H 9




(C/P) H 9



(CONVERTIBLE) H 9




J 2




(HINT:SEE PAGE 7)


R 7




R 8



(W/ CRUISE CONTROL) S 7




(W/O CRUISE CONTROL) S 7





BACK-UP LIGHT

FROM POWER SOURCE SYSTEM (SEE PAGE 62)



SERVICE HINTS

P 1 BACK-UP LIGHT SW [PARK/NEUTRAL POSITION SW] (A/T)

2-8 : CLOSED WITH THE SHIFT LEVER AT R POSITION

B 1 BACK-UP LIGHT SW (M/T)

2-1 : CLOSED WITH THE SHIFT LEVER IN R POSITION

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
B 1	28 (5S-FE), 30 (7A-FE)	R 7	34 (L/B), 35 (C/P)	R 8	34 (L/B), 35 (C/P)
P 1	29 (5S-FE), 31 (7A-FE)		37 (CONVERTIBLE)		37 (CONVERTIBLE)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IE	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
3C	24	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IG1	42	INSTRUMENT PANEL WIRE AND FLOOR WIRE (LEFT KICK PANEL)
II1	44	ENGINE WIRE AND INSTRUMENT PANEL WIRE (NEAR THE ENGINE CONTROL MODULE)
BQ1	46 (L/B)	FLOOR WIRE AND LUGGAGE ROOM WIRE (LUGGAGE ROOM LEFT)
	48 (C/P)	
	50 (CONVERTIBLE)	


▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
BK	46 (L/B)	BACK DOOR CENTER
	48 (C/P)	
	50 (CONVERTIBLE)	


○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
B10	46 (L/B)	LUGGAGE ROOM WIRE	B12	50 (CONVERTIBLE)	LUGGAGE ROOM WIRE
B12	48 (C/P)				


B 1 GRAY




P 1 GRAY



R 7




R 8





LIGHT AUTO TURN OFF



SYSTEM OUTLINE

WITH THE IGNITION SW TURNED ON, CURRENT FLOWS TO **TERMINAL 7** OF THE INTEGRATION RELAY THROUGH THE **GAUGE** FUSE.

VOLTAGE IS APPLIED AT ALL TIMES TO **TERMINAL (A) 2** OF THE INTEGRATION RELAY THROUGH THE TAILLIGHT RELAY (COIL SIDE), AND TO **TERMINAL (A) 3** THROUGH THE HEAD RELAY (COIL SIDE).

1. NORMAL LIGHTING OPERATION

* TURN TAILLIGHT ON

WITH LIGHT CONTROL SW TURNED TO **TAIL** POSITION, A SIGNAL IS INPUT TO **TERMINAL (A) 1** OF THE INTEGRATION RELAY. DUE TO THIS SIGNAL, CURRENT FROM **TERMINAL (A) 2** OF THE RELAY FLOWS TO **TERMINAL (A) 1** → **TERMINAL 14** OF THE LIGHT CONTROL SW → **TERMINAL 16** → **GROUND**, AND THE TAILLIGHT RELAY CAUSES TAILLIGHT TO TURN ON.

* TURN HEADLIGHT ON

WITH LIGHT CONTROL SW TURNED TO **HEAD** POSITION, A SIGNAL IS INPUT TO **TERMINAL (A) 4** OF THE INTEGRATION RELAY. DUE TO THIS SIGNAL, CURRENT FROM **TERMINAL (A) 3** OF THE RELAY FLOWS TO **TERMINAL (A) 4** → **TERMINAL 13** OF THE LIGHT CONTROL SW → **TERMINAL 16** → **GROUND** IN THE HEADLIGHT CIRCUIT, AND HEADLIGHT RELAY CAUSES HEADLIGHTS TO TURN ON.

2. LIGHT AUTO TURN OFF OPERATION

WITH LIGHT ON AND THE IGNITION SW TURNED OFF (INPUT SIGNAL GOES TO **TERMINAL 7** OF THE RELAY), WHEN THE DRIVER'S DOOR IS OPENED (INPUT SIGNAL GOES TO **TERMINAL 6** OF THE RELAY), THE RELAY OPERATES AND CURRENT IS CUT OFF FROM **TERMINAL (A) 2** OF THE RELAY TO **TERMINAL (A) 1** IN TAILLIGHT CIRCUIT AND FROM **TERMINAL (A) 3** TO **TERMINAL (A) 4** IN HEADLIGHT CIRCUIT.

AS A RESULT, ALL LIGHTS ARE TURNED OFF AUTOMATICALLY.

SERVICE HINTS

HEAD RELAY

- 2-1 : CLOSED WITH THE LIGHT CONTROL SW AT **HEAD** POSITION OR THE DIMMER SW AT **FLASH** POSITION (USA)
CLOSED WITH THE ENGINE RUNNING AND THE PARKING BRAKE LEVER RELEASED,
THE LIGHT CONTROL SW AT **HEAD** POSITION OR THE DIMMER SW AT **FLASH** POSITION (CANADA)

TAILLIGHT RELAY

- 5-3 : CLOSED WITH THE LIGHT CONTROL SW AT **TAIL** OR **HEAD** POSITION

D10 DOOR COURTESY SW LH

- 1-GROUND : CLOSED WITH THE LH DOOR OPEN

113 (A) LIGHT AUTO CUT RELAY [INTEGRATION RELAY]

- 7-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION
- 6-GROUND : CONTINUITY WITH THE LH DOOR OPEN
- 10-GROUND : ALWAYS CONTINUITY

- (A) 2-GROUND : ALWAYS APPROX. 12 VOLTS

- (A) 3-GROUND : ALWAYS APPROX. 12 VOLTS

- (A) 4-GROUND : CONTINUITY WITH THE LIGHT CONTROL SW AT **HEAD** POSITION

- (A) 1-GROUND : CONTINUITY WITH THE LIGHT CONTROL SW AT **TAIL** OR **HEAD** POSITION



LIGHT AUTO TURN OFF

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C11	32	D10	36 (CONVERTIBLE)	J1	33
D10	34 (L/B), 35 (C/P)	I13	A		
			33		

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR



CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IA	20	ENGINE ROOM MAIN WIRE AND INPANE J/B (LEFT KICK PANEL)
ID	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
IE		
IF		
1A	22	ENGINE ROOM MAIN WIRE AND J/B NO.1 (LEFT KICK PANEL)
1C	22	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT KICK PANEL)
2A	26	ENGINE ROOM MAIN WIRE AND J/B NO.2 (ENGINE COMPARTMENT LEFT)
2B		
3C	24	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IC2	42	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
ID1	42	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)
IG1	42	INSTRUMENT PANEL WIRE AND FLOOR WIRE (LEFT KICK PANEL)

▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
ID	42	LEFT KICK PANEL
IE	42	INSTRUMENT PANEL BRACE LH





POWER WINDOW

SYSTEM OUTLINE

CURRENT ALWAYS THROUGH THE **POWER FUSE** FLOWS TO **TERMINAL 5** OF THE POWER MAIN RELAY. WITH THE IGNITION SW TURNED ON, CURRENT FLOWS THROUGH THE **GAUGE FUSE** TO **TERMINAL 1** OF THE POWER MAIN RELAY → **TERMINAL 2** → TO **GROUND**. THIS ACTIVATES THE RELAY, AND CURRENT FLOWS FROM **TERMINAL 3** OF THE POWER MAIN RELAY → **TERMINAL 7** OF THE POWER WINDOW MASTER SW, TO **TERMINAL 4** OF THE POWER WINDOW CONTROL SW (PASSENGER'S SIDE) AND TO **TERMINAL 4** OF THE QUARTER POWER WINDOW SW LH, RH (CONVERTIBLE).

1. MANUAL OPERATION BY POWER WINDOW SW (DRIVER'S WINDOW)

WITH THE IGNITION SW TURNED ON AND WITH THE POWER WINDOW MASTER SW IN **UP** POSITION, CURRENT TO **TERMINAL 7** OF THE POWER WINDOW MASTER SW FLOWS TO **TERMINAL 8** OF THE MASTER SW → **TERMINAL 1** OF THE POWER WINDOW MOTOR LH → MOTOR → **TERMINAL 2** → **TERMINAL 6** OF THE MASTER SW → **TERMINAL 9** → **GROUND**, CAUSING THE POWER WINDOW MOTOR TO ROTATE IN THE UP DIRECTION. THE WINDOW ASCENDS ONLY WHILE THE SW IS BEING PUSHED. IN DOWN OPERATION, THE FLOW OF CURRENT FROM **TERMINAL 7** OF THE POWER WINDOW MASTER SW TO **TERMINAL 6** OF THE MASTER SW CAUSES THE FLOW OF CURRENT FROM **TERMINAL 2** OF THE MOTOR → MOTOR → **TERMINAL 1** → **TERMINAL 8** OF THE MASTER SW → **TERMINAL 9** → **GROUND**, FLOWING IN THE OPPOSITE DIRECTION TO MANUAL UP OPERATION, CAUSING THE MOTOR TO ROTATE IN REVERSE AND LOWERING THE WINDOW.

2. AUTO DOWN OPERATION

WITH THE IGNITION SW ON AND THE DRIVER'S SW OF THE POWER WINDOW MASTER SW IN DOWN POSITION, CURRENT TO **TERMINAL 7** OF THE MASTER SW FLOWS TO **TERMINAL 6** OF THE MASTER SW → **TERMINAL 2** OF THE POWER WINDOW MOTOR LH → MOTOR → **TERMINAL 1** → **TERMINAL 8** OF THE MASTER SW → **TERMINAL 9** → **GROUND**, CAUSING THE MOTOR TO ROTATE TOWARDS THE DOWN SIDE. THEN THE SOLENOID IN THE MASTER SW IS ACTIVATED AND IT LOCKS THE DRIVER'S SW BEING PUSHED, CAUSING THE MOTOR TO CONTINUE TO ROTATE IN AUTO DOWN OPERATION.

WHEN THE WINDOW HAS COMPLETELY DESCENDED, THE CURRENT FLOWING BETWEEN **TERMINAL 8** OF THE MASTER SW AND **TERMINAL 9** INCREASES. AS A RESULT, THE SOLENOID STOPS OPERATING, THE DRIVER'S SW TURNS OFF AND THE FLOW FROM **TERMINAL 7** OF THE MASTER SW TO **TERMINAL 6** IS CUT OFF, STOPPING THE MOTOR SO THAT AUTO STOP OCCURS.

3. STOPPING OF AUTO DOWN AT DRIVER'S WINDOW

WHEN THE DRIVER'S SW IS PUSHED TO THE UP SIDE DURING AUTO **DOWN** OPERATION, A GROUND CIRCUIT OPENS IN THE MASTER SW AND CURRENT DOES NOT FLOW FROM **TERMINAL 8** OF THE MASTER SW TO **TERMINAL 9**, SO THE MOTOR STOPS, CAUSING AUTO DOWN OPERATION TO STOP. IF THE DRIVER'S SW IS PUSHED CONTINUOUSLY, THE MOTOR ROTATES IN THE UP DIRECTION IN MANUAL UP OPERATION.

4. MANUAL OPERATION BY POWER WINDOW SW (PASSENGER'S WINDOW)

WITH POWER WINDOW CONTROL SW (PASSENGER'S SIDE) PUSHED TO THE UP SIDE, CURRENT FROM **TERMINAL 4** OF THE POWER WINDOW CONTROL SW FLOWS TO **TERMINAL 1** OF THE POWER WINDOW CONTROL SW → **TERMINAL 2** OF THE WINDOW MOTOR RH → MOTOR → **TERMINAL 1** → **TERMINAL 3** OF THE POWER WINDOW CONTROL SW → **TERMINAL 5** → **TERMINAL 4** OF THE POWER WINDOW MASTER SW → WINDOW LOCK SW → **TERMINAL 9** → **GROUND**, CAUSING THE POWER WINDOW MOTOR (PASSENGER'S SIDE) TO ROTATE IN THE UP DIRECTION. UP OPERATION CONTINUES ONLY WHILE THE POWER WINDOW SW IS PUSHED TO THE UP SIDE. WHEN THE WINDOW DESCENDS, CURRENT TO THE MOTOR FLOWS IN THE OPPOSITE DIRECTION, FROM **TERMINAL 1** TO MOTOR → **TERMINAL 2**, AND THE MOTOR ROTATES IN REVERSE. WHEN THE WINDOW LOCK SW IS PUSHED OUT TO THE NORMAL SIDE, THE GROUND CIRCUIT TO THE PASSENGER'S WINDOW BECOMES OPEN.

AS A RESULT, EVEN IF OPEN/CLOSE OPERATION OF THE PASSENGER'S WINDOW IS TRIED, CURRENT FROM **TERMINAL 7** OF THE POWER WINDOW MASTER SW IS NOT GROUNDED AND THE MOTOR DOES NOT ROTATE, SO THE PASSENGER'S WINDOW CANNOT BE OPERATED AND WINDOW LOCK OCCURS.

5. KEY OFF POWER WINDOW OPERATION

WITH THE IGNITION SW TURNED FROM ON TO OFF, THE DOOR LOCK ECU OPERATES AND CURRENT FLOWS FROM THE **DOOR FUSE** TO **TERMINAL 8** OF THE DOOR LOCK CONTROL RELAY → **TERMINAL 15** → **TERMINAL 1** OF THE POWER MAIN RELAY → **TERMINAL 2** → **GROUND** FOR ABOUT **60** SECONDS. THE SAME AS NORMAL OPERATION, CURRENT FLOWS FROM THE POWER FUSE TO **TERMINAL 5** OF THE POWER MAIN RELAY → **TERMINAL 3** → **TERMINAL 7** OF THE POWER WINDOW MASTER SW AND **TERMINAL 4** OF POWER WINDOW CONTROL SW (PASSENGER'S SIDE). AS A RESULT, FOR ABOUT **60** SECONDS AFTER THE IGNITION SW IS TURNED OFF, IT IS POSSIBLE TO RAISE AND LOWER THE POWER WINDOW BY THE FUNCTIONING OF THIS RELAY. ALSO, BY OPENING THE DOOR (DOOR COURTESY SW ON) WITHIN ABOUT **60** SECONDS AFTER TURNING THE IGNITION SW TO OFF, A SIGNAL IS INPUT TO **TERMINAL 2, 14** OF DOOR LOCK CONTROL RELAY. AS A RESULT, THE ECU TURNS OFF, AND UP AND DOWN OF THE MOVEMENT OF THE WINDOW STOPS.


6. MANUAL OPERATION BY QUARTER WINDOW SW (CONVERTIBLE)

WITH THE QUARTER POWER WINDOW SW PUSHED TO UP SIDE, CURRENT FROM **TERMINAL 4** OF THE QUARTER POWER WINDOW SW LH, RH FLOWS TO **TERMINAL 2** (LH), **3** (RH) → **TERMINAL 2** OF THE QUARTER POWER WINDOW MOTOR → MOTOR → **TERMINAL 1** OF THE MOTOR → **TERMINAL 1** (LH), **6** (RH) OF THE QUARTER POWER WINDOW SW → **TERMINAL 3** (LH), **1** (RH) → **TERMINAL 3** OF THE POWER WINDOW MASTER SW → WINDOW LOCK SW → **TERMINAL 9** → **GROUND**, CAUSING THE QUARTER POWER WINDOW MOTOR TO ROTATE IN THE UP DIRECTION. UP OPERATION CONTINUES ONLY WHILE THE QUARTER POWER WINDOW SW IS PUSHED TO UP SIDE. WHEN THE WINDOW DESCENDS, THE CURRENT FLOW TO THE MOTOR FLOWS IN THE OPPOSITE DIRECTION, FROM **TERMINAL 1** OF THE MOTOR → MOTOR → **TERMINAL 2**, AND THE MOTOR ROTATES IN REVERSE.


WHEN THE WINDOW LOCK SW IS PUSHED OUT TO THE NORMAL SIDE, THE **GROUND** CIRCUIT TO THE QUARTER POWER WINDOW BECOMES OPEN. AS A RESULT, EVEN IF OPEN/CLOSE OPERATION OF QUARTER WINDOW IS TRIED, CURRENT FROM **TERMINAL 3** (LH), **1** (RH) OF THE QUARTER POWER WINDOW SW IS NOT GROUNDED AND THE MOTOR DOES NOT ROTATE, SO THE QUARTER POWER WINDOW CAN NOT BE OPERATED AND WINDOW LOCK OCCURS.



POWER WINDOW



- *1 : CONVERTIBLE
- *2 : W/ DOOR LOCK CONTROL
- *3 : W/O DOOR LOCK CONTROL
- *4 : L/B, C/P





POWER WINDOW

SERVICE HINTS

D 7 DOOR LOCK CONTROL RELAY

- 8-GROUND : ALWAYS APPROX. 12 VOLTS
- 16-GROUND : ALWAYS CONTINUITY
- 1-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION
- 2-GROUND : CONTINUITY WITH THE LH DOOR OPEN
- 14-GROUND : CONTINUITY WITH THE RH DOOR OPEN
- 15-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW ON AND STAYS AT 12 VOLTS FOR 60 SECONDS AFTER THE IGNITION SW IS TURNED OFF, BUT IF THE DOOR IS OPENED IN THIS 60 SECOND PERIOD, VOLTAGE WILL DROP TO 0 VOLTS

D10, D11 DOOR COURTESY SW LH, RH

- 1-GROUND : CLOSED WITH THE DOOR OPEN

P 6 POWER WINDOW CONTROL SW (PASSENGER'S SIDE)

- 4-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW ON AND STAYS AT 12 VOLTS FOR 60 SECONDS AFTER THE IGNITION SW IS TURNED OFF, BUT IF THE DOOR IS OPENED IN THIS 60 SECONDS PERIOD, VOLTAGE WILL DROP TO 0 VOLTS

P 7 POWER WINDOW MASTER SW

- 9-GROUND : ALWAYS CONTINUITY
- 7-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW ON AND STAYS AT 12 VOLTS FOR 60 SECONDS AFTER THE IGNITION SW IS TURNED OFF, BUT IF THE DOOR IS OPENED IN THIS 60 SECONDS PERIOD, VOLTAGE WILL DROP TO 0 VOLTS
- 8-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION AND THE MASTER SW AT **UP** POSITION
- 6-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION AND THE MASTER SW AT **DOWN** OR **AUTO DOWN** POSITION

Q 1, Q 2 QUARTER POWER WINDOW SW LH, RH

- 4-GROUND : APPROX. 12 VOLTS WITH IGNITION SW ON AND STAYS AT 12 VOLTS FOR 60 SECONDS AFTER THE IGNITION SW IS TURNED OFF, BUT IF A DOOR IS OPENED IN THIS 60 SECONDS PERIOD, VOLTAGE WILL DROP TO 0 VOLTS

WINDOW LOCK SW

- OPEN WTH THE WINDOW LOCK SW AT **NORMAL** POSITION

: PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
D 5	32	P 6	34 (L/B), 35 (C/P)	P 9	34 (L/B), 35 (C/P)
D 7	32		36 (CONVERTIBLE)		36 (CONVERTIBLE)
D10	34 (L/B), 35 (C/P)	P 7	34 (L/B), 35 (C/P)	Q 1	33 (CONVERTIBLE)
	36 (CONVERTIBLE)		36 (CONVERTIBLE)		Q 2
D11	34 (L/B), 35 (C/P)	P 8	34 (L/B), 35 (C/P)	Q 3	37 (CONVERTIBLE)
	36 (CONVERTIBLE)		36 (CONVERTIBLE)		Q 4

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
ID	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
IE		
IF		
IG		
1C	22	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT KICK PANEL)
1E		
3A	24	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)
3C		

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IE1	42	FRONT DOOR LH WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IE2		
IG1	42	INSTRUMENT PANEL WIRE AND FLOOR WIRE (LEFT KICK PANEL)
IH1	42	FLOOR WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)
IN1	44	FRONT DOOR RH WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)

▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	42	INSTRUMENT PANEL BRACE LH


○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
13	44	INSTRUMENT PANEL WIRE	118	44	INSTRUMENT PANEL WIRE
14					

D 5 BLACK



D 7




D10




D11




P 6



(L/B, C/P) P 7 BLUE



(CONVERTIBLE) P 7 BLUE



P 8




P 9




Q 1




Q 2 BLACK



Q 3 BLACK




Q 4 BLACK






DOOR LOCK CONTROL



FROM POWER SOURCE SYSTEM (SEE PAGE 62)

*1 : CONVERTIBLE
*2 : L/B, C/P





DOOR LOCK CONTROL

SYSTEM OUTLINE

CURRENT ALWAYS FLOWS TO **TERMINAL 8** OF THE DOOR LOCK CONTROL RELAY THROUGH THE **DOOR FUSE**.
WHEN THE IGNITION SW TURNED ON, CURRENT FLOWS THROUGH THE **GAUGE FUSE** TO **TERMINAL 1** OF THE RELAY.

1. MANUAL LOCK OPERATION

WHEN THE DOOR CONTROL SW OR KEY SW ARE PUSHED TO **LOCK** POSITION, A LOCK SIGNAL IS INPUT TO **TERMINAL 10, 12** (FOR KEY SW) OF THE DOOR LOCK CONTROL RELAY, CAUSING THE RELAY TO FUNCTION. CURRENT FLOWS FROM **TERMINAL 8** OF THE RELAY TO **TERMINAL 4** → **TERMINAL 7** OF THE DOOR LOCK MOTORS → **TERMINAL 5** → **TERMINAL 3** OF THE RELAY → **TERMINAL 16** → **GROUND** AND THE DOOR LOCK MOTOR CAUSES THE DOOR TO LOCK.

2. MANUAL UNLOCK OPERATION

WHEN THE DOOR LOCK CONTROL SW OR KEY SW ARE PUSHED TO **UNLOCK** POSITION, AN UNLOCK SIGNAL IS INPUT TO **TERMINAL 11, 9** (FOR KEY SW LH) OR **13** (FOR KEY SW RH) OF THE DOOR LOCK CONTROL RELAY, CAUSING THE RELAY TO FUNCTION. CURRENT FLOWS FROM **TERMINAL 8** OF THE RELAY TO **TERMINAL 3** → **TERMINAL 5** OF THE DOOR LOCK MOTORS → **TERMINAL 7** → **TERMINAL 4** OF THE RELAY → **TERMINAL 16** → **GROUND** AND THE DOOR LOCK MOTOR CAUSES THE DOOR TO UNLOCK.

WHEN UNLOCK OPERATION OCCURS USING THE LH DOOR KEY SW, PERFORMING THE UNLOCK OPERATION ONCE UNLOCKS ONLY THE DRIVER'S DOOR. TO UNLOCK ALL THE OTHER DOORS TOGETHER, UNLOCK OPERATION MUST BE PERFORMED AGAIN WITHIN 3 SECONDS OF THE FIRST OPERATION.

3. IGNITION KEY REMINDER OPERATION

* OPERATION OF DOOR LOCK BUTTON (OPERATION OF DOOR LOCK MOTORS)

WHEN THE IGNITION KEY IS IN THE CYLINDER (UNLOCK WARNING SW ON) AND THE DOOR IS OPENED AND LOCKED USING DOOR LOCK BUTTON (DOOR LOCK MOTOR), THE DOOR IS LOCKED ONCE BUT EACH DOOR IS UNLOCKED SOON BY THE OPERATION OF THE RELAY. AS A RESULT OF THE RELAY ACTIVATION, CURRENT FLOWS FROM **TERMINAL 8** OF THE RELAY TO **TERMINAL 3** → **TERMINAL 5** OF THE DOOR LOCK MOTORS → **TERMINAL 7** → **TERMINAL 4** OF THE ECU → **TERMINAL 16** → **GROUND**, CAUSING ALL THE DOORS TO UNLOCK. THE SAME APPLIES TO OPERATION OF THE DOOR LOCK CONTROL SW AND THE DOOR LOCK KEY SW.

* KEYLESS LOCK OPERATION

WHEN THE IGNITION KEY IS STILL INSERTED IN THE CYLINDER (UNLOCK WARNING SW ON), THE DOOR IS OPENED AND UNLOCK OPERATION IS PREVENTED BY KEEPING THE DOOR LOCK BUTTON PRESSED TO THE LOCK SIDE, THE DOOR IS KEPT IN THE LOCK CONDITION. IF THE DOOR IS THEN CLOSED, A SIGNAL IS INPUT TO THE RELAY FROM THE DOOR COURTESY SW. THIS ACTIVATES THE RELAY AND EACH DOOR IS UNLOCKED.

SERVICE HINTS

D10, D11 DOOR COURTESY SW LH, RH

1-GROUND : CLOSED WITH THE DOOR OPEN

D13, D14 DOOR KEY LOCK AND UNLOCK SW LH, RH

1-2 : CLOSED WITH THE DOOR LOCK CYLINDER UNLOCKED WITH THE KEY

3-2 : CLOSED WITH THE DOOR LOCK CYLINDER LOCKED WITH THE KEY

D13, D14 DOOR LOCK MOTOR AND DOOR UNLOCK DETECTION SW LH, RH

4-6 : CLOSED WITH THE DOOR LOCK MOTOR AND DOOR UNLOCK DETECTION SW AT UNLOCK POSITION

U 1 UNLOCK WARNING SW

2-1 : CLOSED WITH THE IGNITION KEY IN THE CYLINDER

D 7 DOOR LOCK CONTROL RELAY

11-GROUND : CONTINUITY WITH THE DOOR LOCK CONTROL SW AT **UNLOCK** POSITION

10-GROUND : CONTINUITY WITH THE DOOR LOCK CONTROL SW AT **LOCK** POSITION

1-GROUND : APPROX. **12** VOLTS WITH THE IGNITION SW AT **ON** POSITION

7-GROUND : CONTINUITY WITH THE IGNITION KEY IN THE CYLINDER

6-GROUND : CONTINUITY WITH THE LH DOOR AT **UNLOCK** POSITION

5-GROUND : CONTINUITY WITH THE RH DOOR AT **UNLOCK** POSITION

9-GROUND : CONTINUITY WITH THE DOOR LOCK KEY SW LH AT **UNLOCK** POSITION

13-GROUND : CONTINUITY WITH THE DOOR LOCK KEY SW RH AT **UNLOCK** POSITION

12-GROUND : CONTINUITY WITH THE DOOR LOCK KEY SW AT **LOCK** POSITION

16-GROUND : ALWAYS CONTINUITY

8-GROUND : ALWAYS APPROX. **12** VOLTS

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
D 5	32	D12	34 (L/B), 35 (C/P)	J 7	33
D 7	32		36 (CONVERTIBLE)	J 8	33
D10	34 (L/B), 35 (C/P)	D13	34 (L/B), 35 (C/P)	P 7	34 (L/B), 35 (C/P)
	36 (CONVERTIBLE)		36 (CONVERTIBLE)		37 (CONVERTIBLE)
D11	34 (L/B), 35 (C/P)	D14	34 (L/B), 35 (C/P)	U 1	33
	36 (CONVERTIBLE)		36 (CONVERTIBLE)		

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IC	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
ID		
IE		
IF		
IG		
3A	24	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL)
3C		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IE1	42	FRONT DOOR LH WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IE2		
IG1	42	INSTRUMENT PANEL WIRE AND FLOOR WIRE (LEFT KICK PANEL)
IH1	42	FLOOR WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IN1	44	FRONT DOOR RH WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)

▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	42	INSTRUMENT PANEL BRACE LH


○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I 3	44	INSTRUMENT PANEL WIRE	B 2	50 (CONVERTIBLE)	FRONT DOOR LH WIRE
I 4			B 6	46 (L/B)	FRONT DOOR RH WIRE
B 2	48 (C/P)	48 (C/P)			
			50 (CONVERTIBLE)		

D 5 BLACK



D 7




D10




D11




D12




D13 GRAY



D14 GRAY




J 7




(HINT:SEE PAGE 7)

J 8 BLUE




(HINT:SEE PAGE 7)

(L/B, C/P) P 7 BLUE



(CONVERTIBLE) P 7 BLUE




U 1 GRAY





REMOTE CONTROL MIRROR (w/ POWER WINDOW)

FROM POWER SOURCE SYSTEM (SEE PAGE 62)



SERVICE HINTS

R16 REMOTE CONTROL MIRROR SW

- 1-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ACC** OR **ON** POSITION
- 3-4 ; CONTINUITY WITH THE OPERATION SW AT **UP** OR **LEFT** POSITION
- 9-4 : CONTINUITY WITH THE OPERATION SW AT **RIGHT** POSITION AND THE SELECT **SW** AT **LH** POSITION
- 10-4 : CONTINUITY WITH THE OPERATION SW AT **DOWN** POSITION AND THE SELECT **SW** AT **LH** POSITION
- 2-4 : CONTINUITY WITH THE OPERATION SW AT **RIGHT** POSITION AND THE SELECT **SW** AT **RH** POSITION
- 6-4 : CONTINUITY WITH THE OPERATION SW AT **DOWN** POSITION AND THE SELECT **SW** AT **RH** POSITION

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
R14	34 (L/B), 35 (C/P)	R15	34 (L/B), 35 (C/P)	R16	34 (L/B), 35 (C/P)
	37 (CONVERTIBLE)		37 (CONVERTIBLE)		37 (CONVERTIBLE)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
ID	20	INSTRUMENT BLOCK PANEL WIRE AND INPANE J/B (EFT JKICK PANEL)
1C	22	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1E		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IE2	42	FRONT DOOR LH WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IN2	44	FRONT DOOR RH WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)

▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	42	INSTRUMENT PANEL BRACE LH

○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
B3	46 (L/B)	FRONT DOOR LH WIRE	B3	50 (CONVERTIBLE)	FRONT DOOR LH WIRE
	48 (C/P)				


R14



R15




R16





REMOTE CONTROL MIRROR (w/o POWER WINDOW)

FROM POWER SOURCE SYSTEM (SEE PAGE 62)



SERVICE HINTS

R 5 REMOTE CONTROL MIRROR SW

3-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ACC** OR **ON** POSITION

8-7 : CONTINUITY WITH THE OPERATION SW AT **UP** OR **LEFT** POSITION

1-7 : CONTINUITY WITH THE OPERATION SW AT **RIGHT** POSITION AND THE SELECT SW AT **LH** POSITION

2-7 : CONTINUITY WITH THE OPERATION SW AT **DOWN** POSITION AND THE SELECT SW AT **LH** POSITION

5-7 : CONTINUITY WITH THE OPERATION SW AT **RIGHT** POSITION AND THE SELECT SW AT **RH** POSITION

10-7 : CONTINUITY WITH THE OPERATION SW AT **DOWN** POSITION AND THE SELECT SW AT **RH** POSITION

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
R 5	33	R14	34 (L/B), 35 (C/P)	R15	34 (L/B), 35 (C/P)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IE	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
3B	24	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)
3C		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IE2	42	FRONT DOOR LH WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IN2	44	FRONT DOOR RH WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)


▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	42	INSTRUMENT PANEL BRACE LH


○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I 3	44	INSTRUMENT PANEL WIRE	I 4	44	INSTRUMENT PANEL WIRE


R 5



R14



R15






FRONT WIPER AND WASHER

*1: W/ REAR WIPER

FROM POWER SOURCE SYSTEM (SEE PAGE 62)



WASHER									
OFF	OFF	<input type="checkbox"/>							
	MIST	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
INT	OFF	<input type="checkbox"/>			<input type="checkbox"/>				
	MIST	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
LOW	OFF	<input type="checkbox"/>					<input type="checkbox"/>		
	MIST	<input type="checkbox"/>	<input type="checkbox"/>				<input type="checkbox"/>	<input type="checkbox"/>	
HIGH	OFF	<input type="checkbox"/>						<input type="checkbox"/>	
	MIST	<input type="checkbox"/>	<input type="checkbox"/>					<input type="checkbox"/>	<input type="checkbox"/>

SYSTEM OUTLINE

WITH THE IGNITION SW TURNED ON, CURRENT FLOWS TO **TERMINAL 17** OF THE FRONT WIPER AND WASHER SW, **TERMINAL 2** OF THE WASHER MOTOR AND **TERMINAL 6** OF THE FRONT WIPER MOTOR THROUGH THE **WIPER FUSE**.

1. LOW SPEED POSITION

WITH THE WIPER SW TURNED TO **LOW** POSITION, CURRENT FLOWS FROM **TERMINAL 17** OF THE FRONT WIPER AND WASHER SW TO **TERMINAL 7** → **TERMINAL 3** OF THE FRONT WIPER MOTOR → WIPER MOTOR → **TERMINAL 1** → **GROUND**, CAUSING THE WIPER MOTOR TO RUN AT LOW SPEED.

2. HIGH SPEED POSITION

WITH THE WIPER SW TURNED TO **HIGH** POSITION, CURRENT FLOWS FROM **TERMINAL 17** OF THE FRONT WIPER AND WASHER SW TO **TERMINAL 8** → **TERMINAL 2** OF THE FRONT WIPER MOTOR → WIPER MOTOR → **TERMINAL 1** → **GROUND**, CAUSING THE WIPER MOTOR TO RUN AT HIGH SPEED.

3. INT POSITION

WITH THE WIPER SW TURNED TO **INT** POSITION, THE RELAY OPERATES AND THE CURRENT WHICH IS CONNECTED BY RELAY FUNCTION FLOWS FROM **TERMINAL 17** OF THE FRONT WIPER AND WASHER SW TO **TERMINAL 2** → **GROUND**. THIS OPERATES THE INTERMITTENT CIRCUIT AND CURRENT FLOWS FROM **TERMINAL 17** OF THE FRONT WIPER AND WASHER SW → **TERMINAL 7** → **TERMINAL 3** OF THE FRONT WIPER MOTOR → WIPER MOTOR → **TERMINAL 1** → **GROUND**, AND OPERATING THE WIPER.

THE INTERMITTENT OPERATION IS CONTROLLED BY A CONDENSER'S CHARGED AND DISCHARGED FUNCTION INSTALLED IN THE RELAY, AND THE INTERMITTENT TIME IS CONTROLLED BY A TIME CONTROL SW TO CHANGE THE CHARGING TIME OF THE CONDENSER.

4. MIST POSITION

WITH THE WIPER SW TURNED TO **MIST** POSITION, CURRENT FLOWS FROM **TERMINAL 17** OF THE FRONT WIPER AND WASHER SW TO FRONT WIPER MIST SW → **TERMINAL 2** → **GROUND**, AND CURRENT FLOWS FROM **TERMINAL 17** TO **TERMINAL 7** → **TERMINAL 3** OF THE FRONT WIPER MOTOR → WIPER MOTOR → **TERMINAL 1** → **GROUND**, CAUSING THE WIPER MOTOR TO RUN AT LOW SPEED.

5. WASHER CONTINUITY OPERATION

WITH THE WASHER SW PUSHED TO ON, CURRENT FLOWS FROM **TERMINAL 2** OF THE WASHER MOTOR TO **TERMINAL 1** → **TERMINAL 11** OF THE FRONT WIPER AND WASHER SW → **TERMINAL 2** → **GROUND**, CAUSING THE WASHER MOTOR TO RUN, AND THE WINDOW WASHER EMITS A WATER SPRAY. THIS CAUSES CURRENT TO FLOW TO WASHER CONTINUITY OPERATION CIRCUIT IN **TERMINAL 17** OF THE FRONT WIPER AND WASHER SW → **TERMINAL 7** → **TERMINAL 3** OF THE FRONT WIPER MOTOR → WIPER MOTOR → **TERMINAL 1** → **GROUND**, OPERATING THE WIPER.

SERVICE HINTS

C13 FRONT WIPER AND WASHER SW [COMB. SW]

2-GROUND : ALWAYS CONTINUITY

17-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION

7-GROUND : APPROX. 12 VOLTS WITH WIPER AND WASHER SW AT **LOW** OR **MIST** POSITION

APPROX. 12 VOLTS 2 TO 12 SECONDS INTERMITTENTLY WITH THE WIPER AND WASHER SW AT **INT** POSITION

16-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW ON UNLESS THE WIPER MOTOR AT **STOP** POSITION

8-GROUND : APPROX. 12 VOLTS WITH THE WIPER AND WASHER SW AT **HIGH** POSITION

F7 FRONT WIPER MOTOR

6-5 : CLOSED UNLESS THE WIPER MOTOR AT **STOP** POSITION



FRONT WIPER AND WASHER

*2 :W/CRUISE CONTROL
*3 :W/O CRUISE CONTROL

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C13	32	J1	33	W1	29 (5S-FE), 31 (7A-FE)
F7	28 (5S-FE), 30 (7A-FE)	J9	33		

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
ID	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
1A	22	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1C	22	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1J	22	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IC3	42	ENGINE ROOM MAIN WIRE AND COWL WIRE (INSIDE OF R/B NO. 4)


▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
ID	42	LEFT KICK PANEL
IF	42	R/B NO. 4 SET BOLT


○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E2	38 (5S-FE)	ENGINE ROOM MAIN WIRE	E2	40 (7A-FE)	ENGINE ROOM MAIN WIRE


(•2) C13 BLACK



(•3) C13 BLACK



F 7 BLACK




J 1



(HINT:SEE PAGE 7)

J 9




(HINT:SEE PAGE 7)

W 1 GRAY







(#1) C13 BLACK



(#2) C13 BLACK



J 1




(HINT:SEE PAGE 7)

R13




W 1 GRAY



#1 : W/ CRUISE CONTROL
#2 : W/O CRUISE CONTROL



REAR WIPER AND WASHER



SYSTEM OUTLINE

WHEN THE IGNITION SW IS TURNED ON, CURRENT FLOWS TO **TERMINAL 2** OF THE WASHER MOTOR, **TERMINAL 1** OF THE REAR WIPER MOTOR AND RELAY THROUGH THE **WIPER FUSE**.

1. REAR WIPER NORMAL OPERATION

WITH THE IGNITION SW TURNED ON AND REAR WIPER AND WASHER SW TURNED ON, CURRENT TO **TERMINAL 1** OF THE REAR WIPER RELAY FLOWS TO **TERMINAL 3** OF THE RELAY → **TERMINAL 10** OF THE REAR WIPER AND WASHER SW → **TERMINAL 2** → **GROUND**. THUS, THE RELAY COIL IS ACTIVATED AND CURRENT TO **TERMINAL +1** → **TERMINAL +1** OF THE REAR WIPER MOTOR → **GROUND**, CAUSING THE MOTOR TO OPERATE THE WIPER.

2. REAR WIPER INTERMITTENT OPERATION

WHEN THE IGNITION SW IS TURNED ON AND THE REAR WIPER AND WASHER SW IS TURNED TO **INT** POSITION, CURRENT TO **TERMINAL 1** OF THE REAR WIPER MOTOR AND RELAY FLOWS TO **TERMINAL 2** OF THE RELAY → **TERMINAL 13** OF THE REAR WIPER AND WASHER SW → **TERMINAL 2** → **GROUND**.

THIS CAUSES THE MOTOR TO OPERATE (THE POINT CHANGES) AND THE INTERMITTENT CIRCUIT OF THE RELAY OPERATES. INTERMITTENT OPERATION OF THE CIRCUIT IS CONTROLLED BY THE CHARGING AND DISCHARGING OF THE CONDENSER INSTALLED INSIDE THE RELAY.

3. WASHER OPERATION

WITH THE IGNITION SW TURNED ON AND THE REAR WIPER AND WASHER SW TURNED TO **ON** POSITION, WHEN THE WIPER SW IS TURNED FURTHER, CURRENT TO **TERMINAL 2** OF THE WASHER MOTOR FLOWS TO **TERMINAL 3** OF THE MOTOR → **TERMINAL 12** OF THE REAR WIPER AND WASHER SW → **TERMINAL 2** → **GROUND** SO THAT THE WASHER MOTOR ROTATES AND THE WINDOW WASHER EMITS A WATER, ONLY WHILE THE SWITCH IS FULLY TURNED.

WHEN THE WIPER SW IS OFF AND THEN TURNED WASHER ON (WIPER OFF SIDE), THE WIPER SW IS ON AND THEN TURNED TO WASHER ON (WIPER ON SIDE), ONLY THE WASHER OPERATES.

SERVICE HINTS

W 1 WASHER MOTOR

2-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION

3-GROUND : CONTINUITY WITH THE WASHER SW TURNED ON

R 13 REAR WIPER MOTOR AND RELAY

1-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION

2-GROUND : CONTINUITY WITH THE REAR WIPER AND WASHER SW AT **INT** POSITION

3-GROUND : CONTINUITY WITH THE REAR WIPER AND WASHER SW AT **ON** POSITION

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C13	32	R13	34 (L/B)		
J1	33	W1	29 (5S-FE), 31 (7A-FE)		

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
ID	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
1A	22	ENGINE ROOM MAIN WIRE AND J/B NO.1 (LEFT KICK PANEL)
1C	22	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT KICK PANEL)
1F	22	FLOOR WIRE AND J/B NO.1 (LEFT KICK PANEL)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IC3	42	ENGINE ROOM MAIN WIRE AND COWL WIRE (INSIDE OF R/B NO.4)
IF1	42	COWL WIRE AND FLOOR WIRE (LEFT KICK PANEL)
BO1	46 (L/B)	BACK DOOR NO.1 WIRE AND FLOOR WIRE (BACK DOOR UPPER LEFT)
BP1	46 (L/B)	BACK DOOR NO.2 WIRE AND BACK DOOR NO.1 WIRE (BACK DOOR UPPER LEFT)

▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
ID	42	LEFT KICK PANEL



SHIFT LOCK



SYSTEM OUTLINE

WHEN THE IGNITION SW IS AT **ACC** POSITION, CURRENT FROM THE **CIG & RAD** FUSE FLOWS TO **TERMINAL 1** OF THE SHIFT LOCK ECU.

WHEN IGNITION SW IS AT **ON** POSITION, CURRENT FROM THE **ECU-IG** FUSE FLOWS TO **TERMINAL 3** OF THE SHIFT LOCK ECU.

1. SHIFT LOCK MECHANISM

WITH THE IGNITION SW ON, WHEN A SIGNAL THAT THE BRAKE PEDAL IS DEPRESSED (STOP LIGHT SW ON) AND A SIGNAL THAT THE SHIFT LEVER IS AT **P** POSITION (CONTINUITY BETWEEN P1 AND P OF THE SHIFT LOCK CONTROL SW) IS INPUT TO THE ECU. THE ECU OPERATES AND CURRENT FLOWS FROM **TERMINAL 3** OF THE ECU TO **TERMINAL SLS+** OF THE SHIFT LOCK SOLENOID → SOLENOID → **TERMINAL SLS-** → **TERMINAL 5** OF THE ECU → **GROUND**. THIS CAUSES THE SHIFT LOCK SOLENOID TO TURN ON (PLATE STOPPER DISENGAGES) AND THE SHIFT LEVER CAN SHIFT INTO OTHER POSITIONS THAN THE **P** POSITION.

2. KEY INTERLOCK MECHANISM

WITH THE IGNITION SW AT **ON** OR **ACC** POSITION, WHEN THE SHIFT LEVER IS AT "P" POSITION (NO CONTINUITY BETWEEN P2 AND P OF THE SHIFT LOCK CONTROL SW). CURRENT FROM **TERMINAL 1** OF THE ECU TO THE KEY INTERLOCK SOLENOID IS CUT OFF. THIS CAUSES THE KEY INTERLOCK SOLENOID TO TURN OFF (THE LOCK LEVER DISENGAGES FROM LOCK POSITION) AND THE IGNITION KEY CAN BE TURNED FROM **ACC** TO **LOCK** POSITION.

SERVICE HINTS

S3 SHIFT LOCK ECU

1-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ACC** OR **ON** POSITION

3-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT ON POSITION

5-GROUND : ALWAYS CONTINUITY

6-GROUND : APPROX. 12 VOLTS WITH THE BRAKE PEDAL DEPRESSED

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
J2	33	S3	33		
K2	33	S7	33		

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IC	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
ID		
IE		
IF		
IH		
1C	22	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1E		
1J	22	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
3A	24	INSTRUMENT PANEL WIRE AND J/B NO. 3 (BEHIND THE INSTRUMENT PANEL CENTER)
3C		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS




CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
ID1	42	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)

▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	42	INSTRUMENT PANEL BRACE LH



(HINT:SEE PAGE 7)



SYSTEM OUTLINE

CURRENT IS APPLIED AT ALL TIMES THROUGH THE **POWER FUSE** TO **TERMINAL 5** OF THE POWER MAIN RELAY AND **TERMINAL 12** OF THE MOON ROOF CONTROL RELAY. WITH THE IGNITION SW TURNED ON, CURRENT FLOWS TO **TERMINAL 1** OF THE POWER MAIN RELAY → **TERMINAL 2** → **GROUND** THROUGH THE **GAUGE FUSE**.

AS A RESULT, POWER MAIN RELAY IS ACTIVATED AND CURRENT TO **TERMINAL 5** OF THE POWER MAIN RELAY FLOWS FROM **TERMINAL 3** OF THE POWER MAIN RELAY TO **TERMINAL 6** OF THE MOON ROOF CONTROL RELAY.

1. SLIDE OPEN OPERATION

WHEN THE IGNITION SW IS TURNED ON AND THE MOON ROOF CONTROL SW IS PUSHED TO **OPEN** POSITION, CURRENT FLOWS FROM **TERMINAL 1** OF THE MOON ROOF CONTROL RELAY TO **TERMINAL 3** OF THE MOON ROOF CONTROL SW → **TERMINAL 8** → **GROUND**. THE MOON ROOF LIMIT SW NO.1 OR NO.2 IS ON AT THIS TIME.

WHEN THIS OCCURS, THE RELAY IS ACTIVATED AND CURRENT TO **TERMINAL 12** OF THE MOON ROOF CONTROL RELAY FLOWS FROM **TERMINAL 5** TO **TERMINAL 1** OF THE MOON ROOF MOTOR → **TERMINAL 3** → **TERMINAL 4** OF THE MOON ROOF CONTROL RELAY → **TERMINAL 11** → **GROUND**, ROTATING THE MOTOR TO OPEN THE MOON ROOF WHILE THE SW IS BEING PUSHED TO **OPEN** POSITION.

2. SLIDE CLOSE OPERATION

WITH THE IGNITION SW TURNED ON AND THE MOON ROOF LIMIT SW NO.1 AND NO.2 BOTH ON (THE MOON ROOF COMPLETELY OPENING), WHEN THE MOON ROOF CONTROL SW IS PUSHED TO **CLOSE** POSITION, CURRENT FLOWS FROM **TERMINAL 2** OF THE MOON ROOF CONTROL RELAY TO **TERMINAL 4** OF THE MOON ROOF CONTROL SW → **TERMINAL 8** → **GROUND**.

WHEN THIS OCCURS, THE RELAY IS ACTIVATED AND CURRENT TO **TERMINAL 12** OF THE MOON ROOF CONTROL RELAY FLOWS FROM **TERMINAL 4** TO **TERMINAL 3** OF THE MOON ROOF MOTOR → **TERMINAL 1** → **TERMINAL 5** OF THE MOON ROOF CONTROL RELAY → **TERMINAL 11** → **GROUND**, ROTATING THE MOTOR TO CLOSE THE MOON ROOF WHILE THE SW IS BEING PUSHED TO **CLOSE** POSITION.

THE MOON ROOF LIMIT SW NO.1 TURNS OFF (LIMIT SW NO.2 IS ON) AND AT **200 MM (7.874 IN.)** BEFORE FULLY AT **CLOSE** POSITION, SIGNAL IS INPUT FROM **TERMINAL 1** OF THE LIMIT SW NO.1 TO **TERMINAL 8** OF THE MOON ROOF CONTROL RELAY. THIS SIGNAL ACTIVATES THE RELAY AND STOPS CONTINUOUS FROM **TERMINAL 12** OF THE MOON ROOF CONTROL RELAY TO **TERMINAL 11**. AS A RESULT, THE MOON ROOF STOPS AT THIS POSITION. TO CLOSE THE MOON ROOF COMPLETELY, PUSHING THE MOON ROOF CONTROL SW AGAIN TO THE CLOSE SIDE CAUSES A SIGNAL TO BE INPUT AGAIN TO **TERMINAL 2** OF THE MOON ROOF CONTROL RELAY. THIS ACTIVATES THE RELAY AND THE MOON ROOF WILL CLOSE AS LONG AS THE MOON ROOF CONTROL SW IS BEING PUSHED, ALLOWING THE MOON ROOF TO FULLY CLOSE.

3. TILT UP OPERATION

WHEN THE MOON ROOF CONTROL SW IS PUSHED TO **TILT UP** POSITION, WITH THE IGNITION SW TURNED ON AND THE MOON ROOF COMPLETELY CLOSED (MOON ROOF LIMIT SW NO.2 IS OFF), CURRENT FLOWS FROM **TERMINAL 3** OF THE MOON ROOF CONTROL RELAY TO **TERMINAL 5** OF THE MOON ROOF CONTROL SW → **TERMINAL 8** → **GROUND**. AS A RESULT, THE RELAY IS ACTIVATED AND CURRENT TO **TERMINAL 12** OF THE MOON ROOF CONTROL RELAY FLOWS FROM **TERMINAL 4** OF THE RELAY TO **TERMINAL 3** OF THE MOON ROOF MOTOR → **TERMINAL 1** → **TERMINAL 5** OF THE MOON ROOF CONTROL RELAY → **TERMINAL 11** → **GROUND** AND ROTATES THE MOTOR SO THAT TILT UP OPERATION OCCURS AS LONG AS THE MOON ROOF CONTROL SW IS PUSHED ON THE TILT UP SIDE.

4. TILT DOWN OPERATION

WHEN THE MOON ROOF CONTROL SW IS PUSHED TO **TILT DOWN** POSITION, WITH THE IGNITION SW TURNED ON AND THE MOON ROOF TILTED UP (NO.1 AND NO.2 MOON ROOF LIMIT SW ARE BOTH OFF), CURRENT FLOWS FROM **TERMINAL 7** OF THE MOON ROOF CONTROL RELAY TO **TERMINAL 6** OF THE MOON ROOF CONTROL SW → **TERMINAL 8** → **GROUND**.

AS A RESULT, THE RELAY IS ACTIVATED AND CURRENT TO **TERMINAL 12** OF THE MOON ROOF CONTROL RELAY FLOWS FROM **TERMINAL 5** OF THE RELAY TO **TERMINAL 1** OF THE MOON ROOF MOTOR → **TERMINAL 3** → **TERMINAL 4** OF THE MOON ROOF CONTROL RELAY → **TERMINAL 11** → **GROUND** AND ROTATES THE MOTOR SO THAT TILT DOWN OPERATION OCCURS AS LONG AS THE MOON ROOF CONTROL SW IS PUSHED ON THE TILT DOWN SIDE. (DURING TILT DOWN, LIMIT SW NO.1 IS CHANGED FROM OFF TO ON.)

5. KEY OFF MOON ROOF OPERATION

WITH THE IGNITION SW TURNED FROM ON TO OFF, THE DOOR LOCK CONTROL RELAY OPERATES AND CURRENT FLOWS FROM THE **DOOR FUSE** THROUGH **TERMINAL 8** OF THE RELAY OR FROM THE **GAUGE FUSE** THROUGH **TERMINAL 1** OF THE DOOR LOCK CONTROL RELAY TO **TERMINAL 15** → **TERMINAL 1** OF THE POWER MAIN RELAY → **TERMINAL 2** → **GROUND** FOR ABOUT **60** SECONDS. THE SAME AS NORMAL OPERATION, CURRENT FLOWS FROM THE **POWER FUSE** → **TERMINAL 5** OF THE POWER MAIN RELAY → **TERMINAL 3** → **TERMINAL 6** OF THE MOON ROOF CONTROL RELAY. AS A RESULT, FOR ABOUT **60** SECONDS AFTER THE IGNITION SW IS TURNED OFF, THE FUNCTIONING OF THIS RELAY MAKES IT POSSIBLE TO OPEN AND CLOSE THE MOON ROOF. ALSO, BY OPENING THE FRONT DOOR (DOOR COURTESY SW ON) WITHIN ABOUT **60** SECONDS AFTER TURNING THE IGNITION SW TO OFF, A SIGNAL IS INPUT TO **TERMINALS 2** OR **14** OF THE DOOR LOCK CONTROL RELAY.

AS A RESULT, THE ECU TURNS OFF, AND OPEN AND CLOSE MOVEMENT OF THE MOON ROOF STOPS.



MOON ROOF

SERVICE HINTS

POWER MAIN RELAY

3-5 : CLOSED WITH THE IGNITION SW AT **ON** POSITION OR KEY OFF MOON ROOF OPERATION

M 2 MOON ROOF CONTROL RELAY

11-GROUND : ALWAYS CONTINUITY

6-GROUND : APPROX. **12** VOLTS WITH THE IGNITION SW AT **ON** POSITION

4-GROUND : APPROX. **12** VOLTS WITH THE IGNITION SW ON AND THE MOON ROOF CONTROL SW AT **CLOSE** OR **UP** POSITION (EXCEPT APPROX. **200** MM (**7.874** IN.) BEFORE FULLY AT **CLOSED** POSITION)

5-GROUND : APPROX. **12** VOLTS WITH THE IGNITION SW ON AND THE MOON ROOF CONTROL SW AT **OPEN** OR **DOWN** POSITION

M 3 MOON ROOF CONTROL SW

5-8 : CLOSED WITH THE MOON ROOF CONTROL SW AT **TILT UP** POSITION

4-8 : CLOSED WITH THE MOON ROOF CONTROL SW AT **CLOSE** POSITION

6-8 : CLOSED WITH THE MOON ROOF CONTROL SW AT **TILT DOWN** POSITION

3-8 : CLOSED WITH THE MOON ROOF CONTROL SW AT **OPEN** POSITION

8-GROUND : ALWAYS CONTINUITY

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
D 5	32	D11	34 (L/B), 35 (C/P)	M 4	34 (L/B), 35 (C/P)
D 7	32	M 2	34 (L/B), 35 (C/P)	M 5	34 (L/B), 35 (C/P)
D10	34 (L/B), 35 (C/P)	M 3	34 (L/B), 35 (C/P)		

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
ID	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
IE		
IF		
IG		
1C	22	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT KICK PANEL)
1E		
1H	22	ROOF WIRE AND J/B NO.1 (LEFT KICK PANEL)
3A	24	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)
3C		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IG1	42	INSTRUMENT PANEL WIRE AND FLOOR WIRE (LEFT KICK PANEL)
IH1	42	FLOOR WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)

▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	42	INSTRUMENT PANEL BRACE LH
BG	46 (L/B)	ROOF LEFT
	48 (C/P)	


○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I 4	44	INSTRUMENT PANEL WIRE	B 4	46 (L/B)	ROOF WIRE
I 6				48 (C/P)	

D 5 BLACK



D 7




D10




D11



M 2




M 3



M 4




M 5





CIGARETTE LIGHTER AND CLOCK



SERVICE HINTS

C 3 CIGARETTE LIGHTER

- 2-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ACC** OR **ON** POSITION
- 1-GROUND : ALWAYS CONTINUITY

C 6 CLOCK

- 2-GROUND : ALWAYS 12 VOLTS (POWER FOR CLOCK)
- 5-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ACC** OR **ON** POSITION
(POWER FOR INDICATION)
- 3-GROUND : ALWAYS CONTINUITY

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C 3	33	C 6	32		

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
ID	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
IE		
1A	22	ENGINE ROOM MAIN WIRE AND J/B NO.1 (LEFT KICK PANEL)
1C	22	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT KICK PANEL)
3B	24	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)
3C		


▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	42	INSTRUMENT PANEL BRACE LH

C 3




C 6






CRUISE CONTROL

FROM POWER SOURCE SYSTEM (SEE PAGE 62)







SYSTEM OUTLINE

CURRENT IS APPLIED AT ALL TIMES THROUGH THE **STOP** FUSE TO **TERMINAL 2** OF THE STOP LIGHT SW, AND ALSO THROUGH THE **ECU-B** FUSE TO **TERMINAL 15** OF THE CRUISE CONTROL ECU.

WITH THE IGNITION SW TURNED TO ON, CURRENT FLOWS THROUGH THE **GAUGE** FUSE TO **TERMINAL (B) 4** OF THE COMBINATION METER AND CURRENT THROUGH THE **ECU-IG** FUSE FLOWS TO **TERMINAL 14** OF THE CRUISE CONTROL ECU.

WHEN THE IGNITION SW ON AND THE CRUISE CONTROL MAIN SWITCH IS PUSHED ON, A SIGNAL IS INPUT FROM **TERMINAL 19** OF THE CRUISE CONTROL ECU TO **TERMINAL 5** OF THE CRUISE CONTROL SW. AS A RESULT, THE CRUISE CONTROL ECU FUNCTIONS AND CURRENT FLOWS TO **TERMINAL 14** OF THE CRUISE CONTROL ECU → **TERMINAL 13** → **GROUND**, AND THE CRUISE CONTROL SYSTEM IS IN A CONDITION READY FOR OPERATION.

AT THE SAME TIME, CURRENT THROUGH THE **GAUGE** FUSE FLOWS FROM **TERMINAL (B) 4** OF THE CRUISE CONTROL INDICATOR LIGHT TO **TERMINAL (C) 9** → **TERMINAL 7** OF THE CRUISE CONTROL ECU → **TERMINAL 13** → **GROUND**, CAUSING THE CRUISE CONTROL INDICATOR LIGHT TO LIGHT UP, INDICATING THAT THE CRUISE CONTROL IS READY FOR OPERATION.

1. SET OPERATION

WHEN THE CRUISE CONTROL MAIN SW IS PUSHED ON AND THE SET SW IS TURNED WITH THE VEHICLE SPEED WITHIN THE SET LIMIT (APPROX. **40 KM/H, 25 MPH** TO **200 KM/H, 124 MPH**), A SIGNAL IS INPUT TO **TERMINAL 18** OF THE CRUISE CONTROL ECU AND THE VEHICLE SPEED AT THE TIME THE SET SW IS RELEASED IS MEMORIZED IN THE ECU AS THE SET SPEED.

2. SET SPEED CONTROL

DURING CRUISE CONTROL DRIVING, THE ECU COMPARES THE SET SPEED MEMORIZED IN THE ECU WITH THE ACTUAL VEHICLE SPEED INPUT TO **TERMINAL 20** OF THE CRUISE CONTROL ECU FROM THE VEHICLE SPEED SENSOR, AND CONTROLS THE CRUISE CONTROL ACTUATOR TO MAINTAIN THE SET SPEED.

WHEN THE ACTUAL SPEED IS LOWER THAN THE SET SPEED, THE ECU CAUSES CURRENT TO THE CRUISE CONTROL ACTUATOR TO FLOW FROM **TERMINAL 12** TO **TERMINAL 6** OF THE CRUISE CONTROL ACTUATOR → **TERMINAL 7** → **TERMINAL 11** OF THE CRUISE CONTROL ECU. AS A RESULT, THE MOTOR IN THE CRUISE CONTROL ACTUATOR IS ROTATED TO OPEN THE THROTTLE VALVE AND THE THROTTLE CABLE IS PULLED TO INCREASE THE VEHICLE SPEED. WHEN THE ACTUAL DRIVING SPEED IS HIGHER THAN THE SET SPEED, CURRENT TO THE CRUISE CONTROL ACTUATOR FLOWS FROM **TERMINAL 11** OF THE ECU TO **TERMINAL 7** OF THE CRUISE CONTROL ACTUATOR → **TERMINAL 6** → **TERMINAL 12** OF THE CRUISE CONTROL ECU.

THIS CAUSES THE MOTOR IN THE CRUISE CONTROL ACTUATOR TO ROTATE TO CLOSE THE THROTTLE VALVE AND RETURN THE THROTTLE CABLE TO DECREASE THE VEHICLE SPEED.

3. COAST CONTROL

DURING CRUISE CONTROL DRIVING, WHILE THE COAST SW IS ON, THE CRUISE CONTROL ACTUATOR RETURNS THE THROTTLE CABLE TO CLOSE THE THROTTLE VALVE AND DECREASE THE DRIVING SPEED. THE VEHICLE SPEED, WHEN THE COAST SWITCH IS TURNED OFF, IS MEMORIZED AND THE VEHICLE CONTINUES AT THE NEW SET SPEED.

4. ACCEL CONTROL

DURING CRUISE CONTROL DRIVING, WHILE THE ACCEL SW IS TURNED ON, THE CRUISE CONTROL ACTUATOR PULLS THE THROTTLE CABLE TO OPEN THE THROTTLE VALVE AND INCREASE THE DRIVING SPEED.

THE VEHICLE SPEED, WHEN THE ACCEL SW IS TURNED OFF, IS MEMORIZED AND THE VEHICLE CONTINUES AT THE NEW SET SPEED.

5. RESUME CONTROL

UNLESS THE VEHICLE SPEED FALLS BELOW THE MINIMUM SPEED LIMIT (APPROX. **40 KM/H, 25 MPH**) AFTER CANCELING THE SET SPEED BY THE CANCEL SW, PUSHING THE RESUME SW WILL CAUSE THE VEHICLE TO RESUME THE SPEED SET BEFORE CANCELLATION.

6. MANUAL CANCEL MECHANISM

IF ANY OF THE FOLLOWING OPERATIONS OCCURS DURING CRUISE CONTROL OPERATION, THE MAGNETIC CLUTCH OF THE ACTUATOR TURNS OFF AND THE MOTOR ROTATES TO CLOSE THE THROTTLE VALVE AND THE CRUISE CONTROL IS RELEASED.

* PLACING THE SHIFT LEVER EXCEPT "D" POSITION (PARK/NEUTRAL POSITION SW EXCEPT "D" POSITION). "SIGNAL IS NOT INPUT TO **TERMINAL 2** OF THE ECU" (A/T)

* DEPRESSED THE CLUTCH PEDAL (CRUISE CONTROL CLUTCH SW OFF). "SIGNAL IS NOT INPUT TO **TERMINAL 2** OF THE ECU" (M/T)

* DEPRESSED THE BRAKE PEDAL (STOP LIGHT SW ON). "SIGNAL IS INPUT TO **TERMINAL 16** OF THE ECU"

* PUSHED THE CANCEL SWITCH (CANCEL SW ON). "SIGNAL IS INPUT TO **TERMINAL 18** OF THE ECU"

7. AUTO CANCEL FUNCTION

A) IF ANY OF THE FOLLOWING OPERATING CONDITIONS OCCURS DURING CRUISE CONTROL OPERATION, THE SET SPEED IS ERASED, CURRENT FLOWING TO THE MAGNETIC CLUTCH IS STOPPED AND THE CRUISE CONTROL IS RELEASED. (MAIN SW PUSH OUT OFF.) WHEN THIS OCCURS, THE IGNITION SW MUST BE TURNED OFF ONCE BEFORE THE MAIN SW WILL PUSH ON.

- * WHEN CURRENT CONTINUES TO FLOW TO THE MOTOR INSIDE THE ACTUATOR IN THE THROTTLE VALVE "OPEN" DIRECTION.
- * THE MOTOR DOES NOT OPERATE DESPITE THE MOTOR DRIVE SIGNAL BEING OUTPUT.

B) IF ANY OF THE FOLLOWING OPERATING CONDITIONS OCCURS DURING CRUISE CONTROL OPERATION, THE SET SPEED IS ERASED, CURRENT FLOW TO THE MAGNETIC CLUTCH IS STOPPED AND THE CRUISE CONTROL IS RELEASED. (MAIN SW PUSH OUT OFF.) WHEN THIS OCCURS, THE CANCEL STATE IS CLEARED AS THE MAIN SW WILL PUSH ON AGAIN.

- * OVER CURRENT TO TRANSISTOR DRIVING THE MOTOR AND/OR THE MAGNETIC CLUTCH.
- * OPEN CIRCUIT IN THE MAGNETIC CLUTCH.
- * MOMENTARY INTERRUPTION OF VEHICLE SPEED SIGNAL.
- * SHORT CIRCUIT IN THE CRUISE CONTROL SW.
- * WHEN THE VEHICLE SPEED FALLS MORE THAN **16 KM/H (10 MPH)** BELOW THE SET SPEED.

C) IF ANY OF THE FOLLOWING CONDITIONS OCCURS DURING CRUISE CONTROL OPERATION, THE SET SPEED IS ERASED AND THE CRUISE CONTROL IS RELEASED. (THE POWER TO THE MAGNETIC CLUTCH IS CUT OFF UNTIL THE SET SW IS "ON" AGAIN.)

- * WHEN THE VEHICLE SPEED FALLS BELOW THE MINIMUM SPEED LIMIT, APPROX. **40 KM/H (25 MPH)**
- * WHEN POWER TO THE CRUISE CONTROL SYSTEM IS MOMENTARILY CUT OFF.

D) IF ANY OF THE FOLLOWING CONDITIONS OCCURS DURING CRUISE CONTROL OPERATION, THE CRUISE CONTROL IS RELEASED.

- * OPEN THE CIRCUIT FOR **TERMINAL 2** OF THE STOP LIGHT SW.

8. AUTOMATIC TRANSMISSION CONTROL FUNCTION

* IN OVERDRIVE, IF THE VEHICLE SPEED BECOMES LOWER THAN THE OVERDRIVE CUT SPEED (SET SPEED MINUS APPROX. **4 KM/H, 2.5 MPH**) DURING CRUISE CONTROL OPERATION, SUCH AS DRIVING UP A HILL, THE OVERDRIVE IS RELEASED AND THE POWER INCREASES TO PREVENT A REDUCTION IN VEHICLE SPEED,

* AFTER RELEASING THE OVERDRIVE, VEHICLE SPEED BECOMES HIGHER THAN THE OVERDRIVE RETURN SPEED (SET SPEED MINUS APPROX. **2 KM/H, 1.2 MPH**) AND THE ECU JUDGES BY THE SIGNALS FROM THE ACTUATOR'S POTENTIOMETER THAT THE UPWARD SLOPE HAS FINISHED, THE OVERDRIVE IS RESUMED AFTER APPROX. **2 SECONDS**.

* DURING CRUISE CONTROL DRIVING, THE CRUISE CONTROL OPERATION SIGNAL IS OUTPUT FROM THE CRUISE CONTROL ECU TO THE ENGINE CONTROL MODULE. UPON RECEIVING THIS SIGNAL, THE ENGINE CONTROL MODULE CHANGES THE SHIFT PATTERN TO NORMAL.

TO MAINTAIN SMOOTH CRUISE CONTROL OPERATION (ON A DOWNWARD SLOPE ETC.), THE LOCK-UP RELEASE OF THE TRANSMISSION WHEN THE IDLING SIGNAL OF THE THROTTLE POSITION IS "ON" IS FORBIDDEN.

SERVICE HINTS

C 1 CRUISE CONTROL ACTUATOR

- 1-3 : APPROX. **2 Ω**
- 5-4 : APPROX. **38 Ω**

C12 CRUISE CONTROL SW [COMB. SW]

- 5-3 : CONTINUITY WITH THE MAIN SW ON
- 4-3 : APPROX. **418 Ω** WITH THE CANCEL SW ON
APPROX. **198 Ω** WITH THE SET/COAST SW ON
APPROX. **68 Ω** WITH THE RESUME/ACCEL SW ON

C15 CRUISE CONTROL ECU

- 14-GROUND : APPROX. **12 VOLTS** WITH THE IGNITION SW AT **ON** POSITION
- 15-GROUND : ALWAYS APPROX. **12 VOLTS**
- 20-GROUND : **4 PULSES** WITH **1** ROTATION OF THE ROTOR SHAFT
- 18-GROUND : APPROX. **418 Ω** WITH THE CANCEL SW ON IN THE CONTROL SW
APPROX. **198 Ω** WITH THE SET/COAST SW ON IN THE CONTROL SW
APPROX. **68 Ω** WITH THE RESUME/ACCEL SW ON IN THE CONTROL SW
- 13-GROUND : ALWAYS CONTINUITY



CRUISE CONTROL

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C 1	28 (5S-FE), 30 (7A-FE)	C15	32	J 7	33
C 9	B 32	D 1	28 (5S-FE), 30 (7A-FE)	J 9	33
C10	C 32	E 5	A 32	P 1	29 (5S-FE), 31 (7A-FE)
C12	32	E 7	C 32	S 7	33
C14	32	J 2	33	V 1	29 (5S-FE), 31 (7A-FE)

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
ID		
IE	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
IF		
1A	22	ENGINE ROOM MAIN WIRE AND J/B NO.1 (LEFT KICK PANEL)
1C	22	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT KICK PANEL)
1J		
1K	22	COWL WIRE AND J/B NO.1 (LEFT KICK PANEL)
3B		
3C	24	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IC1	42	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
ID1		
ID2	42	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)
II1		
II2	44	ENGINE WIRE AND INSTRUMENT PANEL WIRE (NEAR THE ENGINE CONTROL MODULE)
IJ1	44	ENGINE WIRE AND COWL WIRE (INSTRUMENT PANEL CENTER)


▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	42	INSTRUMENT PANEL BRACE LH
IF	42	R/B NO.4 SET BOLT


○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I 8	44	ENGINE WIRE	I13	44	ENGINE WIRE


C 1 GRAY




C 9 Ⓟ




C10 Ⓞ GRAY




C12 BLACK




C14 BLUE




C15 GREEN




(5S-FE) D 1 BLACK




(7A-FE) D 1 BLACK




(5S-FE A/T) E 5 (A) DARK GRAY




(7A-FE A/T) E 5 (A) DARK GRAY




(5S-FE A/T) E 7 (C) DARK GRAY



(7A-FE A/T) E 7 (C) DARK GRAY




J 2




(HINT:SEE PAGE 7)

J 7




(HINT:SEE PAGE 7)

J 9




(HINT:SEE PAGE 7)

P 1 GRAY



8 7




V 1 BLACK






ABS

FROM POWER SOURCE SYSTEM (SEE PAGE 62)



FROM POWER SOURCE SYSTEM (SEE PAGE 62)





SYSTEM OUTLINE

THIS SYSTEM CONTROLS THE RESPECTIVE BRAKE FLUID PRESSURES ACTING ON THE BRAKE CYLINDERS OF THE RIGHT FRONT WHEEL, THE LEFT FRONT WHEEL AND THE REAR WHEELS WHEN THE BRAKES ARE APPLIED IN A PANIC STOP SO THAT THE WHEELS DO NOT LOCK. THIS RESULTS IN IMPROVED DIRECTIONAL STABILITY AND STEERABILITY DURING PANIC BRAKING.

1. INPUT SIGNALS

(1) SPEED SENSOR SIGNAL

THE SPEED OF THE WHEELS IS DETECTED AND INPUT TO **TERMINALS FL+, FR+, RL+ AND RR+** OF THE ABS ECU.

(2) STOP LIGHT SW SIGNAL

A SIGNAL IS INPUT TO **TERMINAL STP** OF THE ABS ECU WHEN THE BRAKE PEDAL DEPRESSED.

2. SYSTEM OPERATION

DURING SUDDEN BRAKING THE ABS ECU WHICH HAS SIGNALS INPUT FROM EACH OF THE SENSORS, CONTROLS CURRENT TO THE SOLENOID INSIDE THE ACTUATOR AND CAUSES THE HYDRAULIC PRESSURE ACTING ON EACH OF THE WHEEL CYLINDERS ESCAPE TO THE RESERVOIR. THE PUMP INSIDE THE ACTUATOR IS ALSO OPERATING AT THIS TIME AND IT RETURNS THE BRAKE FLUID FROM THE RESERVOIR TO THE MASTER CYLINDER, PREVENTING LOCKING OF THE VEHICLE WHEELS.

IF THE ECU JUDGES THAT THE HYDRAULIC PRESSURE ACTING ON THE WHEEL CYLINDER IS INSUFFICIENT, THE CURRENT ACTING ON THE SOLENOID IS CONTROLLED AND THE HYDRAULIC PRESSURE IS INCREASED- HOLDING OF THE HYDRAULIC PRESSURE IS ALSO CONTROLLED BY THE ECU, BY THE SAME METHOD AS ABOVE. BY REPEATED PRESSURE REDUCTION, HOLDING AND INCREASE ARE REPEATED TO MAINTAIN VEHICLE STABILITY AND TO IMPROVE STEERABILITY DURING SUDDEN BRAKING.

SERVICE HINTS

A10 (A), A11 (B) ABS ECU

(CONNECT THE ECU CONNECTOR)

(B) 8-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION AND THE DATA LINK CONNECTOR 1 **TS-E1** NOT CONNECTED

(B) 9-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION AND THE DATA LINK CONNECTOR 1 **TC-E1** NOT CONNECTED

(A) 1-GROUND :

(A) 4-GROUND :

(A) 5-GROUND :

(A) 10-GROUND :

(A) 11-GROUND :

(A) 12-GROUND :

(A) 21-GROUND :

(A) 22-GROUND :

} APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION AND THE ABS WARNING LIGHT GOES OFF

(B) 2-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION

(B) 12-GROUND : APPROX. 12 VOLTS WITH THE BRAKE PEDAL DEPRESSED

(DISCONNECT THE ECU CONNECTOR)

(A) 3 - **(A)** 14 : } 1.0 - 2.6 KΩ

(A) 19 - **(A)** 20 : }

(B) 1 - **(B)** 7 : } 0.8 - 2.05 KΩ

(B) 3 - **(B)** 10 : }

 : PARTS LOCATION

CODE		SEE PAGE	CODE		SEE PAGE	CODE	SEE PAGE
A4	A	28 (5S-FE), 30 (7A-FE)	A17		34 (L/B), 35 (C/P)	D1	28 (5S-FE), 30 (7A-FE)
A5	B	28 (5S-FE), 30 (7A-FE)			36 (CONVERTIBLE)	J1	33
A6		28 (5S-FE), 30 (7A-FE)	A18		34 (L/B), 35 (C/P)	J2	33
A7		28 (5S-FE), 30 (7A-FE)			36 (CONVERTIBLE)	J7	33
A10	A	32	C9	B	32	S7	33
A11	B	32	C10	C	32		

 : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
5	27	R/B NO. 5 (ENGINE COMPARTMENT FRONT RIGHT)

 : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
ID	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
IE		
IF		
1C	22	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1J	22	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1K		
2A	26	ENGINE ROOM MAIN WIRE AND J/B. NO. 2 (ENGINE COMPARTMENT LEFT)
3B	24	INSTRUMENT PANEL WIRE AND J/B NO. 3 (BEHIND THE INSTRUMENT PANEL CENTER)

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	38 (5S-FE)	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (INSIDE OF R/B NO. 2)
	40 (7A-FE)	
IC1	42	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IC4	42	ENGINE ROOM MAIN WIRE ANE COWL WIRE (INSIDE OF R/B NO. 4)
ID1	42	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)
ID2		
IF1	42	COWL WIRE AND FLOOR WIRE (LEFT KICK PANEL)
II2	44	ENGINE WIRE AND INSTRUMENT PANEL WIRE (NEAR THE ENGINE CONTROL MODULE)
IJ1	44	ENGINE WIRE AND COWL WIRE (INSTRUMENT PANEL CENTER)

 : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EA	38 (5S-FE)	FRONT SIDE OF RIGHT FENDER
	40 (7A-FE)	
ID	42	LEFT KICK PANEL

 : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E1	38 (5S-FE)	ENGINE ROOM MAIN WIRE	E2	40 (7A-FE)	ENGINE ROOM MAIN WIRE
	40 (7A-FE)		I1	44	COWL WIRE
E2	38 (5S-FE)	I11			




ABS

A 4 (A) GRAY



A 5 (B) GRAY




A 6 GRAY




A 7 GRAY



A10 (A)



A11 (B)




A17 GRAY




A18 GRAY




C 9 (B)




C10 (C) GRAY




(5S-FE) D 1 BLACK



(7A-FE) D 1 BLACK




J 1




(HINT:SEE PAGE 7)

J 2




(HINT:SEE PAGE 7)

J 7





(HINT:SEE PAGE 7)

(W/ CRUISE CONTROL) S 7




(W/O CRUISE CONTROL) S 7





NOTICE: When inspecting or repairing the SRS, perform the operation in accordance with the following precautionary instructions and the procedure and precautions in the Repair Manual for the applicable model year.


- Malfunction symptoms of the supplemental restraint system are difficult to confirm, so the diagnostic trouble codes become the most important source of information when troubleshooting.
When troubleshooting the supplemental restraint system, always inspect the diagnostic trouble codes before disconnecting the battery.
- Work must be started after 90 seconds from the time the Ignition SW is set to the “LOCK” position and the negative (-) terminal cable is disconnected from the battery.
(The supplement restraint system is equipped with a back-up power source so that if work is started within 90 seconds of disconnecting the negative (-) terminal cable of the battery, the SRS may be activated.)
When the negative (-) terminal cable is disconnected from the battery, memory of the clock and audio system will be cancelled. So, before starting work, make a record of the contents memorized by each memory system. When work is finished, reset the clock and audio system as before and adjust the clock.
To avoid erasing the memory of each memory system, never use a back-up power supply from outside the vehicle.
- When removing the steering wheel pad or handling a new steering wheel pad, keep the pad upper surface facing upward. Also, lock the lever of the twin lock type connector at the rear of the pad and take care not to damage the connector.
(Storing the pad with its metallic surface up may lead to a serious accident if the SRS inflates for some reason.)
- Always store a removed or new front passenger airbag assembly with the airbag door facing up. Storing the airbag assembly with the airbag door facing down could cause a serious accident if the airbag inflates.
- Store the steering wheel pad where the ambient temperature remains below 93° C (200° F), without high humidity and away from electrical noise.
- Never use SRS parts from another vehicle. When replacing SRS parts, replace them with new parts.
- Never disassemble and repair the steering wheel pad, front passenger airbag assembly and center airbag sensor assembly or front airbag sensors.
- Before repairing the body, remove the airbag sensors if during repair shocks are likely to be applied to the sensors due to vibration of the body or direct tapping with tools or other parts.
- Do not reuse a steering wheel pad or front airbag sensors.
After evaluating whether the center airbag sensor assembly is damaged or not, decide whether or not to reuse it. (See the Repair Manual for the method for evaluating the center airbag sensor assembly.)
- When troubleshooting the supplemental restraint system, use a high-impedance (Min. 10kΩ/V) tester.
- The wire harness of the supplemental restraint system is integrated with the cowl wire harness assembly, engine wire harness assembly and instrument panel wire harness assembly.
The vehicle wiring harness exclusively for the airbag system is distinguished by corrugated yellow tubing, as are the connectors.
- Do not measure the resistance of the airbag squibs.
(It is possible this will deploy the airbag and is very dangerous.)
- If the wire harness used in the supplemental restraint system is damaged, replace the whole wire harness assembly.
When the connector to the front airbag sensors can be repaired alone (when there is no damage to the wire harness), use the repair wire specially designed for the purpose.
(Refer to the Repair Manual for the applicable Model year for details of the replacement method.)
- INFORMATION LABELS (NOTICES) are attached to the periphery of the SRS components. Follow the instructions on the notices.



The supplemental restraint system has connectors which possess the functions described below:

1. SRS ACTIVATION PREVENTION MECHANISM


Each connector contains a short spring plate. When the connector is disconnected, the short spring plate automatically connects the power source and grounding terminals of the squib to preclude a potential difference between the terminals.



2. ELECTRICAL CONNECTION CHECK MECHANISM


This mechanism is designed to electrically check if connectors are connected correctly and completely.


The electrical connection check mechanism is designed so that the connection detection pin connects with the diagnosis terminals when the connector housing lock is in the locked condition.



3. CONNECTOR TWIN-LOCK MECHANISM


With this mechanism connectors (male and female connectors) are locked by two locking devices to increase connection reliability. If the primary lock is incomplete, ribs interfere and prevent the secondary lock.





SRS

FROM POWER SOURCE SYSTEM (SEE PAGE 62)



SYSTEM OUTLINE

THE SRS IS A DRIVER AND PASSENGER PROTECTION DEVICE WHICH HAS A SUPPLEMENTAL ROLE TO THE SEAT BELTS.

WHEN THE IGNITION SW IS TURNED TO ACC OR ON, CURRENT FROM THE **CIG & RAD** FUSE FLOWS TO **TERMINAL 14** OF THE CENTER AIRBAG SENSOR ASSEMBLY. ONLY WHEN THE IGNITION SW IS ON DOES CURRENT FROM THE **IGN** FUSE FLOW TO **TERMINAL 13**.

IF AN ACCIDENT OCCURS WHILE DRIVING, DECELERATION CAUSED BY A FRONTAL IMPACT IS DETECTED BY EACH OF THE SENSORS AND THE SWITCH, IN THE CENTER AIRBAG SENSOR ASSEMBLY AND WHEN THE FRONTAL IMPACT EXCEEDS A SET LEVEL (WHEN THE SAFING SENSOR BUILT INTO THE CENTER AIRBAG SENSOR ASSEMBLY IS ON AND THE CENTER AIRBAG SENSOR IS ON, THE FRONT AIRBAG SENSORS ARE OFF), CURRENT FROM THE **CIG & RAD** OR THE **IGN** FUSE FLOWS TO **TERMINALS 3, 2** OF THE CENTER AIRBAG SENSOR ASSEMBLY TO **TERMINAL 1** OF THE AIRBAG SQUIB → **TERMINAL 2** → **TERMINALS 4, 1** OF THE CENTER AIRBAG SENSOR ASSEMBLY → **TERMINAL 5, TERMINAL 6** OR **BODY GROUND** → **GROUND**.

WHEN THE SAFING SENSOR BUILT INTO THE CENTER AIRBAG SENSOR ASSEMBLY IS ON AND THE FRONT AIRBAG SENSOR LH OR RH IS ON, THE CENTER AIRBAG SENSOR IS OFF AND CURRENT FROM THE **CIG & RAD** OR THE **IGN** FUSE FLOWS TO **TERMINALS 3, 2** OF THE CENTER AIRBAG SENSOR ASSEMBLY TO **TERMINAL 1** OF THE AIRBAG SQUIB → **TERMINAL 2** → **TERMINALS 4, 1** OF THE CENTER AIRBAG SENSOR ASSEMBLY → **TERMINAL 8** OR **11** → **TERMINAL 1** OF THE FRONT AIRBAG SENSOR → **TERMINAL 2** → **TERMINAL 9** OR **10** OF THE CENTER AIRBAG SENSOR ASSEMBLY → **TERMINAL 5, TERMINAL 6** OR **BODY GROUND** → **GROUND**, WHEN THE SAFING SENSOR BUILT INTO THE CENTER AIRBAG SENSOR ASSEMBLY IS ON, AND THE FRONT AIRBAG SENSOR LH OR RH IS ON AND THE CENTER AIRBAG SENSOR IS ON, ONE OF THE ABOVE-MENTIONED CIRCUITS IS ACTIVATED SO THAT CURRENT FLOWS TO THE AIRBAG SQUIBS, CAUSING IT TO OPERATE.

THE AIRBAG STORED INSIDE THE STEERING WHEEL PAD IS INSTANTANEOUSLY EXPANDED TO SOFTEN THE SHOCK TO THE DRIVER. SIMULTANEOUSLY, THE AIRBAG STORED INSIDE THE PASSENGER'S INSTRUMENT PANEL IS INSTANTANEOUSLY EXPANDED TO SOFTEN THE SHOCK TO THE PASSENGER.

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A14	32	D1	28 (5S-FE) , 30 (7A-FE)	J4	33
A15	32	F1	28 (5S-FE) , 30 (7A-FE)	J9	33
C2	32	F2	28 (5S-FE) , 30 (7A-FE)		
C8	32	J1	33		

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
ID	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
1B	22	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1C	22	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1D		
1J	22	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
II1	44	ENGINE WIRE AND INSTRUMENT PANEL WIRE (NEAR THE ENGINE CONTROL MODULE)
IJ1	44	ENGINE WIRE AND COWL WIRE (INSTRUMENT PANEL CENTER)


▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EC	38 (5S-FE)	INTAKE MANIFOLD
	40 (7A-FE)	
ID	42	LEFT KICK PANEL
IF	42	R/B NO. 4 SET BOLT




SRS


A14 YELLOW




A15 YELLOW




C 2 YELLOW




C 8 BLUE



(5S-FE) D 1 BLACK



(7A-FE) D 1 BLACK




F 1 YELLOW



F 2 YELLOW



J 1



(HINT:SEE PAGE 7)

(5S-FE) J 4




(HINT:SEE PAGE 7)

(7A-FE) J 4



(HINT:SEE PAGE 7)


J 9



(HINT:SEE PAGE 7)



FROM POWER SOURCE SYSTEM (SEE PAGE 62)



*1 : W/ CRUISE CONTROL
*2 : W/O CRUISE CONTROL

SERVICE HINTS

HORN RELAY

(2) 2- (2) 3 : CLOSED WITH THE HORN SW ON

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C12	A 32	H5	28 (5S-FE) , 30 (7A-FE)		
C13	B 32	H6	28 (5S-FE) , 30 (7A-FE)		

□ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS



CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IC2	42	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)

(*1) C12 (A) BLACK


(*2) C13 (B) BLACK

H 5 BLACK

H 6 BLACK




FROM POWER SOURCE SYSTEM (SEE PAGE 62)



FROM POWER SOURCE SYSTEM (SEE PAGE 62)

*1 : MALFUNCTION INDICATOR LAMP
*2 : W/ CRUISE CONTROL

FROM POWER SOURCE SYSTEM (SEE PAGE 62)



SYSTEM OUTLINE

THIS SYSTEM ELECTRONICALLY CONTROLS THE GEAR SHIFT TIMING, LOCK-UP TIMING, THE CLUTCH AND BRAKE HYDRAULIC PRESSURE, AND THE ENGINE TORQUE DURING SHIFTING TO ACHIEVE OPTIMUM SHIFT FEELING. ACCORDING TO THE VEHICLE DRIVING CONDITIONS AND ENGINE OPERATING CONDITIONS AS DETECTED BY VARIOUS SENSORS.

1. GEAR SHIFT OPERATION

DURING DRIVING, THE ENGINE CONTROL MODULE SELECTS THE SHIFT FOR EACH GEAR WHICH IS MOST APPROPRIATE TO THE DRIVING CONDITIONS, BASED ON INPUT SIGNALS FROM THE ENGINE COOLANT TEMP. SENSOR TO **TERMINAL THW** OF THE ENGINE CONTROL MODULE, AND ALSO THE INPUT SIGNALS TO **TERMINAL SPD** OF THE ENGINE CONTROL MODULE FROM THE VEHICLE SPEED SENSOR DEVOTED TO THE ELECTRONICALLY CONTROLLED TRANSMISSION. CURRENT IS THEN OUTPUT TO THE ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOIDS. WHEN SHIFTING TO 1ST SPEED, CURRENT FLOWS FROM **TERMINAL S1** OF THE ENGINE CONTROL MODULE TO **TERMINAL 3** OF THE ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOID → **GROUND**, AND CONTINUITY TO THE NO.1 SOLENOID CAUSES THE SHIFT.

FOR 2ND SPEED, CURRENT FLOWS FROM **TERMINAL S1** OF THE ENGINE CONTROL MODULE TO **TERMINAL 3** OF THE ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOID → **GROUND**, AND FROM **TERMINAL S2** OF THE ENGINE CONTROL MODULE TO **TERMINAL 1** OF THE ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOID → **GROUND**, AND CONTINUITY TO SOLENOIDS NO.1 AND NO.2 CAUSES THE SHIFT.

FOR 3RD SPEED, THERE IS NO CONTINUITY TO NO.1 SOLENOID, ONLY TO NO.2, CAUSING THE SHIFT.

SHIFTING INTO 4TH SPEED (OVERDRIVE) TAKES PLACE WHEN THERE IS NO CONTINUITY TO EITHER NO.1 OR NO.2 SOLENOID.

2. LOCK-UP OPERATION

WHEN THE ENGINE CONTROL MODULE JUDGES FROM EACH SIGNAL THAT LOCK-UP OPERATION CONDITIONS HAVE BEEN MET, CURRENT FLOWS FROM **TERMINAL SL** OF THE ENGINE CONTROL MODULE TO **TERMINAL 1** (5S-FE), **2** (7A-FE) OF THE ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOIDS → **GROUND**, CAUSING CONTINUITY TO THE LOCK-UP SOLENOID AND CAUSING LOCK-UP OPERATION.

3. STOP LIGHT SW CIRCUIT

IF THE BRAKE PEDAL IS DEPRESSED (STOP LIGHT SW ON) WHEN DRIVING IN LOCK-UP CONDITION, A SIGNAL IS INPUT TO **TERMINAL B/K** OF THE ENGINE CONTROL MODULE, AND THE ENGINE CONTROL MODULE OPERATES AND CONTINUITY TO THE LOCK-UP SOLENOID IS CUT.

4. OVERDRIVE CIRCUIT*** O/D MAIN SW ON**

WHEN THE O/D MAIN SW IS TURNED ON (SW POINT IS OPEN), A SIGNAL IS INPUT TO **TERMINAL OD2** OF THE ENGINE CONTROL MODULE, AND ENGINE CONTROL MODULE OPERATION CAUSES GEAR SHIFT WHEN THE CONDITIONS FOR OVERDRIVE ARE MET.

*** O/D MAIN SW OFF**

WHEN THE O/D MAIN SW IS TURNED OFF (SW POINT IS CLOSED), CURRENT THROUGH THE O/D OFF INDICATOR LIGHT FLOWS THROUGH THE O/D MAIN SW TO **GROUND**, CAUSING THE INDICATOR LIGHT TO LIGHT UP. AT THE SAME TIME, A SIGNAL IS INPUT TO **TERMINAL OD2** OF THE ENGINE CONTROL MODULE AND ENGINE CONTROL MODULE OPERATION PREVENTS SHIFT INTO OVERDRIVE.

SERVICE HINTS

E5 (A), (D), E6 (B), (E), E7 (C), (F) ENGINE CONTROL MODULE

BATT	-E1	: 9.0-14.0 VOLTS (ALWAYS CONTINUITY)
+B	-E1	: 9.0-14.0 VOLTS (IGNITION SW AT ON POSITION)
VTA	-E2	: 0.3-0.8 VOLTS (IGNITION SW ON AND THROTTLE VALVE FULLY CLOSED) 3.2-4.9 VOLTS (IGNITION SW ON AND THROTTLE VALVE OPEN)
PIM	-E2	: 3.3-3.9 VOLTS (IGNITION SW AT ON POSITION)
VC	-E2	: 4.5-5.5 VOLTS (IGNITION SW AT ON POSITION)
SPD	-E1	: 4.5-5.5 VOLTS (IGNITION SW AT ON POSITION)
THW	-E2	: 0.2-1.0 VOLTS (IGNITION SW ON AND COOLANT TEMP. 80°C (176°F))
B/K	-E1	: 9.0-14.0 VOLTS (BRAKE PEDAL DEPRESSED)
S1, S2	-E1	: 9.0-14.0 VOLTS WITH THE IGNITION SW AT ON POSITION (ENGINE RUNNING)
OD1	-E1	: 9.0-14.0 VOLTS
OD2	-E1	: 0-3.0 VOLTS WITH THE O/D MAIN SW TURNED ON 9.0-14.0 VOLTS WITH THE O/D MAIN SW TURNED OFF
2	-E1	: 7.5-14.0 VOLTS WITH THE SHIFT LEVER AT 2 POSITION 0-1.5 VOLTS WITH THE SHIFT LEVER AT EXCEPT 2 POSITION
L	-E1	: 7.5-14.0 VOLTS WITH THE SHIFT LEVER AT L POSITION 0-1.5 VOLTS WITH THE SHIFT LEVER AT EXCEPT L POSITION
R	-E1	: 7.5-14.0 VOLTS WITH THE SHIFT LEVER AT R POSITION (7A-FE) 0-1.5 VOLTS WITH THE SHIFT LEVER AT EXCEPT R POSITION (7A-FE)

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C9	B 32	E5	A 32 (5S-FE)	J7	33
C10	C 32		D 32 (7A-FE)	M1	29 (5S-FE), 31 (7A-FE)
C15	32	E6	B 32 (5S-FE)	O6	33
D1	28 (5S-FE), 30 (7A-FE)		E 32 (7A-FE)	P1	29 (5S-FE), 31 (7A-FE)
E2	A 28 (5S-FE)	E7	C 32 (5S-FE)	S7	33
	B 30 (7A-FE)		F 32 (7A-FE)	T1	29 (5S-FE), 31 (7A-FE)
E3	C 28 (5S-FE)	J2	33	V1	29 (5S-FE), 31 (7A-FE)
E4	28 (5S-FE), 30 (7A-FE)	J3	33		

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
ID	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
IE		
IF		
1A	22	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1C	22	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
3A	24	INSTRUMENT PANEL WIRE AND J/B NO. 3 (BEHIND THE INSTRUMENT PANEL CENTER)
3B		
3C		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	38 (5S-FE)	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (INSIDE OF R/B NO. 2)
	40 (7A-FE)	
ID1	42	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)
II1	44	ENGINE WIRE AND INSTRUMENT PANEL WIRE (NEAR THE ENGINE CONTROL MODULE)
II2		
IJ1	44	ENGINE WIRE AND COWL WIRE (INSTRUMENT PANEL CENTER)


▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EB	38 (5S-FE)	FRONT SIDE OF LEFT FENDER
	40 (7A-FE)	
EC	38 (5S-FE)	INTAKE MANIFOLD
	40 (7A-FE)	
IE	42	INSTRUMENT PANEL BRACE LH


 : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E 6	38 (5S-FE)	ENGINE WIRE	I 8	44	ENGINE WIRE
	40 (7A-FE)		I13		
I 5	44	INSTRUMENT PANEL WIRE			


C 9 




C10  GRAY




C15 GREEN





(5S-FE) D 1 BLACK




(7A-FE) D 1 BLACK




(5S-FE) E 2  BLACK



(7A-FE) E 2  BLACK




(5S-FE) E 3  GRAY




E 4 DARK GRAY




(5S-FE) E 5  DARK GRAY




(7A-FE) E 5  DARK GRAY




(5S-FE) E 6  DARK GRAY




(7A-FE) E 6  DARK GRAY




(5S-FE) E 7  DARK GRAY




(7A-FE) E 7  DARK GRAY




J 2




J 3



J 7



M 1 BLACK




(HINT:SEE PAGE 7)


(HINT:SEE PAGE 7)

(HINT:SEE PAGE 7)


O 6 BLUE




P 1 GRAY



(W/ CRUISE S 7 CONTROL)



(W/O CRUISE S 7 CONTROL)



UNLOCK AND SEAT BELT WARNING



T 1 BLACK




V 1 BLACK




B 6



C 8 (A) BLUE




C 9 (B)



D10




U 1 GRAY





UNLOCK AND SEAT BELT WARNING

FROM POWER SOURCE SYSTEM (SEE PAGE 62)



SYSTEM OUTLINE

CURRENT ALWAYS FLOWS TO **TERMINAL 1** OF THE INTEGRATION RELAY THROUGH THE **DOM**E FUSE.

1. SEAT BELT WARNING SYSTEM

WHEN THE IGNITION SW IS TURNED ON, CURRENT FLOWS FROM THE **GAUGE** FUSE TO **TERMINAL 7** OF THE INTEGRATION RELAY, AT THE SAME TIME, CURRENT FLOWS TO **TERMINAL 9** OF THE RELAY FROM THE **GAUGE** FUSE THROUGH THE SEAT BELT WARNING LIGHT. THIS CURRENT ACTIVATES THE INTEGRATION RELAY AND CURRENT THROUGH THE WARNING LIGHT FLOWS FROM **TERMINAL 9** OF THE RELAY TO **TERMINAL 10** → **GROUND**, CAUSING THE WARNING LIGHT TO LIGHT UP. A BUCKLE SW OFF SIGNAL IS INPUT TO **TERMINAL 8** OF THE RELAY, CURRENT TO **TERMINAL 7** OF THE RELAY FLOWS FROM **TERMINAL 10** TO **GROUND** AND THE SEAT BELT WARNING BUZZER SOUNDS FOR APPROX. **4-8** SECONDS. HOWEVER, IF THE SEAT BELT IS PUT ON DURING THIS PERIOD (WHILE THE BUZZER IS SOUNDING), SIGNAL INPUT TO **TERMINAL 8** OF THE RELAY STOPS AND THE CURRENT FLOWING FROM **TERMINAL 7** OF THE RELAY TO **TERMINAL 10** → **GROUND** IS CUT, CAUSING THE BUZZER TO STOP.

2. UNLOCK WARNING SYSTEM

WITH THE IGNITION KEY INSERTED IN THE IGNITION KEY CYLINDER (UNLOCK SW ON), THE IGNITION SW STILL OFF AND THE DRIVER'S DOOR OPEN (DOOR COURTESY SW ON), WHEN A SIGNAL IS INPUT TO **TERMINAL 6** OF THE RELAY, THE INTEGRATION RELAY OPERATES, CURRENT FLOWS FROM **TERMINAL 7** OF THE RELAY TO **TERMINAL 10** → **GROUND** AND THE UNLOCK WARNING BUZZER SOUNDS.

SERVICE HINTS

B 6 BUCKLE SW LH

1-2 : CLOSED WITH THE DRIVER'S SEAT BELT IN USE

D10 DOOR COURTESY SW LH

1-GROUND : CLOSED WITH THE LH DOOR OPEN

U 1 UNLOCK WARNING SW

2-1 : CLOSED WITH THE IGNITION KEY IN THE CYLINDER

INTEGRATION RELAY

10-GROUND : ALWAYS CONTINUITY

6-GROUND : CONTINUITY WITH THE DRIVER'S DOOR OPEN

5-GROUND : CONTINUITY WITH THE IGNITION KEY IN THE CYLINDER

8-GROUND : CONTINUITY WITH THE DRIVER'S SEAT BELT IN USE

9-GROUND : 0 VOLTS WITH THE IGNITION SW ON AND THE BUCKLE SW OFF

1-GROUND : ALWAYS APPROX. 12 VOLTS

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE	
B6	34 (L/B), 35 (C/P)	C9	B	32	U1	33
	36 (CONVERTIBLE)	D10		34 (L/B), 35 (C/P)		
C8	A		32	36 (CONVERTIBLE)		

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IC	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
ID		
IE		
IF		
IH		
1A	22	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1C	22	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
3B	24	INSTRUMENT PANEL WIRE AND J/B NO. 3 (BEHIND THE INSTRUMENT PANEL CENTER)
3C		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IG1	42	INSTRUMENT PANEL WIRE AND FLOOR WIRE (LEFT KICK PANEL)


▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	42	INSTRUMENT PANEL BRACE LH
BH	46 (L/B)	UNDER THE LEFT CENTER PILLAR
	48 (C/P)	
	50 (CONVERTIBLE)	



ELECTRIC TENSION REDUCER

FROM POWER SOURCE SYSTEM (SEE PAGE 62)



SERVICE HINTS

B 6 BUCKLE SW LH

1-2 : CLOSED WITH THE DRIVER'S SEAT BELT IN USE

B 7 BUCKLE SW RH

1-2 : CLOSED WITH THE PASSENGER'S SEAT BELT IN USE

T 4, T 5 TENSION REDUCER SOLENOID LH, RH

1-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
B 6	34 (L/B), 35 (C/P)	B 7	36 (CONVERTIBLE)	T 5	34 (L/B), 35 (C/P)
	36 (CONVERTIBLE)	T 4	34 (L/B), 35 (C/P)		37 (CONVERTIBLE)
B 7	34 (L/B), 35 (C/P)	T 4	37 (CONVERTIBLE)		

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
ID	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
1C	22	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT KICK PANEL)
1F	22	FLOOR WIRE AND J/B NO.1 (LEFT KICK PANEL)


▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
BH	46 (L/B)	UNDER THE LEFT CENTER PILLAR
	48 (C/P)	
	50 (CONVERTIBLE)	


○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
B 5	46 (L/B)	FLOOR WIRE	B 5	50 (CONVERTIBLE)	FLOOR WIRE
	48 (L/B)				

B 6




B 7



T 4




T 5





REAR WINDOW DEFOGGER



SERVICE HINTS

DEFOGGER RELAY

5-3 : CLOSED WITH THE IGNITION SW AT **ON** POSITION AND THE DEFOGGER SW ON

R 4 REAR WINDOW DEFOGGER

5-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION

4-GROUND : ALWAYS CONTINUITY

○ : PARTS LOCATION

CODE	SEE PAGE		CODE	SEE PAGE		CODE	SEE PAGE	
E7	A	32 (5S-FE)	J9	33		R11	A	37 (CONVERTIBLE)
	B	32 (7A-FE)	R4	33		R12	B	34 (L/B), 35 (C/P)
J6	33		R11	A	34 (L/B), 35 (C/P)			37 (CONVERTIBLE)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IE	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
IF		
IG		
IH		
3C	24	INSTRUMENT PANEL WIRE AND J/B NO. 3 (BEHIND THE INSTRUMENT PANEL CENTER)


□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
ID1	42	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)
IG1	42	INSTRUMENT PANEL WIRE AND FLOOR WIRE (LEFT KICK PANEL)
II1	44	ENGINE WIRE AND INSTRUMENT WIRE (NEAR THE ENGINE CONTROL MODULE)
BO1	46 (L/B)	BACK DOOR NO. 1 WIRE AND FLOOR WIRE (BACK DOOR UPPER LEFT)
BP1	46 (L/B)	BACK DOOR NO. 2 WIRE AND BACK DOOR NO. 1 WIRE (BACK DOOR UPPER LEFT)


▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	42	INSTRUMENT PANEL BRACE LH
IF	42	R/B NO. 4 SET BOLT
BJ	48 (C/P)	RIGHT REAR PILLAR
BL	50 (CONVERTIBLE)	ROOM PARTITION PANEL
BM	46 (L/B)	BACK DOOR RIGHT


(5S-FE A/T) E 7 Ⓐ DARK GRAY




(5S-FE M/T) E 7 Ⓐ DARK GRAY




(7A-FE A/T) E 7 Ⓑ DARK GRAY



(7A-FE M/T) E 7 Ⓑ DARK GRAY



J 6



(HINT:SEE PAGE 7)

J 9



(HINT:SEE PAGE 7)

R 4



(L/B,C/P) R11 Ⓐ BLACK



(CONVERTIBLE) R11 Ⓐ GRAY




R12 Ⓑ BLACK





AUTO ANTENNA

*1: SEPARATE TYPE AMPLIFIER *3: L/B
 *2: BUILT-IN TYPE AMPLIFIER *4: C/P, CONVERTIBLE



SERVICE HINTS

A19 AUTO ANTENNA MOTOR AND RELAY

2-GROUND : ALWAYS APPROX. 12 VOLTS

5-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION

6-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ACC** OR **ON** POSITION

1-GROUND : ALWAYS CONTINUITY

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A19	34 (L/B), 35 (C/P)	R 3	33		
	36 (CONVERTIBLE)	S 4	33		

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
ID	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
IE		
1A	22	ENGINE ROOM MAIN WIRE AND J/B NO.1 (LEFT KICK PANEL)
1C	22	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT KICK PANEL)
1F	22	FLOOR WIRE AND J/B NO.1 (LEFT KICK PANEL)
3C	24	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)


□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IH1	42	FLOOR WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IK2	44	INSTRUMENT PANEL WIRE AND FLOOR NO.3 WIRE (BEHIND THE RADIO AND PLAYER)
BQ2	46 (L/B)	FLOOR WIRE AND LUGGAGE ROOM WIRE (LUGGAGE ROOM LEFT)


▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
BH	48 (C/P)	UNDER THE LEFT CENTER PILLAR
	50 (CONVERTIBLE)	
BK	46 (L/B)	BACK DOOR CENTER


A19



R 3 BLUE




S 4






RADIO AND PLAYER (SEPARATE TYPE AMPLIFIER)

FROM POWER SOURCE SYSTEM (SEE PAGE 62)



*1: L/B, C/P *3 :L/B
 *2 :CONVERTIBLE *4 : C/P. CONVERTIBLE *5 :W/ CD PLAYER





RADIO AND PLAYER (SEPARATE TYPE AMPLIFIER)

SERVICE HINTS

S 4 (A) STEREO COMPONENT AMPLIFIER

- (A) 6-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT ACC OR ON POSITION
- (A) 7, (A) 16-GROUND : ALWAYS APPROX. 12 VOLTS
- (A) 12-GROUND : ALWAYS CONTINUITY

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A19	34 (L/B), 35 (C/P)	R 9	B	T11	34 (L/B), 35 (C/P)
	36 (CONVERTIBLE)	R10	A		37 (CONVERTIBLE)
F 8	34 (L/B), 35 (C/P)		S 4	B	W 4
	36 (CONVERTIBLE)	A		33	
F 9	34 (L/B), 35 (C/P)	S 5	B	W 5	B
	36 (CONVERTIBLE)		A		
R 2	33	T10	C	W 6	34 (L/B), 35 (C/P)
R 9	A				34 (L/B), 35 (C/P)
				W 7	34 (L/B), 35 (C/P)
					37 (CONVERTIBLE)

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IE	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
3C	24	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IC2	42	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
ID1	42	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)
IE2	42	FRONT DOOR LH WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IH1	42	FLOOR WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IK1	44	INSTRUMENT PANEL WIRE AND FLOOR NO.3 WIRE (BEHIND THE RADIO AND PLAYER)
IK2		
IK3		
IN2	44	FRONT DOOR RH WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)
BQ2	46 (L/B)	FLOOR WIRE AND LUGGAGE ROOM WIRE (LUGGAGE ROOM LEFT)


▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	42	INSTRUMENT PANEL BRACE LH

○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I 9	44	FLOOR NO.3 WIRE	B 3	50 (CONVERTIBLE)	FRONT DOOR LH WIRE
I14	44	RADIO SUB WIRE	B 7	46 (L/B)	FRONT DOOR RH WIRE
B 3	46 (L/B)	FRONT DOOR LH WIRE		48 (C/P)	
	48 (C/P)			50 (CONVERTIBLE)	

*1 : L/B, C/P
 *2 : CONVERTIBLE






RADIO AND PLAYER

FROM POWER SOURCE SYSTEM (SEE PAGE 62)

- *1 : L/B
- *2 : C/P, CONVERTIBLE
- *3 : 6 SPEAKER
- *4 : L/B, C/P
- *5 : CONVERTIBLE



(BUILT-IN TYPE AMPLIFIER)

*4 : L/B, C/P
*5 : CONVERTIBLE

SERVICE HINTS

R 3 (B) RADIO AND PLAYER

- (B) 4-GROUND : ALWAYS APPROX. 12 VOLTS
- (B) 3-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT ACC OR ON POSITION
- (B) 7-GROUND : ALWAYS CONTINUITY

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A19	34 (L/B), 35 (C/P)	R 2	A 33	T10	34 (L/B), 35 (C/P)
	36 (CONVERTIBLE)	R 3	B 33		37 (CONVERTIBLE)
F 8	34 (L/B), 35 (C/P)	R 9	A 34 (L/B), 35 (C/P)	T11	34 (L/B), 35 (C/P)
	36 (CONVERTIBLE)		B 37 (CONVERTIBLE)		37 (CONVERTIBLE)
F 9	34 (L/B), 35 (C/P)	R10	A 34 (L/B), 35 (C/P)		
	36 (CONVERTIBLE)		B 37 (CONVERTIBLE)		

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IE	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
3C	24	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IC2	42	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
ID1	42	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)
IE2	42	FRONT DOOR LH WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IH1	42	FLOOR WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IN2	44	FRONT DOOR RH WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)
BQ2	46 (L/B)	FLOOR WIRE AND LUGGAGE ROOM WIRE (LUGGAGE ROOM LEFT)

▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	42	INSTRUMENT PANEL BRACE LH

○ : SPLICE POINTS


CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
B 3	46 (L/B)	FRONT DOOR LH WIRE	B 7	46 (L/B)	FRONT DOOR RH WIRE
	48 (C/P)			48 (C/P)	
	50 (CONVERTIBLE)			50 (CONVERTIBLE)	





TOP STACK

FROM POWER SOURCE SYSTEM (SEE PAGE 62)



SERVICE HINTS

T 2 TOP STACK CONTROL SW

- 3-5 : CLOSED WITH THE TOP STACK SW AT **OPEN** POSITION
- 3-6 : CLOSED WITH THE TOP STACK SW AT **CLOSE** POSITION

T 3 TOP STACK MAIN RELAY

- 4-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION
- 1-GROUND : 4 PULSE WITH 1 ROTATION OF ROTOR SHAFT
- 2-GROUND : ALWAYS CONTINUITY

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C 9	32	T 3	33	T 8	37
J 7	33	T 6	37	T 9	37
T 2	33	T 7	37	V 1	29 (5S-FE)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
ID	20	INSTRUMENT PANEL AND FLOOR WIRE (LEFT KICK PANEL)
IE		
3B	24	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)
3C		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IG1	42	INSTRUMENT PANEL WIRE AND FLOOR WIRE WIRE (LEFT KICK PANEL)
IH1	42	FLOOR WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
II1	44	ENGINE WIRE AND INSTRUMENT PANEL WIRE (NEAR THE ENGINE CONTROL MODULE)
II2		

▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	42	INSTRUMENT PANEL BRACE LH
BH	50 (CONVERTIBLE)	UNDER THE LEFT CENTER PILLAR


○ : SPLICE POINTS


CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
B13	50 (CONVERTIBLE)	FLOOR WIRE			





COMBINATION METER (USA)







COMBINATION METER (USA)

SERVICE HINTS

B 2 BRAKE FLUID LEVEL WARNING SW

1-2 : CLOSED WITH THE FLOAT DOWN

P 2 PARKING BRAKE SW

1-GROUND : CLOSED WITH THE PARKING BRAKE LEVER PULLED UP

O 1 OIL PRESSURE SW

1-GROUND : OPENED WITH THE OIL PRESSURE ABOVE APPROX. 0.2 KG/CM² (2.8 PSI, 19.6 KPA)

W 2 WATER TEMP. SENDER

1-GROUND : APPROX. 160-240 Ω (50° C, 122° F)
APPROX. 17.1- 20.4 Ω (120° C, 248° F)

F10 FUEL SENDER

1-2 : APPROX. 3 Ω AT FUEL FULL
APPROX. 110 Ω AT FUEL EMPTY

C 8 (A), C 9 (B), C10 (C) COMBINATION METER

(A) 8, (B) 4-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT ON POSITION

(B) 6, (B) 16, (C) 4-GROUND : ALWAYS CONTINUITY

(A) 3, (B) 10-GROUND : ALWAYS APPROX. 12 VOLTS

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
B 2	28 (5S-FE), 30 (7A-FE)	F10	34 (L/B), 35 (C/P)	P 1	29 (5S-FE), 31 (7A-FE)
C 7	32		36 (CONVERTIBLE)	P 2	33
C 8	A 32	G 1	28 (5S-FE), 30 (7A-FE)	V 1	29 (5S-FE), 31 (7A-FE)
C 9	B 32	J 7	33	W 2	29 (5S-FE), 31 (7A-FE)
C10	C 32	O 1	29 (5S-FE), 31 (7A-FE)		

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
ID	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
IE		
IF		
1A	22	ENGINE ROOM MAIN WIRE AND J/B NO.1 (LEFT KICK PANEL)
1C	22	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT KICK PANEL)
1D		
1J	22	COWL WIRE AND J/B NO.1 (LEFT KICK PANEL)
3B	24	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)
3C		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IC2	42	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
ID1	42	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)
IG1	42	INSTRUMENT PANEL WIRE AND FLOOR WIRE (LEFT KICK PANEL)
II1	44	ENGINE WIRE AND INSTRUMENT PANEL WIRE (NEAR THE ENGINE CONTROL MODULE)
II2		
IJ1	44	ENGINE WIRE AND COWL WIRE (INSTRUMENT PANEL CENTER)


▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EB	38 (5S-FE)	FRONT SIDE OF LEFT FENDER
	40 (7A-FE)	
EC	38 (5S-FE)	INTAKE MANIFOLD
	40 (7A-FE)	
IE	42	INSTRUMENT PANEL BRACE LH


B 2 GRAY




C 7




C 8 (A) BLUE




C 9 (B)




C10 (C) GRAY




F10 DARK GRAY



G 1 BLACK



J 7




(HINT:SEE PAGE 7)

O 1 BLACK



P 1 GRAY



P 2 BLACK



V 1 BLACK




W 2 GRAY





COMBINATION METER (CANADA)





COMBINATION METER (CANADA)

SERVICE HINTS

B 2 BRAKE FLUID LEVEL WARNING SW

1-2: CLOSED WITH THE FLOAT DOWN

P 2 PARKING BRAKE SW

1-GROUND : CLOSED WITH THE PARKING BRAKE LEVER PULLED UP

O 1 OIL PRESSURE SW

1-GROUND : OPENED WITH THE OIL PRESSURE ABOVE APPROX. 0.2 KG/CM² (2.8 PSI, 19.6 KPA)

W 2 WATER TEMP. SENDER

1-GROUND : APPROX. 160-240 Ω (50°C, 122°F)
APPROX. 17.1-20.4 Ω (120°C, 248°F)

F10 FUEL SENDER

1-2 : APPROX. 3 Ω AT FUEL FULL
APPROX. 110 Ω AT FUEL EMPTY

C 8 (A), C 9 (B), C10 (C) COMBINATION METER

(A) 8, (B) 4-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT ON POSITION

(B) 6, (B) 9, (B) 16, (C) 4 -GROUND : ALWAYS CONTINUITY

(A) 3, (B) 10-GROUND : ALWAYS APPROX. 12 VOLTS

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
B2	28 (5S-FE) 30 (7A-FE)	D3	32	P1	29 (5S-FE) 31 (7A-FE)
C7	32	F10	34 (L/B)	P2	33
C8	A 32	G1	28 (5S-FE) 30 (7A-FE)	V1	29 (5S-FE) 31 (7A-FE)
C9	B 32	J7	33	W2	29 (5S-FE) 31 (7A-FE)
C10	C 32	O1	29 (5S-FE) 31 (7A-FE)		

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	R/B NO. 2 (ENGINE COMPARTMENT LEFT)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
ID	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
IE		
IF		
1A	22	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1C	22	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1D		
1J	22	COWL WIRE AND J/B NO.1 (LEFT KICK PANEL)
3B	24	INSTRUMENT PANEL WIRE AND J/B NO. 3 (BEHIND THE INSTRUMENT PANEL CENTER)
3C		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IC2	42	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
ID1	42	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)
IG1	42	INSTRUMENT PANEL WIRE AND FLOOR WIRE (LEFT KICK PANEL)
II1	44	ENGINE WIRE AND INSTRUMENT PANEL WIRE (NEAR THE ENGINE CONTROL MODULE)
II2		
IJ1	44	ENGINE WIRE AND COWL WIRE (INSTRUMENT PANEL CENTER)

▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EB	38 (5S-FE)	FRONT SIDE OF LEFT FENDER
	40 (7A-FE)	
EC	38 (5S-FE)	INTAKE MANIFOLD
	40 (7A-FE)	
IE	42	INSTRUMENT PANEL BRACE LH

○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I4	44	INSTRUMENT PANEL WIRE			


B 2 GRAY




C 7




C 8 (A) BLUE




C 9 (B)



C10 (C) GRAY




D 3 GRAY




F10 DARK GRAY



G 1 BLACK




J 7




(HINT: SEE PAGE 7)

O 1 BLACK



P 1 GRAY



P 2 BLACK



V 1 BLACK



W 2 GRAY






RADIATOR FAN AND CONDENSER FAN

*1 :5S-FE *3 :W/ ABS
 *2 :7A-FE *4 :W/O ABS

FROM POWER SOURCE SYSTEM (SEE PAGE 62)



SYSTEM OUTLINE

1. FAN MOTOR OPERATION

WHEN THE IGNITION SW IS TURNED ON, CURRENT FROM THE **ECU-IG** FUSE FLOWS TO THE FAN NO.1 RELAY (COIL SIDE) AND THE FAN NO.2 RELAY (COIL SIDE) → **TERMINAL 3** OF THE A/C SINGLE PRESSURE SW → **TERMINAL 2** → **TERMINAL 2** (5S-FE), 1 (7A-FE) OF THE WATER TEMP. SW (RADIATOR FAN) → **TERMINAL 1** (5S-FE) → **GROUND**, AND THE FAN NO.1 RELAY AND THE FAN NO.2 RELAY ARE TURNED ON.

AT THE SAME TIME THAT THIS CURRENT FLOWS, CURRENT FROM THE **ECU-IG** FUSE FLOWS TO THE E/G MAIN RELAY (COIL SIDE) TO **GROUND**, CAUSING THE E/G MAIN RELAY TO TURN ON. AS A RESULT, CURRENT FROM THE **ALT** FUSE FLOWS TO THE **CDS** FUSE AND **RDI** FUSE.

* LOW SPEED OPERATION

WHEN THE IGNITION SW IS TURNED ON AND THE A/C IS ACTIVATED, CURRENT FLOWS FROM THE A/C COMP RELAY (POINT SIDE) TO THE FAN NO.3 RELAY (COIL SIDE) → **GROUND**, CAUSING THE FAN NO.3 RELAY TO TURN ON. AS A RESULT, CURRENT FROM THE **CDS** FUSE FLOWS TO **TERMINAL 2** OF THE A/C CONDENSER FAN MOTOR → **TERMINAL 1** → THE FAN NO.2 RELAY (POINT SIDE) → THE FAN NO.3 RELAY (POINT SIDE) → **TERMINAL 2** OF THE RADIATOR FAN MOTOR → **TERMINAL 1** → **GROUND**, AND EACH OF THE FAN MOTOR. WITH THE RESULT THAT THE FANS ARE ACTIVATED AT LOW SPEED.

IF THE ENGINE COOLANT TEMPERATURE IS APPROX. **90°C (194°F)** OR LESS, AND THE REFRIGERANT PRESSURE IS APPROX. **15.5 KG/CM² (220 PSI, 1520 KPA)** OR LESS, BOTH THE WATER TEMP. SW (FOR RADIATOR FAN) AND THE A/C DUAL PRESSURE SW ARE CLOSED, SO THAT THE FAN NO.1 RELAY AND THE FAN NO.2 RELAY ARE TURNED ON. AS A RESULT, EACH OF THE FAN MOTORS OPERATE AT LOW SPEED.

* HIGH SPEED OPERATION

WHEN, DURING A/C OPERATION, THE REFRIGERANT PRESSURE BECOMES HIGHER THAN ORDINARY LEVEL (APPROX. **15.5 KG/CM² (220 PSI, 1520 KPA)**), THE A/C SINGLE PRESSURE SW IS TURNED OFF. AS A RESULT, THE FAN NO.1 RELAY AND THE FAN NO.2 RELAY ARE TURNED OFF, AND CURRENT FLOWS FROM THE **RDI** FUSE TO FAN NO.1 RELAY (POINT SIDE) → **TERMINAL 2** OF THE RADIATOR FAN MOTOR → **TERMINAL 1** → **GROUND**, AND CURRENT FROM THE **CDS** FUSE FLOWS TO **TERMINAL 2** OF THE A/C CONDENSER FAN MOTOR → **TERMINAL 1** → THE FAN NO.2 RELAY (POINT SIDE) → **GROUND**, AND TO EACH OF THE FAN MOTOR IN PARALLEL, THUS CAUSING THE FAN MOTOR TO OPERATE AT HIGH SPEED.

NOTE THAT, BECAUSE CURRENT FLOWS IN THE SAME MANNER EVEN IF THE ENGINE WATER TEMPERATURE IS APPROX. **90°C (194°F)** OR HIGHER, THE FAN MOTOR STILL OPERATES AT HIGH SPEED.

SERVICE HINTS

A 3 A/C SINGLE PRESSURE SW

3-2 : OPEN ABOVE APPROX. **15.5 KG/CM² (220 PSI, 1520 KPA)**
CLOSE BELOW APPROX. **12.5 KG/CM² (178 PSI, 1226 KPA)**

W 3 WATER TEMP. SW (RADIATOR FAN) (5S-FE)

2-1 : OPEN ABOVE APPROX. **90°C (194°F)**
CLOSED BELOW APPROX. **83°C (181.4°F)**

W 3 WATER TEMP. SW (RADIATOR FAN) (7A-FE)

1-GROUND : OPEN ABOVE APPROX. **90°C (194°F)**
CLOSED BELOW APPROX. **83°C (181.4°F)**

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A 1	28 (5S-FE), 30 (7A-FE)	J 1	33	W 3	29 (5S-FE), 31 (7A-FE)
A 3	28 (5S-FE), 30 (7A-FE)	J 9	33		
E 7	32	R 1	29 (5S-FE), 31 (7A-FE)		

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT
5	27	ENGINE COMPARTMENT FRONT RIGHT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
ID	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
1A	22	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1C	22	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)



RADIATOR FAN AND CONDENSER FAN

☐ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	38 (5S-FE)	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (INSIDE OF R/B NO. 2)
	40 (7A-FE)	
IC2	42	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IC3	42	ENGINE ROOM MAIN WIRE AND COWL WIPER (INSIDE OF R/B NO. 4)

▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EA	38 (5S-FE)	FRONT SIDE OF RIGHT FENDER
	40 (7A-FE)	
ID	42	LEFT KICK PANEL
IF	42	R/B NO. 4 SET BOLT


○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E1	38 (5S-FE)	ENGINE ROOM MAIN WIRE	E2	40 (7A-FE)	ENGINE ROOM MAIN WIRE
	40 (7A-FE)		E4	38 (5S-FE)	
E2	38 (5S-FE)			40 (7A-FE)	


A 1 BLACK




A 3 GRAY




(5S-FE A/T) E 7 DARK GRAY



(5S-FE M/T) E 7 DARK GRAY




J 1




(HINT:SEE PAGE 7)

J 9



(HINT:SEE PAGE 7)

R 1 GRAY



(5S-FE) W 3 GRAY




(7A-FE) W 3 DARK GRAY






AIR CONDITIONING


FROM POWER SOURCE SYSTEM (SEE PAGE 62)







AIR CONDITIONING



SYSTEM OUTLINE

1. HEATER BLOWER MOTOR OPERATION

CURRENT IS APPLIED AT ALL TIMES THROUGH THE **HTR FUSE (40A)** TO **TERMINAL 2** OF THE HEATER RELAY.

WHEN THE IGNITION SW IS TURNED ON, CURRENT FLOWS THROUGH THE **HTR FUSE (10A)** TO **TERMINAL 3** OF THE HEATER RELAY → THE COIL SIDE → **TERMINAL 5** → **TERMINAL 8** OF THE BLOWER SW.

* LOW SPEED OPERATION

WHEN THE BLOWER SW IS MOVED TO **LO** POSITION, CURRENT FLOWS TO **TERMINAL 8** OF THE BLOWER SW → **TERMINAL 1** → **GROUND**, CAUSING THE HEATER RELAY TO SWITCH ON. THIS CAUSES THE CURRENT TO FLOW FROM THE **HTR FUSE (40A)** TO **TERMINAL 2** OF THE HEATER RELAY → **TERMINAL 1** → **TERMINAL 2** OF THE BLOWER MOTOR → **TERMINAL 1** → **TERMINAL 1** OF THE BLOWER RESISTOR → **TERMINAL 4** → **GROUND**, CAUSING THE BLOWER MOTOR TO ROTATE AT LOW SPEED.

* MEDIUM SPEED OPERATION (OPERATION AT M1, M2)

WHEN THE BLOWER SW IS MOVED TO **M1** POSITION, CURRENT FLOWS TO **TERMINAL 8** OF THE BLOWER SW → **TERMINAL 1** → **GROUND**, TURNING THE HEATER RELAY TO SWITCH ON. THIS CAUSES THE CURRENT TO FLOW FROM THE **HTR FUSE (40A)** TO **TERMINAL 2** OF THE HEATER RELAY → **TERMINAL 1** → **TERMINAL 2** OF THE BLOWER MOTOR → **TERMINAL 1** → **TERMINAL 1** OF THE BLOWER RESISTOR → **TERMINAL 2** → **TERMINAL 6** OF THE BLOWER SW → **TERMINAL 1** → **GROUND**. AT THIS TIME, THE BLOWER RESISTANCE OF THE BLOWER RESISTOR IS LESS THAN AT LOW SPEED, SO THE BLOWER MOTOR ROTATES AT MEDIUM LOW SPEED.

WHEN THE BLOWER SW IS MOVED TO **M2** POSITION, CURRENT FLOWS THROUGH THE MOTOR FLOWS FROM **TERMINAL 1** OF THE BLOWER RESISTOR TO **TERMINAL 3** → **TERMINAL 5** OF THE BLOWER SW → **TERMINAL 1** → **GROUND**. AT THIS TIME, RESISTANCE OF THE BLOWER RESISTOR IS LESS THAN AT **M1** POSITION, SO THE BLOWER MOTOR ROTATES AT MEDIUM HIGH SPEED.

* HIGH SPEED OPERATION

WHEN THE BLOWER SW IS MOVED TO HIGH POSITION, CURRENT FLOWS TO **TERMINAL 8** OF THE BLOWER SW → **TERMINAL 1** → **GROUND**, TURNING THE HEATER RELAY TO SWITCH ON.

THIS CAUSES THE CURRENT TO FLOW FROM THE **HTR FUSE (40A)** TO **TERMINAL 2** OF THE HEATER RELAY → **TERMINAL 1** → **TERMINAL 2** OF THE BLOWER MOTOR → **TERMINAL 1** → **TERMINAL 4** OF THE BLOWER SW → **TERMINAL 1** → **GROUND**, CAUSING THE BLOWER MOTOR TO ROTATE AT HIGH SPEED.

2. OPERATION OF AIR INLET CONTROL SERVO MOTOR

* SWITCHING FROM FRESH TO RECIRC

WITH THE IGNITION SW TURNED ON, CURRENT FLOWS FROM THE **HTR FUSE (10A)** TO **TERMINAL 1** OF THE AIR INLET CONTROL SERVO MOTOR. WHEN THE RECIRC/FRESH SW IS SWITCHED TO THE RECIRC SIDE, CURRENT FLOWS FROM **TERMINAL 1** OF THE AIR INLET CONTROL SERVO MOTOR TO **TERMINAL 2** → **TERMINAL 17** OF THE HEATER CONTROL SW → **TERMINAL 22** → **GROUND**. THE MOTOR ROTATES AND THE DAMPER MOVES TO THE RECIRC SIDE. WHEN IT IS IN THE **RECIRC** POSITION, CURRENT IS CUT INSIDE THE SERVO MOTOR AND THE DAMPER STOPS AT THAT POSITION.

* SWITCHING FROM RECIRC TO FRESH

WITH THE IGNITION SW TURNED ON, WHEN THE RECIRC/FRESH SW IS SWITCHED TO THE FRESH SIDE, CURRENT FLOWS FROM **TERMINAL 1** OF THE AIR INLET CONTROL SERVO MOTOR TO **TERMINAL 3** → **TERMINAL 16** OF THE HEATER CONTROL SW → **TERMINAL 22** → **GROUND**. THE MOTOR ROTATES AND THE DAMPER MOVES TO THE FRESH SIDE. WHEN IT IS IN THE **FRESH** POSITION, CURRENT IS CUT INSIDE THE SERVO MOTOR AND THE DAMPER STOPS AT THAT POSITION.

3. OPERATION OF AIR VENT MODE CONTROL SERVO MOTOR

WITH THE IGNITION SW TURNED ON, CURRENT FLOWS FROM **HTR (10A)** FUSE TO **TERMINAL 5** OF THE AIR VENT MODE CONTROL SERVO MOTOR → **TERMINAL 6** → **GROUND**, AND THE DAMPER MOVES TO THE POSITION OF THE MODE SELECTION SW OF THE HEATER CONTROL SWITCH ON. WHEN THE MODE SELECTION SW OF THE HEATER CONTROL SW IS MOVED TO **DEF** POSITION FROM THE DAMPER IN THE **FACE** POSITION, CURRENT FLOWS FROM **TERMINAL 7** OF THE AIR VENT MODE CONTROL SERVO MOTOR TO **TERMINAL 3** OF THE HEATER CONTROL SW → **TERMINAL 22** → **GROUND**. AS A RESULT, THE SERVO MOTOR OPERATES UNTIL THE DAMPER REACHES **DEF** POSITION. WHEN THIS OCCURS THE CURRENT TO THE HEATER CONTROL SW IS SHUT OFF AND ROTATION OF THE MOTOR STOPS. SWITCHING TO OTHER MODES IS CONTROLLED BY THE SERVO MOTOR ACCORDING THE FLOWING CURRENT:

1. **FOOT/DEF** POSITION : CURRENT FLOWS FROM **TERMINAL 4** OF THE SERVO MOTOR TO **TERMINAL 4** OF THE HEATER CONTROL SW.

2. **FOOT** POSITION : CURRENT FLOWS FROM **TERMINAL 3** OF THE SERVO MOTOR TO **TERMINAL 5** OF THE HEATER CONTROL SW.

3. **BI-LEVEL** POSITION : CURRENT FLOWS FROM **TERMINAL 2** OF THE SERVO MOTOR TO **TERMINAL 6** OF THE HEATER CONTROL SW.

4. **FACE** POSITION : CURRENT FLOWS FROM **TERMINAL 1** OF THE SERVO MOTOR TO **TERMINAL 7** OF THE HEATER CONTROL SW.



AIR CONDITIONING

SERVICE HINTS

A 3 A/C DUAL PRESSURE SW

1-4 : OPEN WITH THE PRESSURE LESS THAN **2.0 KG/CM² (28.4 PSI, 196 KPA)** OR ABOVE **32 KG/CM² (455 PSI, 3138 KPA)**

A 8 A/C AMPLIFIER

14-6 : CONTINUITY WITH THE A/C SW (HEATER CONTROL SW) ON AND THE IGNITION SW AT **ON** POSITION

15-GROUND : ALWAYS CONTINUITY

6-GROUND : ALWAYS CONTINUITY

14-GROUND : APPROX. **12 VOLTS** WITH THE IGNITION SW ON

A 9 A/C THERMISTOR

1-2 : APPROX. **2341 ± 234 Ω** AT **15°C (59°F)**

B 4 BLOWER RESISTOR

1-3 : APPROX. **0.47 Ω**

1-2 : APPROX. **1.42 Ω**

1-4 : APPROX. **2.28 Ω**

B 5 BLOWER SW

8-1 : CONTINUITY WITH THE BLOWER SW AT **LO, M1, M2** AND **HI** POSITIONS

6-1 : CONTINUITY WITH THE BLOWER SW AT **M1** POSITION

5-1 : CONTINUITY WITH THE BLOWER SW AT **M2** POSITION

4-1 : CONTINUITY WITH THE BLOWER SW AT **HI** POSITION

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A 2	28 (5S-FE), 30 (7A-FE)	A13	32	H 8	33
A 3	28 (5S-FE), 30 (7A-FE)	B 3	32	I 2	29 (5S-FE)
A 8	32	B 4	32	J 5	33
A 9	32	B 5	32	J 6	33
A12	32	E 7	32	J 9	33

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	26	ENGINE COMPARTMENT LEFT
4	25	RIGHT KICK PANEL
5	27	ENGINE COMPARTMENT FRONT RIGHT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IA	20	ENGINE ROOM MAIN WIRE AND INPANE J/B (LEFT KICK PANEL)
IF	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	38 (5S-FE)	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (INSIDE OF R/B NO.2)
	40 (7A-FE)	
IC3	42	ENGINE ROOM MAIN WIRE AND COWL WIRE (INSIDE OF R/B NO.4)
ID1	42	INSTRUMENT PANEL WIRE AND COWL WIRE (LEFT KICK PANEL)
IL1	44	COWL WIRE AND A/C SUB WIRE (UPPER THE A/C UNIT)
IM1	44	ENGINE WIRE AND A/C SUB WIRE (NEAR THE BLOWER MOTOR)

▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IF	42	R/B NO.4 SET BOLT


○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I11	44	COWL WIRE	I16	44	A/C SUB WIRE


(5S-FE) A 2 GRAY




(7A-FE) A 2 GRAY




A 3 GRAY



(5S-FE) A 8 BLACK



(7A-FE) A 8 BLACK



A 9




A12 BLUE




A13 BLACK




B 3 BLACK




B 4 BLACK




B 5




(5S-FE A/T) E 7 DARK GRAY




(5S-FE M/T) E 7 DARK GRAY




(7A-FE A/T) E 7 DARK GRAY




(7A-FE M/T) E 7 DARK GRAY




H 8 ORANGE



I 2 BLACK




J 5




(HINT:SEE PAGE 7)

J 6



(HINT:SEE PAGE 7)


J 9





(HINT:SEE PAGE 7)



GROUND POINT







*6 : CONVERTIBLE
 *9 : W/ POWER WINDOW
 *10 : SEPARATE TYPE AMPLIFIER
 *11 : BUILT-IN TYPE AMPLIFIER

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
J 1	33	J 7	33		
J 4	33	J 9	33		

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
1	25	LEFT KICK PANEL
2	26	ENGINE COMPARTMENT LEFT
4	25	RIGHT KICK PANEL
5	27	ENGINE COMPARTMENT FRONT RIGHT
6	27	ENGINE COMPARTMENT FRONT LEFT

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IA	20	ENGINE ROOM MAIN WIRE AND INPANE J/B (LEFT KICK PANEL)
IC	20	INSTRUMENT PANEL WIRE AND INPANE J/B (LEFT KICK PANEL)
IE		
1E	22	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT KICK PANEL)
1H	22	ROOF WIRE AND J/B NO.1 (LEFT KICK PANEL)
1J	22	COWL WIRE AND J/B NO.1 (LEFT KICK PANEL)
3A	24	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)
3B		
3C		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	38 (5S-FE)	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (INSIDE OF R/B NO.2)
	40 (7A-FE)	
IC2	42	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IC3	42	ENGINE ROOM MAIN WIRE AND COWL WIRE (INSIDE OF R/B NO.4)
IE2	42	FRONT DOOR LH WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IG1	42	INSTRUMENT PANEL WIRE AND FLOOR WIRE (LEFT KICK PANEL)
II1	44	ENGINE WIRE AND INSTRUMENT PANEL WIRE (NEAR THE ENGINE CONTROL MODULE)
II2		
IJ1	44	ENGINE WIRE AND COWL WIRE (INSTRUMENT PANEL CENTER)
IK2	44	INSTRUMENT PANEL WIRE AND FLOOR NO.3 WIRE (BEHIND THE RADIO AND PLAYER)
IL1	44	COWL WIRE AND A/C SUB WIRE (UPPER THE A/C UNIT)
IN1	44	FRONT DOOR RH WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)
BO1	46 (L/B)	BACK DOOR NO.1 WIRE AND FLOOR WIRE (BACK DOOR UPPER LEFT)
BP1	46 (L/B)	BACK DOOR NO.2 WIRE AND BACK DOOR NO.1 WIRE (BACK DOOR UPPER LEFT)
BQ1	46 (L/B)	FLOOR WIRE AND LUGGAGE ROOM WIRE (LUGGAGE ROOM LEFT)
	48 (C/P)	
	50 (CONVERTIBLE)	



GROUND POINT


▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EA	38 (5S-FE)	FRONT SIDE OF RIGHT FENDER
	40 (7A-FE)	
EB	38 (5S-FE)	FRONT SIDE OF LEFT FENDER
	40 (7A-FE)	
EC	38 (5S-FE)	INTAKE MANIFOLD
	40 (7A-FE)	
ID	42	LEFT KICK PANEL
IE	42	INSTRUMENT PANEL BRACE LH
IF	42	R/B NO.4 SET BOLT
BG	46 (L/B)	ROOF LEFT
	48 (C/P)	
BH	46 (L/B)	UNDER THE LEFT CENTER PILLAR
	48 (C/P)	
	50 (CONVERTIBLE)	
BJ	48 (C/P)	RIGHT REAR PILLAR
BK	46 (L/B)	BACK DOOR CENTER
	48 (C/P)	
	50 (CONVERTIBLE)	
BL	50 (CONVERTIBLE)	ROOM PARTITION PANEL
BM	46 (L/B)	BACK DOOR RIGHT

○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E 1	38 (5S-FE)	ENGINE ROOM MAIN WIRE	B 2	48 (C/P)	FRONT DOOR LH WIRE
	40 (7A-FE)			50 (CONVERTIBLE)	
E 2	38 (5S-FE)	ENGINE ROOM MAIN WIRE	B 4	46 (L/B)	ROOF WIRE
	40 (7A-FE)			48 (C/P)	
E 4	38 (5S-FE)	ENGINE ROOM MAIN WIRE	B 5	50 (CONVERTIBLE)	ROOF WIRE
	40 (7A-FE)			46 (L/B)	
E 6	38 (5S-FE)	ENGINE WIRE	B 5	48 (C/P)	FLOOR WIRE
	40 (7A-FE)			50 (CONVERTIBLE)	
I 1	44	COWL WIRE	B 6	46 (L/B)	FRONT DOOR RH WIRE
I 3	44	INSTRUMENT PANEL WIRE		48 (C/P)	
I 4			50 (CONVERTIBLE)		
I 6	44	ENGINE WIRE	B 8	46 (L/B)	FLOOR WIRE
I 8				48 (C/P)	
I 9	44	FLOOR NO. 3 WIRE	B 9	46 (L/B)	LUGGAGE ROOM WIRE
I11	44	COWL WIRE	B11	48 (C/P)	FLOOR WIRE
I12			B14	50 (CONVERTIBLE)	
I13	44	ENGINE WIRE	B15	46 (L/B)	FLOOR WIRE
I15	44	COWL WIRE	B16	46 (L/B)	BACK DOOR NO. 2 WIRE
B 2	46 (L/B)	FRONT DOOR LH WIRE			

J 1




(HINT:SEE PAGE 7)

(5S-FE) J 4




(HINT:SEE PAGE 7)

(7A-FE) J 4




(HINT:SEE PAGE 7)

J 7



(HINT:SEE PAGE 7)

J 9




(HINT:SEE PAGE 7)

K OVERALL ELECTRICAL WIRING DIAGRAM

* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the wiring diagram section.

220 HOW TO READ THIS SECTION




Engine Control

Starting


Power Source

- G**: Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it). Junction Blocks are shaded to clearly separate them from other parts (different junction blocks are shaded differently for further clarification).



Example:

- H**: Indicates related system.
- I**: Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows (↗).



- J**: () is used to indicate different wiring and connector, etc. when the vehicle model, engine type, or specification is different.
- K**: Indicates a shielded cable.




- L**: Indicates and located on ground point.
- M**: The same code occurring on the next page indicates that the wire harness is continuous.

- A**: System Title
- B**: Indicates the wiring color.


Wire colors are indicated by an alphabetical code.

B = Black L = Blue R = Red
 BR = Brown LG = Light Green V = Violet
 G = Green O = Orange W = White
 GR = Gray P = Pink Y = Yellow

The first letter indicates the basic wire color and the second letter indicates the color of the stripe.



- C**: Indicates the connector to be connected to a part (the numeral indicates the pin No.)
- D**: The position of the parts is the same as shown in the wiring diagram and wire routing.
- E**: Indicates the pin number of the connector. The numbering system is different for female and male connectors.



The numbering system for the overall wiring diagram is the same as above.

- F**: Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B.
- Example: **1** Indicates Relay Block No. 1.

K OVERALL ELECTRICAL WIRING DIAGRAM


SYSTEM INDEX

1996 Model (Location No. 1 to 27)

SYSTEMS	LOCATION	SYSTEMS	LOCATION	SYSTEMS	LOCATION
ABS	17-2	Fog Light	27-2	Rear Window Defogger	19-3
Air Conditioning	26-3	Front Wiper and Washer	11-2	Rear Wiper and Washer	11-3
Auto Antenna	22-4	Headlight	4-2 (USA) 5-2 (Canada)	Remote Control Mirror	12-2
Back-Up Light	10-2	Horn	8-4	Shift Lock	9-2
Charging	1-3	Ignition	1-4	SRS	18-2
Cigarette Lighter	15-3	Illumination	7-2	Starting	1-2
Clock	15-4	Interior Light	6-2	Stop Light	10-3
Combination Meter	23-2	Light Auto Turn Off	4-4	Taillight	8-2
Cruise Control	16-2	Moon Roof	15-2	Top Stack	24-2
Door Lock Control	14-2	Power Source	1-27-1	Turn Signal and Hazard Warning Light	9-3
Electric Tension Reducer	24-4	Power Window	13-2	Unlock and Seat Belt Warning	19-2
Electronically Controlled Transmission	20-2	Radiator Fan and Condenser Fan	25-2		
Engine Control	2-2 (5S-FE) 3-2 (7A-FE)	Radio and Player	21-2 (Separate Type Amplifier) 22-2 (Built-in Type Amplifier)		

1 CELICA ELECTRICAL WIRING DIAGRAM

*1: Canada



Power Source

Starting

Charging

Ignition

1

2

3


4

*1: Canada

K OVERALL ELECTRICAL WIRING DIAGRAM


2 CELICA

(Cont. next page)



Engine Control(5S-FE)

Power Source



Under the left center pillar

Under the left center pillar


Front side of left fender

Under the left center pillar

Under the left center pillar

Under the left center pillar


2 CELICA(Cont' d)




K OVERALL ELECTRICAL WIRING DIAGRAM

3 CELICA

(Cont. next page)




3 CELICA(Cont' d)




K OVERALL ELECTRICAL WIRING DIAGRAM

4 CELICA




5 CELICA




K OVERALL ELECTRICAL WIRING DIAGRAM

6 CELICA




7 CELICA




K OVERALL ELECTRICAL WIRING DIAGRAM

8 CELICA




9 CELICA




K OVERALL ELECTRICAL WIRING DIAGRAM

10 CELICA




11 CELICA



K OVERALL ELECTRICAL WIRING DIAGRAM


12 CELICA




*1 : w/Power Window
*2 : w/oPower Window

K OVERALL ELECTRICAL WIRING DIAGRAM

14 CELICA




15 CELICA




K OVERALL ELECTRICAL WIRING DIAGRAM

16 CELICA



17 CELICA



K OVERALL ELECTRICAL WIRING DIAGRAM


18 CELICA




Power Source



SRS



19 CELICA



K OVERALL ELECTRICAL WIRING DIAGRAM


20 CELICA




Power Source



Electronically Controlled Transmission



21 CELICA



Radio and Player (Separate Type Amplifier)






Power Source

2








3

4

*1: JB, CP
*2: W, R, H
*3: W, D, H, R, H




To Auto Antenna
Motor and Relay
<22-4




K OVERALL ELECTRICAL WIRING DIAGRAM

22 CELICA




23 CELICA



K OVERALL ELECTRICAL WIRING DIAGRAM


24 CELICA



Power Source

Radiator Fan and Condenser Fan


*1: 5S EE
*2: 7A EE




K OVERALL ELECTRICAL WIRING DIAGRAM

26 CELICA

(Cont. next page)



26 CELICA (Cont' d)



1: 55E

8

7

6

5

K OVERALL ELECTRICAL WIRING DIAGRAM


27 CELICA



Power Source



Fog Light



4

3

2

1

See Headlight System <4-1> <5-1>

15A HEAD(LH)
15A HEAD(LH)
(USA)
15A HEAD(LH)
(CANADA)

20A FOG

FOG LIGHT RELAY

F11 FRONT FOG LIGHT LH
F12 FRONT FOG LIGHT RH

BFG	LFG	HL	EL
OFF			
FOG			
LOW			

COMB. SW
FOG LIGHT SW

BATTERY

EL MAIN
2.0L

Front side of left fender

JUNCTION CONNECTOR (Earth)
Left kick panel